Sonix Firmware Update Manual

Date: 2016/06/02

- 1. Download "Linux_BurnerAp_1.0.3.tgz" and "SN9C2720M_Firmware.aes" from GitHub. Linux_BurnerAp_1.0.3.tgz is Linux firmware update tool. SN9C2720M_Firmware.aes is firmware binary encryption file.
- 2. Use OpenSSL command to decryption SN9C2720M_Firmware.aes and using public key is "sonix". openssl enc -aes-256-cbc -in SN9C2720M_Firmware.aes -out SN9C2720M_Firmware_1.bin -d -k sonix
- 3. install libusb

\$sudo apt-get install libusb-dev

4. build BurnerAP

\$cd <BurnerAp>

\$make

- 5. Connect your device
- 6. Specify fw path to update

\$sudo ./fw_update [fw_path]