Sonix Firmware Update Manual

Date: 2016/05/25

Linux Version

- 1. Download "Linux BurnerAp 1.0.2.tgz" from GitHub.
- 2. install libusb

\$sudo apt-get install libusb-dev

3. build BurnerAP

\$cd <BurnerAp>

\$make


- 4. Connect your device
- 5. Specify fw path to update \$sudo ./fw update [fw path]

Windows Version

- 1. Download "Binary_ SN9C2720M_Firmware_20160509v01.zip" from GitHub. Extract the zip file. Password is "sonix".
- 2. The folder has 6 files that include firmware update tool and binary file.



3. Run "BurnAP_Dell.exe". Below is software layout.



- 4. Show current firmware version in FW Version field after press "FW Version" button.
- 5. Press Burn Flash button to update firmware. Result and FW Version field will show "Burn File OK!" when update finish.

