

SIMATIC IPC227G - Full setup & configuration

Requirements

Hardware Requirements

- RAM (Memory) : Minimum 16GB (Recommended 32 or higher)
- Hard Disk Size : Minimum 300GB of available space
- CPU Cores : Minimum 4
- Network Interface : IEM Virtual Machine must have exactly one network interface configured
- Static IP Address : Required for stable communications

Software Requirements

- VMware Workstation Pro (Version 16 or later)

Pre-Configuration Steps

- Create/Register Siemens Account
- Verify via Email and Login
- IEM Hub is where you can access user panel and IEM instances

Configuration

1) Launch VMware Workstation Pro

- Open VMware Workstation Pro on your host system
- Ensure VMware is properly installed and licensed
- Plug in all network adaptors and verify connectivity

2) Import Virtual Machine

- Go to File ➡ Open (Ctrl + O)
- Navigate to downloaded .ova file
- Open it
- When prompted, assign a name to Virtual Machine
- Choose suitable storage location
- Click Import

3) Configure network settings in VMware

- Go to Edit ➡ Virtual Network Editor
 - Click "Change Settings"
 - Under VMnet0, set Network Type to "Bridged"
 - Select your physical adapter (preferably Intel(R) Dual Band Wireless-AC 8260) or your systems primary network interface
 - Click Apply and Ok
- (Bridged Mode ensures the VM appears as a separate device on same network as your host)

4) Power on Virtual Machine

- Click "Power on this Virtual Machine"
- Wait for IEM to boot
- Once it loads, note the IP address on the screen

5) Access the Configuration Portal

- On your host computer, open any web browser (eg: Chrome)
- Enter the IP address on the VM and click Enter
- IEM setup interface will appear

6) Network Configuration

- Assign the network details as per your preference or enter these details
 - IP Address : 192.168.1.140
 - Subnet Mask : 255.255.255.0
 - Gateway : 192.168.1.1
 - Primary DNS : 8.8.8.8
 - Secondary DNS : NIL
- Click Update and wait for system to apply changes
- The webpage will reload with new IP address

7) Login Credentials

- Set up your own username and password
- Click Next to continue

8) Upload Provisioning file

- You will be asked to upload a provisioning file, in order to generate it:
 - Go to IEM Hub → Instances → Create New Instance
 - Give any instance name
 - Download the file (.zip or .json)
- Upload the file in configuration screen
- Click Next

9) Configure FQDN

- This field is optional, you can skip it
- Or you can give a custom domain name (eg: iem.localdomain)
- Click Next to proceed

10) Recovery Key and Submission

- The system will generate a recovery key
- Note down the key
- Click Submit to finalize the setup
- The system will begin auto-configuration, this will take a few minutes

11) Verify Configuration Status

- After setup completes, go to IEM Hub → Instances
- Check if the newly created instance is "Active"
- If it's still "Pending", wait a few minutes and refresh

12) Access Edge Management Dashboard

- Click "Edge Management"
- Login using the credentials you set up in step 7
- You will be directed to IEM Home Screen