

Standard Operating Procedure: SOP-013

Machine: Pump P102

Revision Date: 2026-06-28

Purpose: To establish safe and effective operating procedures.

Scope: Applies to all operators in the Production department.

Required PPE: Safety glasses, steel-toed boots, gloves.

Tools Required: Standard toolkit, calibration gauge.

Step-by-step Procedure:

1. Ensure lockout/tagout is verified before starting.
2. Check primary power feeds and lubrication levels.
3. Initiate start sequence per manufacturer guidelines.
4. Monitor for abnormal vibrations or sounds.

Safety Precautions: Never bypass interlocks.

References: ISO9001, Machine Manual