
VIDEOKAMERA CANON XF-100

Anleitung zur Verwendung

Überblick

- Aufzeichnung: MPEG2-MXF, FullHD 50 Mbps, 4:2:2 auf CF-Card x 2
- Objektiv: 30 300 mm KB f/1.8 f/2.8, achromat/asphärisch
- Infrarot-Modus, Optischer Stabilisator
- 2 XLR-Inputs mit Mixer
- Variable Bildraten 12 50 Frames
- ND-Filter, Face-Detection, Manueller AF, Auto AF mit variabler Geschwindigkeit
- HD-Monitor-Anschluss HDMI, Kopfhörer Anschluss

Zubehör




Kompakt-Netzgerät CA-930 (einschl. Netzkabel)



Mikrofonhalter



Akku BP-925 (einschl. Kontaktabdeckung)



DC-Kabel DC-930



Component-Kabel CTC-100/S



Gegenlichtblende



Objektivdeckel



Fernbedienung WL-D6000 (einschl. Lithiumbatterie CR2025)

Technische Daten

XA10 XF100

IMAGE SENSOR		
Sensor System Total pixels per sensor Effective pixels per sensor Minimum illumination	1/3 type HD CMOS Pro Bayer pattern filter 2.37 megapixels 2.07 megapixels Auto: 1.3 lux (with Auto Slow Shutter) Slow Shutter: 0.1 lux	1/3 type CMOS Bayer pattern filter 2.37 megapixels 2.07 megapixels Full Auto (24dB gain), 50i/25p: 3.8 lux / 1.9 lux Manual mode (33dB gain), 50i/25p: 1.3lux / 0.7 lux
Horizontal Resolution	900 TV lines or more (1920 x 1080i mode)	900 TV lines or more (1920 x 1080i mode)
LENS		
Zoom ratio Focal length	10x 4.25 - 42.5mm (35mm equivalent: 30.4 - 304mm)	10x 4.25 - 42.5mm (35mm equivalent: 30.4 - 304mm)
Minimum focus distance	60cm (throughout zoom range); 20mm (wide angle)	60cm (throughout zoom range); 20mm (wide angle)
ND filter	Built-in gradation filter (Auto or Off)	Built-in gradation filter (Auto or Off)
Zoom control	Slider or Handle; Selectable Shockless Zoom mode.	Ring, Rocker or Handle; Selectable Shockless Zoom mode
Zoom speed Focus control	Zoom Slider: Variable speed/Fixed speed (Fast/Normal/Slow, 16 speed level settings available in each mode); Handle zoom: Fixed speed (Fast/Normal/ Slow, 16 speed level settings available in each mode)	Zoom Rocker: Variable speed/Fixed speed (Fast/Normal/Slow, 16 speed level settings available in each mode); Handle zoom: Fixed speed (Fast/Normal/ Slow, 16 speed level settings available in each mode)
rocus control	MANUAL: Lens ring, Touchscreen LCD (Touch Focus, Touch and Track), Focus Preset AUTO: Face Priority AF / Face Only AF / Instant AF / Medium AF / TV AF	Ring control or automatic (Instant AF, Medium AF, TV AF, Face Detection AF, Face Only AF)
Iris control	MANUAL: Custom dial control; Touchscreen control AUTO: YES	Ring control; Custom dial control; Full Auto
Aperture range	f1.8 - f8	f1.8 - f22
Filter diameter	58mm	58mm
Lens elements/groups	12/10	12/10
Image stabilization system	Optical lens shift system (angle & vector movement detection); 3 modes: Dynamic, Standard, Powered	Optical lens shift system (angle & vector movement detection); 3 modes: Dynamic, Standard. Powered
Digital zoom	2x	1.5x; 3x; 6x
IMAGE PROCESSOR		
Type	DIGIC DV III	DIGIC DV III

EVF		
Size Dots Image quality adjustments Adjustable Correction lens	0.61cm (0.24"), 100% view 260,000 - - + 2.0 to -5.5 diopter	0.61cm (0.24"), 100% view 260000 Brightness, contrast, colour, backlight, black & white Vertical tilt + 2.0 to -5.5 diopter
INPUTS/OUTPUTS		
Audio in Headphone output Video monitor output HDMI IEEE 1394 (Firewire) USB HD/SD-SDI output Time code Genlock Component out AV terminal DC input Remote Control Terminal	XLR inputs with 48V phantom power (x2), 3.5mm microphone input jack 3.5mm stereo jack NO YES (HDMI [™] Mini Connector: v1.3, out only, 1080/50p output possible) NO YES (Mini-B, USB 2.0 Hi-Speed) NO NO NO NO NO SES (output only) 3.5mm mini jack (output only for video and audio) YES 2.5mm mini jack YES (SMPTE)	XLR inputs with 48V phantom power (x2), 3.5mm microphone input jack 3.5mm stereo jack NO YES (Type A, output only) NO YES (Mini-B, USB 2.0 Hi-Speed) NO NO NO VES (output only) 3.5mm mini jack (output only for video and audio) YES 2.5mm mini jack Type 1/Type 2 (EBU/SMPTE)
MISC	123 (3) 11 (2)	19pe 17 19pe 2 (25075) 11 12)
Tally lamp Accessory shoe Custom key Custom Dial	YES YES (cold shoe) YES (2 assignable buttons; select from 9 functions) YES (Shutter Priority (Tv), Aperture Priority (Av), Manual Exposure, exposure compensation, AGC limit)	YES (x2) YES (cold shoe) YES (10 assignable buttons; select from 34 functions) YES (Iris, teleconverter, headphone volume, Face AF, IR Lamp control)
EXPOSURE		
Exposure metering Exposure range Exposure compensation Auto Exposure mode Push Auto Iris Exposure Lock Auto Gain Control setting Auto Gain Setting Gain setting	Centre-weighted average or segment evaluative (determined by shooting mode) - 2 to +2 EV (13 steps) Smart Auto, Face Detection AE No YES Full Auto / AGC On / Manual 0 to 24dB, 1dB increments (0 to 18dB in Cinema Mode) 0 to 24dB, 1dB increments	Standard (centre weighted), Spotlight, Backlight 50 - 100,000 lux -2 to +2 EV (13 steps) Full Auto No - Full Auto / AGC On / Manual 3dB; 6dB; 9dB; 12dB; 15dB; 18dB; 21dB (OFF/24dB) Assignable L, M, H settings (-6dB / -3dB / 0dB/ 3dB / 6dB/ 12dB / 18dB / 24dB / 33dB / TUNE (0.5 dB increments from 0 to 24 dB)

XF100


XA10

RECORDING					
Video storage media	64GB built-in flash memory; SDXC/SDHC/ SD memory card (2 card slots); Double slot (simultaneous) recording and Relay (continuous) recording possible. ¹	Type 1 Compact Flash memory cards (2 card slots); Double slot (simultaneous) recording and Relay (continuous) recording possible. ¹			
Type	Class 4 or higher SDHC card required for	UDMA4, 30MB/s or faster (40MB/s or			
.,,,,,	1920x1080 recording	faster for Fast/Slow recording)	SHUTTER SPEED		
Recording time	64GB internal memory or SDXC card: 5hrs 55mins (MXP mode, max. quality) ¹ 24hrs 30mins (LP mode, lowest quality) ¹	32GB CF card: Up to 80mins (1080/50i @ 50 Mbps)	Control Modes	Full Auto / Manual control (touchscreen LCD or control dial)	Full Auto / Manual joystick control (Auto; Speed; Angle; Clear Scan (CS); Slow Shutter (SLS); IR Slow Shutter)
Recording file format Recording format	AVCHD high profile (MPEG4-AVC/H.264) AVCHD (all modes variable bit rate, 4:2:0	Material eXchange Format (MXF) MPEG-2 Long GOP	Shutter speed	1/6 to 1/2000 (depending on Scene Mode and frame rate)	1/18 to 1/2000 depending on frame rate
J	colour sampling) MXP: 1920x1080, 24Mbps;	50Mbps CBR (4:2:2) MPEG-2 422@HL; 35Mbps VBR (4:2:0) MPEG-2 MP@HL;	Shutter Angle Slow Shutter (SLS)	- 1/2 to 1/500 (Low Light Scene Mode)	11.25° to 360° depending on frame rate 1/3, 1/6, 1/12, 1/25 (depending on
	FXP: 1920x1080, 17Mbps; XP+: 1440x1080, 12Mbps; SP: 1440x1080, 7Mbps;	25Mbps CBR (4:2:0) MPEG-2 MP@H14	Clear Scan	NO	frame rate) 50i/p: 50 to 251.15Hz; 25p: 25 to 251.15Hz
	LP: 1440x1080, 5Mbps				231.13112
Recording frame rate	1920 x 1080/50i:	50Mbps: 1920 x 1080/50i, 25p;	INFRARED		
	1920 x 1080/25p (50i recorded stream)	1280 x 720/50p, 25p; 35Mbps: 1920 x 1080/50i, 25p;	Infrared shooting mode Built-in IR lamp	YES (green or white) YES	YES (green or white) YES
		1280 x 720/50p, 25p;	WHITE BALANCE		
		25Mbps: 1440 x 1080/50i, 25p	Auto	YES	YES
Slow/Fast motion	NO	YES	Preset	Set 1, Set 2, Preset (Daylight, Shade,	A, B, Preset (Daylight, Tungsten),
		720p: 12, 15, 18, 20, 21, 22, 23, 24, 25, 26, 27, 28, 30, 32, 34, 37, 42, 45,		Cloudy, Tungsten , Fluorescent H, Fluorescent, Colour Temperature	Colour Temperature
		48, 50fps 1080p: 12, 15, 18, 20, 21, 22, 23,	AUDIO		
		24. 25fps	Recording	Dolby Digital 2ch (AC-3 2ch), 48kHz	16-bit 2ch (48 kHz) linear PCM
Interval Record	NO	YES. 2. 6 or 12 frames. 25 time intervals	Recording	sampling	10 bit 2ci (40 ki i2) iiiicai i ci i
Frame Record	NO	YES. 2, 6 or 12 frames	Control	Audio limiter, Auto/manual settings via	Audio limiter, Auto/manual settings via
Pre Record (cache record)	YES (3 seconds)	YES (3 seconds)		control dials on handle	control dials on handle
Scan Reverse	YES. Up/down, left/right,	YES. Up/down, left/right,	Microphone attenuation	YES	YES
	up/down/left/right image inversion	up/down/left/right image inversion	Microphone level meter	YES	YES
HD->SD conversion	YES (during playback)	-'	Zoom Microphone	YES (customisable frequency response	-
Internal Data Transfer	MOVIE & STILLS: Yes (internal memory	-		and directivity)	
	to card, card to card)		ACCESSORIES		
LCD			Optional	Wide Converter WD-H58W, Teleconverter	Wide Converter WD-H58W, Teleconverter
Size Dots Image quality adjustments Adjustable	8.8cm (3.5"), 100% view 922,000 Brightness, backlight YES (270 degree rotation about	8.8cm (3.5"), 100% view 920000 Brightness, contrast, colour, sharpness, backlight, black & white Yes (270 degree rotation about		TL-H58, 58mm lens filters, Batteries BP-808/BP-819/BP-827, Battery Charger CG-800, Video Light VL Li II, Remote Control ZR-2000, Component Cable CTC-100, HDMI cable HTC-100, Wireless	TL-H58, Batteries BP-930, BP-945, BP-950G, BP-970G, BP-955, BP-975, Compact Power Adapter CA-920, Compact Car adapter CB-920, DC Coupler DC-920, Shoulder Brace SBR-1000. Tripod Adapter
,	horizontal axis)	horizontal axis)		Microphone WM-V1.	TA-100, Zoom Remote Control ZR-2000, Video Light VL-10Li II, Tripod Base TB-1.
Waveform Monitor	YES Reaking: Magnifying: Edge Monitor	YES Peaking; Magnifying; Edge Monitor	BATTERY		
Focus Assist	Peaking; Magnifying; Edge Monitor (using waveform display)	(using waveform display)		Lithium cain batton (built in)	Lithium coin batton (built in)
Peaking	YES YES	Peaking 1, Peaking 2 (Colour, Gain,	Backup power supply	Lithium coin battery (built-in) 3.2W ²	Lithium coin battery (built-in) 5.1W ⁵
reaking	10	Frequency customisable for each)	Power Consumption Continuous Recording	Supplied BP-808: Approx. 110 minutes ²	Supplied BP-925: Approx. 205 minutes ³
Zebra	YES (70% or 100% reference level)	Level 1; Level 2; Both; Output via HDMI		Optional BP-827: Approx. 345 minutes ²	Optional BP-975: Approx. 635 minutes ³
Markers	ON/OFF (Grid, Horizontal, Centre)	On/Off (Aspect ratio, Safe area, Grid.	MISCELLANEOUS		
ancis	2 2 (and, Hansandi, Cariac)	Horizontal, Centre)	Dimensions	Approx 130 x 177 x 205mm (including lens hood and microphone holder)	Approx 139 x 191 x 268mm (including lens hood and microphone holder)
			Detachable handle	YES	-
			Weight (camera only)	775g	1020g
			Weight (fully equipped)	820g	1120g
			Operating Temperature	-5°C to +45°C, 60% relative humidity	-5°C to +45°C, 60% relative humidity
	I	I	range	I	I

RECORDING

Seitenansicht

Bezeichnung der Teile




- 1 Abdeckungen für CF-Kartenschlitz A (CFA) und CF-Kartenschlitz B (CFB)
- 2 CF-Kartenschlitze A (CFA) und B (CFB) (CCC 35)
- 3 Entriegelungstasten für die CF-Karten (\$\subset\$ 36)
- 4 POWER (Ein)-Schalter (24)
- 5 ON/OFF-Anzeige
- 6 SLOT SELECT (Auswahl des CF-Kartenschlitzes)
 -Taste (□ 38)
- 7 DISP. (Anzeige)-Taste (\$\infty\$ 44)/ BATT. (Akkuanzeige)-Taste (\$\infty\$ 22)
- 8 RESET (Zurücksetzen)-Taste (🕮 166)
- 9 INDEX (Index)-Taste (☐ 117)/ ☐ (Aufnahmeprüfung)-Taste (☐ 91)
- 10 № (Einstellung des Weißabgleichs)-Taste (64)

- 11 WB (Weißabgleich)-Taste (4)
- 12 CAMERA (Camcorder)-Schalter (43)
- 13 Schalter der Abdeckungen für CF-Kartenschlitz A (CFA) und CF-Kartenschlitz B (CFB) (C) 35)
- 14 SHUTTER (Verschluss)-Taste (\$\sup\$ 59)
- 15 GAIN (Verstärkung)-Taste (🕮 56)
- 16 IRIS (Blende)-Taste (Q 60)
- 18 AF/MF (automatische/manuelle Scharfeinstellung)
 -Taste (


 49, 51)
- 19 Schalter für Objektivring (🕮 49, 60, 66)
- 20 Objektivring (49, 60, 66)
- 21 Gegenlichtblende (29)

Seitenansicht




- 1 REMOTE (Fernbedienung)-Anschluss
- 2 Anzeige für SD-Kartenzugriff (37)
- 3 SD-Kartenschlitz (37)
- 4 Abdeckung des SD-Kartenschlitzes
- 5 MIC (Mikrofon)-Anschluss (\$\square\$ 80)
- 6 XLR-Anschlüsse (CH1 und CH2) (81)
- 7 Arretierschraube für Gegenlichtblende (💢 29)
- 8 XF105 HD/SD SDI-Anschluss (CC 133)
- 9 XF105 GENLOCK-Anschluss (77)/TC (Timecode)-Anschluss (78)
- 10 Griffriemen (CC 31)

Frontansicht




- 1 Eingebautes Mikrofon (\$\sum 80\$)
- 2 Eingebauter Lautsprecher (120)
- 3 Gurtöse (32)
- 4 CUSTOM (benutzerdefinierbare) Taste (\$\square\$ 48)
- 5 INFRARED (Infrarot)-Schalter (97)
- 6 Instant-AF-Sensor (\$\sup\$51)
- 7 Fernbedienungssensor (\$\sum 33)\$
- 8 Infrarot-Leuchte (97)
- 9 Halter für das Mikrofonkabel (81)
- 10 Mikrofonhalter (\$\square\$ 81)
- 11 Arretierschraube für Mikrofon (QQ 81)

Rückansicht



- 1 Sucher (X 29, 30)
- 2 Sucher-Scharfstellhebel (QQ 29)
- 3 BATT. RELEASE (Akkuentriegelung)-Taste (QQ 22)
- 4 START/STOP (Start/Stopp)-Taste (42)
- 5 Gurtöse (QQ 32)
- 6 WFM (Wellenform-Monitor)-Taste (\$\sum 88\$)/freie Taste 3 (\$\sum 101\$)
- 7 ZEBRA-Taste (71)/freie Taste 2 (101)
- 8 CANCEL (Löschen)-Taste (27)
- 9 Joystick (27)/SET (Einstell)-Taste (27)
- 10 MENU (Menü)-Taste (27)
- 11 LCD-Monitor (CC 30)
- 12 POWERED IS-Taste (54)/freie Taste 1 (101)
- 13 POWER SAVE (Energiespar)-Taste (46)

Topansicht




- 1 Vordere Kontrollleuchte (\$\sum 42\$)
- 2 Zubehörschuh

Zum Anbringen von Zubehör wie der optionalen Batteriebetriebene Video-Lampe VL-10Li II.

- 3 Hintere Kontrollleuchte (42)
- 4 START/STOP-Verriegelungshebel (42)
- 5 START/STOP-Taste (42)
- 6 Griffanschluss für Schrauben 0,64 cm (1/4")
- 7 Zoomregler am Seitengriff (\$\superscript{\
- 8 MAGN. (Vergrößerung)-Taste (☐ 51)/freie Taste 4 (☐ 101)
- 9 CF-Kartenschlitz A (CFA) und CF-Kartenschlitz B (CFB) Zugriffslampen (C 36)
- 10 Zoomregler am Tragegriff (\$\square\$ 68)
- 11 Tonpegel-Einstellräder für CH1 und CH2 (◯ 84)


Bedienfelder

Bedienfeld (1)




- Tonpegel-Schalter für CH1 und CH2 (\$\square\$ 84)
- 2 XLR-Anschluss-Schalter für CH1 und CH2 (☐ 82)
- 3 AUDIO IN (Audio-Eingang)-Schalter für CH1 und CH2 (C) 80, 82)

Anschlüsse 1)



- 1 HD/SD COMPONENT OUT-Anschluss (🛄 133)
- 2 USB-Anschluss
- 3 HDMI OUT-Anschluss (QQ 133)

Anschlüsse 2




- 4 ∩ (Kopfhörer)-Anschluss (□ 85)
- 5 AV-Anschluss (134)
- 6 DC IN-Anschluss (QQ 23)


Inbetriebnahme

- Speicherkarten CF Typ 1 einlegen. Auf Größe und Geschwindigkeit achten! Der SD-Slot ist nicht zur Aufnahme von Videomaterial gedacht!
- Kamera einschalten (Schiebeschalter auf CAMERA bewegen)
- Bildschirm ausklappen, und im Menü CAMERA/MEDIA die Karten initialisieren
- Bei der Aufnahme Bildschirm einklappen und den Sucher verwenden wenn möglich um Akkuleistung zu sparen
- Eine der START/STOP-Tasten drücken (auf Verriegelung achten!)
- Jedes drücken der START/STOP-Tasten erzeugt einen neuen Clip auf der Karte

Bildschirmanzeigen



Bei Anzeige von Datum und Uhrzeit:



- 1 Verbleibende Akkuzeit* (45)
- 2 Doppel-Aufnahme (\$\square\$39\$)
- 3 Aufnahmevorgang* (45)
- 4 Aufzeichnung der Bildschirmanzeigen* (☐ 112)
- 5 Genlock (QQ 77)
- 6 Timecode* (☐ 74)
- 7 Intervallzähler* (\$\square\$ 92)
- 8 Status der SD-Karte*
- 9 Bitrate/Auflösung* (☐ 47)
- 10 Bildrate* (47)
- 11 XF105 SDI-Aufnahmesignal* (157)
- 12 Ausgabe der Bildschirmanzeigen* (154)
- 13 Fernbedienung* (CC 154)
- 14 Motiventfernung* (CD 153)
- 15 Objektivvorsatz*
- 16 Vergrößerung* (☐ 51)
- 17 Peaking* (🛄 50)
- 18 Digitaler Telekonverter* (111 149)
- 19 User Memo* (XXX 86)
- 20 User Bit-Daten* (76)
- 22 Audiopegelmessung (84)

- 23 Audiopegelbegrenzung (🕮 84)
- 24 Bildstabilisierung* (54)/OIS Lens-Shift (99)
- 25 Verschlusszeit* (\$\square\$ 58)
- 26 AE-Pegel* (61)
- 27 Verstärkung* (D 55)
- 28 Blendenwert* (CD 60)
- 29 Weißabgleich* (63)
- 30 Vollautomatischer Modus* (43)/ Sperre* (43)
- 31 Scharfstellmodus* (49)
- 32 ND Filter* (148)
- 33 Benutzerdefiniertes Bild* (103)
- 34 Lichtmessungsmodus* (D 61)
- 35 Infrarot-Modus, Infrarot-Licht (🛄 97)
- 36 Brennweitenanzeige (XX 100)
- 37 Zoomanzeige* (\$\sum 66)\$
- 38 Verbleibende Aufnahmezeit für Doppel-Aufnahme (CD 39)
- 39 CF-Kartenstatus/verfügbare Aufnahmezeit* (□ 45)
- 40 Belichtungsanzeige* (☐ 56)
- 41 Datum/Zeit* (25)

Einstellen des Videomodus

- Menü BITRATE/AUFLÖSUNG wählen
- HQ: 50 Mbps 4:2:2, 1080 **i50**/p25 oder 720 **p50**/25
- MQ: 35 Mbps 4:2:0, 1080 **i50**/p25 oder 720 **p50**/25
- Aufzeichnungsformat ist MXF Container, MPEG2 (nur I-Frames)
- HD-Standards beachten:

Anzahl sichtbarer Zeilen	Abtastung	Anzahl Vollbilder	Norm
1080	i (interlaced)	25 (50 Halbbilder)	ITU-R BT.709 SMPTE 292M
720	P (progressiv)	50	ITU-R BT.709 SMPTE 292M

Zukünftiges Format: 1080p / 50

Wichtige Einstellungen

- Weißabgleich manuell/Auto/Fixwert
- ND-Filter um mit großer Blende bei viel Licht zu filmen (wichtig!)
- Belichtungseinstellungen wählen (Blende/Gain/Shutter/ND)
- Gain (ISO): Verstärkung bei schlechten Lichtverhältnissen
- Zebra-Level einstellen: 52 % +/- 3 % um Belichtung in Hauttönen zu kontrollieren oder 95 % um Überbelichtung zu vermeiden
- Shutter/Integrationszeit verkürzen ist bei Motiven mit schneller Bewegung sinnvoll. Standard-Shutter ist 1/50 s
- Fokus AF oder MF, Fokus-Peaking möglich, Gesichts-AF möglich.