

SNE 6.1 RESTful
Remote Control API Manual.

Contents

1	Upload Command 1.1 Parameters.	
2	Start Command 2.1 Parameters. 2.2 Curl Command 2.3 Return Value	6
3	Stop Command3.1 Parameters3.2 Curl Command3.3 Return Value	7
4	Unload Command 4.1 Parameters. 4.2 Curl Command 4.3 Return Value	8
5	Maps Command 5.1 Parameters. 5.2 Curl Command 5.3 Return Value	9
6	6.1 Parameters	
7	Impairment Information CommandImpairment Information Command7.1 Parameters7.2 Curl Command7.3 Return Value	11
8	8.1 Parameters	12 12 12 12
9	9.1 Retrieve Settings 9.1.1 Parameters 9.1.2 Curl Command 9.1.3 Return Value 9.2 Update Settings 9.2.1 Parameters 9.2.2 Curl Command 9.2.2 Curl Command	13 13 13 14 15 15 15 16

10 Jitter Commands	19
10.1 Retrieve Settings	. 19
10.1.1 Parameters	. 19
10.1.2 Curl Command	
10.1.3 Return Value	
	_
10.2 Update Settings	_
10.2.1 Parameters	
10.2.2 Curl Command	. 20
10.2.3 Return Value	. 20
10.2.4 JSON input	
11 Packet Drop Commands	21
11.1 Retrieve Settings	
11.1.1 Parameters	
11.1.2 Curl Command	
11.1.3 Return Value	
11.2 Update Settings	. 23
11.2.1 Parameters	. 23
11.2.2 Curl Command	
11.2.3 Return Value	
11.2.4 JSON input	. 24
10 December 1991 The court of t	2-
12 Bandwidth Throttle Commands	25
12.1 Retrieve Settings	
12.1.1 Parameters	. 25
12.1.2 Curl Command	. 25
12.1.3 Return Value	
12.2 Update Settings	
12.2.1 Parameters	
12.2.2 Curl Command	
12.2.3 Return Value	
12.2.4 JSON input	. 28
13 Packet Duplication Commands	30
13.1 Retrieve Settings	. 30
13.1.1 Parameters	. 30
13.1.2 Curl Command	
13.1.3 Return Value	
13.2 Update Settings	
13.2.1 Parameters	
13.2.2 Curl Command	
13.2.3 Return Value	. 31
13.2.4 JSON input	. 32
14 Ethernet Fragmentation Commands	33
14.1 Retrieve Settings	. 33
14.1.1 Parameters	
14.1.2 Curl Command	
14.1.3 Return Value	
14.2 Update Settings	
14.2.1 Parameters	. 34
14.2.2 Curl Command	. 34
14.2.3 Return Value	
14.2.4 JSON input	
4 1:4:7 JUUN IIIDUL	. 24

15 Packet Reorder Commands	35
15.1 Retrieve Settings	35
15.1.1 Parameters	35
15.1.2 Curl Command	
15.1.3 Return Value	35
15.2 Update Settings	36
15.2.1 Parameters	
15.2.2 Curl Command	
15.2.3 Return Value	
15.2.4 JSON Input	36
16 Bit Error Commands	38
16.1 Retrieve Settings	
16.1.1 Parameters	
16.1.2 Return Type	38
16.1.3 Curl Command	
16.1.4 Return Value	
16.2 Update Settings	
16.2.1 Parameters	39
16.2.2 Curl Command	
16.2.3 Return Value	
16.2.4 SON Input	
10.2.4 J3ON IIIput	29
17 Packet Counting Commands	40
17.1 Retrieve Settings	40
17.1.1 Parameters	40
17.1.2 Curl Command	40
17.1.3 Return Value	40
17.2 Update Settings	41
17.2.1 Parameters	41
17.2.2 Curl Command	41
17.2.3 Return Value	41
17.2.4 JSON Input	41
18 Traffic Generator Commands	43
18.1 Retrieve Settings	43
18.1.1 Parameters	43
18.1.2 Curl Command	43
18.1.3 Return Value	44
18.2 Update Settings	
18.2.1 Parameters	45
18.2.2 Curl Command	45
18.2.3 Return Value	
18.2.4 JSON Input	46
19 Link Commands	47
19.1 Link Up	47
19.1.1 Parameters	47
19.1.2 Curl Command	47
19.1.3 Return Value	47
19.1.3 Return value	48
19.2.1 Parameters	
19.2.2 Curl Command	
19.2.3 Return Value	48

	19.3 Link Status/Port. 19.3.1 Parameters 19.3.2 Curl Command 19.3.3 Return Value	49 49
2(O Capture Replay Commands	50
	20.1 Get Capture replay Files Information	50
	20.1.1 Parameters	50
	20.1.2 Curl Command	50
	20.1.3 Return Value	
	20.2 Upload a Capture Replay File	
	20.2.1 Parameters	
	20.2.2 Curl Command	
	20.2.3 Return Value	
	20.3 Get a Capture Replay File	
	20.3.1 Parameters	
	20.3.2 Curl Command	
	20.3.3 Return Value	
	20.4 Delete a Capture Replay File	
	20.4.1 Parameters	
	20.4.2 Return Value	52
21	1 Build Version Commands	53
Z .	21.1 Parameters	
	21.2 Curl Command	
	/ 1.) DETUIT VALUE) ⁻

1 Upload Command

Uploads a map file.

1.1 Parameters

- "mapFile" (required) The SNE map XML file to be uploaded.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

1.2 Curl Command

Single user mode

```
curl -X POST "http://192.168.1.100/api/maps/upload"
-H "accept: application/json"
-H "Content-Type: multipart/form-data"
-F "mapFile={mapFile};type=text/xml"
```

Multi-user command

```
curl -X POST "http://192.168.1.100/api/maps/upload?userToken={userToken}"
   -H "accept: application/json"
   -H "Content-Type: multipart/form-data"
   -F "mapFile=@{mapFile};type=text/xml"
```

2 Start Command

Starts executing a loaded map.

2.1 Parameters

- "mapId"(required) The SNE map name or id to be started.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

2.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/start" -H "accept: text/plain" -H "Content-Length: 0
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/start?userToken={userToken}"
    -H "accept: text/plain"
```

```
{
    "code": 1201,
    "message": "Operation Successful"
}
```

3 Stop Command

Stops executing a running map but does not unload it from the SNE.

3.1 Parameters

- "mapId"(required) The SNE map name or id to be stopped.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

3.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/stop"
-H "accept: text/plain"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/stop?userToken={userToken}"
    -H "accept: text/plain"
```

```
{
"code": 1201,
"message": "Operation Successful"
}
```

4 Unload Command

Unloads a stopped map from the SNE.

4.1 Parameters

- "mapId"(required) The SNE map name or id to be unloaded.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

4.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/unload" -H "accept: text/plain"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/unload?userToken={userToken}" -H "accept: text/plain"
```

```
{
"code": 1201,
"message": "Operation Successful"
}
```

5 Maps Command

Retrieves information about all loaded maps.

5.1 Parameters

• NONE

5.2 Curl Command

Single user mode

```
curl -X GET "http://192.168.1.100/api/maps" -H "accept: application/json"
```

```
{
    "status": {
        "code": 1201,
        "message": "Operation Successful"
},
    "maps": [
        {
            "mapName": "example_map",
            "mapId": "{F154EEC2-FED4-4F98-93D4-093D4A1D0234}",
            "state": "Active",
            "user": "",
            "portsUsed": "1,2"
        }
    ]
}
```

6 Mapld Command

Retrives information about a specific loaded map.

6.1 Parameters

- "mapId"(required) The SNE map name or id of the loaded map.
- "userToken" (optional) Specifies a valid user account name for multi-user mode.. Not required when multi-user mode is disabled.

6.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}"
-H "accept: application/json"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}?userToken={userToken}"
    -H "accept: application/json"
```

```
{
    "status": {
        "code": 1201,
        "message": "Operation Successful"
},
    "map": {
        "mapName": "example_map",
        "mapId": "{F154EEC2-FED4-4F98-93D4-093D4A1D0234}",
        "state": "Active",
        "user": "",
        "portsUsed": "1,2"
}
```

7 Impairment Information Command

Retrives information about all impairments in loaded map.

7.1 Parameters

- "mapId" (required) The SNE map name or id of the loaded map.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

7.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments" -H "accept: application/json"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments?userToken={userToken}" -H "accept: application/json"
```

```
{
    "status": {
    "code": 1201,
    "message": "Operation Successful"
    "impairments": [
         "name": "Jitter",
         "impld": "18381B33-9B82-4F6B-9CF8-1428CC371A82",
         "enabled": true,
         "type": "JitterDisruptor"
     },
         "name": "Delay Packet",
         "impId": "B7E15507-76BA-4BCD-ADAB-9F47577E309C",
         "enabled": true.
         "type": "PacketDelayDisruptor"
     },
         "name": "Bandwidth Throttle",
         "impId": "A8B18790-D1D4-43B6-828C-EF88940CCFE2",
         "enabled": true,
         "type": "BandwidthThrottleDisruptor"
   ]
}
```

8 Enable Impairment Command

Updates the enabled status of an impairment.

8.1 Parameters

- "enabled" True or False.
- "mapId"(required) The SNE map name or id to modify.
- "impld" The impairment name or id.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

8.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /enabled?enabled={enabled}"
    -H "accept: application/json"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /enabled?enabled={enabled}&userToken={userToken}"
    -H "accept: application/json"
```

```
{
    "code": 1201,
    "message": "Operation Successful"
}
```

9 Delay Commands

9.1 Retrieve Settings

Retrieves the current settings of the delay impairment.

9.1.1 Parameters

- "mapId"(required) The SNE map name or id to modify.
- "impld" The impairment name or id.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

9.1.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /delay"
    -H "accept: application/json"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /delay&userToken={userToken}"
    -H "accept: application/json"
```

```
{
    "status": {
        "code": 1201,
        "message": "Operation Successful"
},
        "updatePending": false,
    "maxDelayTime": 0,
    "delay": {
        "delayMode": "constDelayMode",
        "enabled": true,
        "maxDataRate": 0,
    "timeConstraints": {
        "enableTimeConstraints": false,
        "startDelay": 1000,
        "duration": 5000
},
    "delayModeSettings":{
        "constDelayMode": {
            "latency": 50,
            "jitterPcnt": 0
},
    "rangeDelayMode": null,
    "gaussianDelayMode": null,
    "rampDelayMode": null,
    "sinDelayMode": null
   }
}
```

9.2 Update Settings

Updates the current settings of the Delay impairment.

9.2.1 Parameters

- "item" Json parameter data.
- "mapId"(required) The SNE map name or id to modify.
- "impld" The impairment name or id.
- "userToken" (optional) Specifies a valid user account name multi-user mode. Not required when multi-user mode is disabled.

9.2.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
/delay"
    -H "accept: application/json"
    -d "{item}"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
/delay&userToken={userToken}"
    -H "accept: application/json"
    -d "{item}"
```

```
{
    "code": 1201,
    "message": "Operation Successful"
}
```

9.2.4 JSON input

```
{
    "delayMode": "constDelayMode",
   "enabled": true,
   "maxDataRate": 1000,
   "timeConstraints": {
       "enableTimeConstraints": false,
       "startDelay": 1000,
       "duration": 5000
   "constDelayMode": {
           "latency": 50,
           "jitterPcnt": 0
       "rangeDelayMode": {
           "minLatency": 50,
           "maxLatency": 100,
           "allowReordering": false
       "gaussianDelayMode": {
           "minLatency": 25,
           "meanLatency": 50,
           "deviation": 10,
           "allowReordering": false
       "startLatency": 50,
           "startPeriod": 250,
           "endLatency": 75,
           "riseTime": 500,
           "allowReordering": false
       "minLatency": 70,
           "maxLatency": 100,
           "sinDuration": 5,
           "allowReordering": false
   }
}
```

Global Parameters

Json Key	Accepted Data	Description
delayMode	constDelayMode rangeDelayMode gaussianDelayMode rampDelayMode sinDelayMode	Sets the type of delay to be updated.
enabled	true false	Sets the enabled status of the impairment.
maxDataRate	100 1000 10000 25000	The predicted line rate going through the impairment
enableTimeConstraintstrue		Sets the enable status of the time
	false	constriants.
startDelay	0.10 to 36000	Sets the start delay time in milliseconds.
duration	0.10 to 36000	Sets the run time in milliseconds.

${\bf constDelayMode}$

Json Key	Accepted Data	Description
latency	Dependson maxData	Sets the latency for the impairment
	Rate	
	0.01 to 10000	For 100 and 1000 Data Rate
	0.01 to 4000	For 10000, 25000 Data Rate
jitterPcnt	0 to 100	Sets the jitter percent on the impairment

${\bf range Delay Mode}$

Json Key	Accepted Data	Description
minLatency	0.01 to < maxLat	Sets the min value of the latency range.
maxLatency	minLat < to 10000	Sets the max value of the latency range.
allowReordering	true	Enables/disables reordering.

${\it gaussian Delay Mode}$

Json Key	Accepted Data	Description
minLatency	0.01 to < maxLat	Sets the minimum delay value.
maxLatency	minLat < to 10000	Sets the max delay value
deviation	0.01 to 10000	Sets the deviation value.
allowReordering	true	Enables/disables reordering.
	false	

rampDelayMode

Json Key	Accepted Data	Description
startLatency	0.01 to 30000.00	Sets the minimum delay value.
startPeriod	0.01 to 10000	Sets the max delay value.
endLatency	0.01 to 10000.00	Sets the deviation value.
riseTime	0.01 to 30000.00	Sets the time period for the delay to rise.
allowReordering	true false	Enables/disables reordering.

sinDelayMode

Json Key	Accepted Data	Description
minLatency	0.01 to < maxLatency	Sets the mini latency of the sin curve.
maxLatency	minLat < to 10000	Sets the max latency of the sin curve
sinDuration	0.01 to 10000	Sets the sinusoidal duration to which to go
		between min/max delay
allowReordering	true	Enables/disables reordering.
	false	

10 Jitter Commands

10.1 Retrieve Settings

Retrieves the current settings of the Jitter impairment.

10.1.1 Parameters

- "mapId"(required) The SNE map name or id to modify.
- "impld" The impairment name or id.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

10.1.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
/jitter"
-H "accept: application/json"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
/jitter&userToken={userToken}"
-H "accept: application/json"
```

```
{
    "status": {
        "code": 1201,
        "message": "Operation Successful"
},
    "jitter": 0,
    "updatePending": false,
    "enabled": true
}
```

10.2 Update Settings

Updates the current settings of the Jitter impairment.

10.2.1 Parameters

- "item" Json parameter data.
- "mapId"(required) The SNE map name or id to modify.
- "impld" The impairment name or id.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

10.2.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
/jitter"
-H "accept: application/json"
-d "{item}"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
/jitter&userToken={userToken}"
-H "accept: application/json"
-d "{item}"
```

10.2.3 Return Value

```
{
    "code": 1201,
    "message": "Operation Successful"
}
```

10.2.4 JSON input

```
{
    "jitter": 10,
    "enabled": true
}
```

Json Key	Accepted Data	Description
jitter	0.01 to 1000.00	Sets the amount of Jitter
enabled	True	Sets the enabled status of the impairment
	false	

11 Packet Drop Commands

11.1 Retrieve Settings

Retrieves the current settings of the Packet Drop impairment.

11.1.1 Parameters

- "mapId"(required) The SNE map name or id to modify.
- "impld" The impairment name or id.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

11.1.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /packetdrop"
    -H "accept: application/json"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /packetdrop&userToken={userToken}"
    -H "accept: application/json"
```

```
{
    "status": {
        "code": 1201,
        "message": "Operation Successful"
    "updatePending": false,
    "packetDrop": \bar{\{}
        "packetDropMode": "standardDropMode",
        "enabled": true,
        "timeConstraints": {
            "enableTimeConstraints": false,
            "startDelay": 1000,
            "duration": 5000
        },
    "packetDropSettings": {
        "standardDropMode": {
            "packetDropCount": 5,
            "perPacketCount": 100,
            "dropMethod": "dropEvenly"
        },
    "percentageDropMode": {
        "percentageDrop": 1
            }
        }
    }
}
```

11.2 Update Settings

Updates the current settings of the Packet Drop impairment.

11.2.1 Parameters

- "item" Json parameter data.
- "mapId"(required) The SNE map name or id to modify.
- "impld" The impairment name or id.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

11.2.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /packetdrop"
    -H "accept: application/json"
    -d "{item}"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
   /packetdrop&userToken={userToken}"
   -H "accept: application/json"
   -d "{item}"
```

```
{
    "code": 1201,
    "message": "Operation Successful"
}
```

11.2.4 JSON input

Global Parameters

Json Key	Accepted Data	Description
packetDropMode	standardDropMode percentageDropMode	Sets the packet drop mode.
enabled	true false	Sets the enabled status of the impairment.

timeConstraints

Json Key	Accepted Data	Description
enableTimeConstraint	strue	Enable/disables time constraints.
	false	
startDelay	0.01 to 360000.00	Sets the start delay.
duration	0.01 to 360000.00	Sets the duration.

standardDropMode

Json Key	Accepted Data	Description
packetDropCount	1 to perPacketCount	Number of packets to drop.
perPacketCount	packetDropCount to 10000000	Packet distance between each drop.
dropMethod	dropEvenly dropBurst	

percentageDropMode

Json Key	Accepted Data	Description
percentageDrop	0 to 100	The percentage of packets to drop.

12 Bandwidth Throttle Commands

12.1 Retrieve Settings

Retrieves the current settings of the Bandwidth Throttle impairment.

12.1.1 Parameters

- "mapId"(required) The SNE map name or id to modify.
- "impld" The impairment name or id.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

12.1.2 Curl Command

Single user mode

curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}/bandwidththrottle"
-H "accept: application/json"

Multi-user mode

curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}/bandwidththrottle&userToken={userToken}"
-H "accept: application/json"

```
{
    "status": {
       "code": 1201,
       "message": "Operation Successful"
    "updatePending": false,
    "bandwidthThrottle": {
        "bandwidthThrottleMode": "constantThrottleMode",
        "enabled": true,
        "timeConstraints": {
            "enableTimeConstraints": false,
            "startDelay": 1000,
            "duration": 5000
        "includeEthernetFraming": false,
        "ethernetFrameSize": 24,
        "fifoSize": 0,
        "bandwidthThrottleSettings": {
            "constantThrottleMode": {
                "bandwidth": 16
                },
            "rangeThrottleMode": {
                 "minBandwidth": 8,
                 "maxBandwidth": 16,
                 "duration": 5000
             }
         }
     }
 }
```

12.2 Update Settings

Updates the current settings of the Bandwidth Throttle impairment.

12.2.1 Parameters

- "item" Json parameter data.
- "mapId"(required) The SNE map name or id to modify.
- "impld" The impairment name or id.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

12.2.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /bandwidththrottle"
    -H "accept: application/json"
    -d "{item}"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
   /bandwidththrottle&userToken={userToken}"
   -H "accept: application/json"
   -d "{item}"
```

```
{
    "code": 1201,
    "message": "Operation Successful"
}
```

12.2.4 JSON input

```
{
    "bandwidthThrottleMode": "constantThrottleMode",
    "enabled": true,
    "timeConstraints": {
        "enableTimeConstraints": false,
        "startDelay": 1000,
        "duration": 5000
    },
    "includeEthernetFraming": false,
    "ethernetFrameSize": 24,
    "fifoSize": 0,
    "bandwidthThrottleSettings": {
        "constantThrottleMode": {
            "bandwidth": 16
        "rangeThrottleMode": {
            "minBandwidth": 8,
            "maxBandwidth": 16,
            "duration": 5000
    }
}
```

Global Parameters

Json Key	Accepted Data	Description
packetDropMode	constantThrottleMode rangeThrottleMode	Sets the throttle mode.
enabled	true false	Sets the enabled status of the impairment.

timeConstraints

Json Key	Accepted Data	Description
enableTimeConstrain	strue	Enable/disables time constraints.
	false	
startDelay	0.01 to 360000.00	Sets the start delay.
duration	0.01 to 360000.00	Sets the duration.

rangeThrottleMode

Json Key	Accepted Data	Description
minBandwidth	500 to 25000 bytes	Minimum allowed bandwidth.
maxBandwidth	minBandwidth to 25000	Maximum allowed bandwidth
duration	Time in milliseconds	Duration of range values.

constantThrottleMode

Json Key	Accepted Data	Description
bandwidth	500 to 25000 bytes	The specified bandwidth limit

13 Packet Duplication Commands

13.1 Retrieve Settings

Retrieves the current settings of the Packet Duplication impairment

13.1.1 Parameters

- "mapId"(required) The SNE map name or id to modify.
- "impld" The impairment name or id.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

13.1.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}/packetduplication"
-H "accept: application/json"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /packetduplication&userToken={userToken}"
    -H "accept: application/json"
```

```
{
    "status": {
        "code": 1201,
        "message": "Operation Successful"
        "updatePending": false,
        "packetDuplication": {
            "packetDuplicationMode": "simpleMode",
            "enabled": true,
            "packetDuplicationSettings": {
    "complexMode": {
        "delay": 10,
        "amount": 10,
        "maxPacketsToStore": 1000
        },
    "timedMode": null
        }
    }
}
```

13.2 Update Settings

Updates the current settings of the Packet Duplication impairment

13.2.1 Parameters

- "item" Json parameter data.
- "mapId"(required) The SNE map name or id to modify.
- "impld" The impairment name or id.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

13.2.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /packetduplication"
    -H "accept: application/json"
    -d "{item}"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
   /packetduplication&userToken={userToken}"
   -H "accept: application/json"
   -d "{item}"
```

```
{
    "code": 1201,
    "message": "Operation Successful"
}
```

13.2.4 JSON input

```
{
    "packetDuplicationMode": "simpleMode",
    "enabled": true,
    "packetDuplicationSettings": {
        "complexMode": {
            "delay": 10,
            "amount": 10,
            "maxPacketsToStore": 1000
        },
        "timedMode": null
    }
}
```

Global Parameters

Json Key	Accepted Data	Description
PacketDuplication Mode	simpleMode timedMode complexMode	Sets duplication mode.
enabled	true false	Sets the enabled status of the impairment.

simpleMode

Json Key	Accepted Data	Description
N/A	N/A	No parameters required.

timedMode

Json Key	Accepted Data	Description
delay	1 to 36000	Numberof millisecondso wait between out-
		putting of duplicate packets
maxPacketsToStore	0 to 15800704	Sets the maximum packets to store.

complexMode

Json Key	Accepted Data	Description
delay	1 to 36000	Numberof millisecondso wait between out putting of duplicate packets
amount	1 to 10	Number of times to duplicate each packet.
maxPacketsToStore	0 to 15800704	Sets the maximum packets to store.

14 Ethernet Fragmentation Commands

14.1 Retrieve Settings

Retrieves the current settings of the Ethernet Fragmentation impairment

14.1.1 Parameters

- "mapId"(required) The SNE map name or id to modify.
- "impld" The impairment name or id.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

14.1.2 Curl Command

Single user mode

```
<url -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}/ethfragmentation"
-H "accept: application/json"</p>
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /ethfragmentation&userToken={userToken}"
    -H "accept: application/json"
```

```
{
    "status": {
        "code": 1201,
        "message": "Operation Successful"
        },
    "mtuSize": 1500,
    "updatePending": false,
    "enabled": true
}
```

14.2 Update Settings

Updates the current settings of the Ethernet Fragmentation impairment

14.2.1 Parameters

- "item" Ison parameter data.
- "mapId"(required) The SNE map name or id to modify.
- "impld" The impairment name or id.
- "userToken" (optional) Specifies a valid user account name for multiuser mode. Not required when multi-user mode is disabled.

14.2.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /ethfragmentation"
    -H "accept: application/json"
    -d "{item}"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /ethfragmentation&userToken={userToken}"
    -H "accept: application/json"
    -d "{item}"
```

14.2.3 Return Value

```
{
    "code": 1201,
    "message": "Operation Successful"
}
```

14.2.4 JSON input

```
{
    "mtuSize": 1500,
    "enabled": true
}
```

Global Parameters

Json Key	Accepted Data	Description
mtuSize	68 to 9000	Sets the maximum MTU value (in bytes).
enabled	true	Sets the enabled status of the impairment
	false	

15 Packet Reorder Commands

15.1 Retrieve Settings

Retrieves the current settings of the Packet Reorder impairment

15.1.1 Parameters

- "mapId"(required) The SNE map name or id to modify.
- "impld" The impairment name or id.
- "userToken" (optional) Specifies a valid user account for multi-user mode. Not required when multi-user mode is disabled.

15.1.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /packetreorder"
    -H "accept: application/json"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /packetreorder&userToken={userToken}"
    -H "accept: application/json"
```

```
{
    "status": {
        "code": 1201,
        "message": "Operation Successful"
        "updatePending": false,
        "packetReorder": {
            "packetReorderMode": "timeReorderMode",
            "enabled": true,
            "packetProbability": 50,
            "packetReorderSettings": {
                "distanceReorderMode": {
                    "minDistance": 1,
                    "maxDistance": 10
                    },
                    "timeReorderMode": {
                        "minDisplacement": 1,
                        "maxDisplacement": 12.75
                        }
                   }
               }
}
```

Updates the current settings of the Packet Reorder impairment.

15.2.1 Parameters

- "item" Ison parameter data.
- "mapId"(required) The SNE map name or id to modify.
- "impld" The impairment name or id.
- "userToken" (optional) Specifies a valid user account for multiuser. Not required when multi-user mode is disabled.

15.2.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /packetreorder"
    -H "accept: application/json"
    -d "{item}"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
   /packetreorder&userToken={userToken}"
   -H "accept: application/json"
   -d "{item}"
```

15.2.3 Return Value

```
{
    "code": 1201,
    "message": "Operation Successful"
}
```

15.2.4 JSON Input

Global Parameters

Json Key	Accepted Data	Description
packetReorderMode	timeReorderMode	Sets packet reorder mode.
	distanceReorderMode	
enabled	true	Sets the enabled status of the impairment
	false	
packetProbability	0 to 100	The perntage of packets to reorder.

timeReorderMode

Json Key	Accepted Data	Description
minDisplacement	0 to < maxDisplace- ment	The minimum delay to displace a packet
maxDisplacementd	MinDisplacement to 500	The maximum delay to displace a packet.

distanceReorderMode

Json Key	Accepted Data	Description
minDisplacement	1 to < maxDisplace- ment	The minimum packetdistanceto displace a packet
maxDisplacementd	minDisplacemne≰ to 10000	The maximum packedistanceto displacea packet.

16 Bit Error Commands

16.1 Retrieve Settings

Retrieves the current settings of the Bit Error impairment

16.1.1 Parameters

- "mapId"(required) The SNE map name or id to modify.
- "impld" The impairment name or id.
- "userToken" (optional) Specifies a valid user account for multiuser mode. Not required when multi-user mode is disabled.

16.1.2 Return Type

16.1.3 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
   /biterror"
   -H "accept: application/json"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
   /biterror&userToken={userToken}"
   -H "accept: application/json"
```

```
{
    "status": {
        "code": 1201,
        "message": "Operation Successful"
        },
    "updatePending": false,
        "bitError": {
            "enabled": true,
            "erroredBits": 1,
            "totalBits": 1000000
        }
}
```

Updates the current settings of the Bit Error impairment

16.2.1 Parameters

- "item" Json parameter data.
- "mapId"(required) The SNE map name or id to modify.
- "impld" The impairment name or id.
- "userToken" (optional) Specifies a valid user account for multiuser mode.. Not required when multi-user mode is disabled.

16.2.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
   /biterror"
   -H "accept: application/json"
   -d "{item}"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
   /biterror&userToken={userToken}"
   -H "accept: application/json"
   -d "{item}"
```

16.2.3 Return Value

```
{
    "code": 1201,
    "message": "Operation Successful"
}
```

16.2.4 JSON Input

```
{
    "enabled": true,
    "erroredBits": 1,
    "totalBits": 1000000
}
```

Global Parameters

Json Key	Accepted Data	Description
enabled	true	Sets the enabled status of the impairment
	false	
erroredBits	1 to 8	Sets the number of bits to corrupt.
totalBits	1 to 100,000,000	Sets the number of bits to miss before
		corrupting

17 Packet Counting Commands

17.1 Retrieve Settings

Retrieves the current settings of the Packet Counting Filter,

17.1.1 Parameters

- "mapId"(required) The SNE map name or id to modify.
- "impld" The impairment name or id.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

17.1.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /packetcounting"
    -H "accept: application/json"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /packetcounting&userToken={userToken}"
    -H "accept: application/json"
```

Updates the current settings of the Packet Counting Filter.

17.2.1 Parameters

- "item" Json parameter data.
- "mapId"(required) The SNE map name or id to modify.
- "impld" The impairment name or id.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

17.2.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /packetcounting"
    -H "accept: application/json"
    -d "{item}"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
   /packetcounting&userToken={userToken}"
   -H "accept: application/json"
   -d "{item}"
```

17.2.3 Return Value

```
{
    "code": 1201,
    "message": "Operation Successful"
}
```

17.2.4 JSON Input

Global Parameters

Json Key	Accepted Data	Description
packetCountingMode	xInYMode	
	percentageCountMod	e
enabled	true	Sets the enabled status of the impairment
	false	

xInYMode

Json Key	Accepted Data	Description
packetFailCount	1 to 1,000,000,000	Set the number of packets to fail(X)
perPacketCount	1 to 1,000,000,000	The number ofpackets to skip untithe next
		failure count(Y)

RESTAPI Manual

${\bf percentage Count Mode}$

Json Key	Accepted Data	Description
percentageFailCount	1 to 100	Sets the percentage of packets to fail.

18 Traffic Generator Commands

18.1 Retrieve Settings

Retrieves the current settings of the Packet Counting Filter,

18.1.1 Parameters

- "mapId"(required) The SNE map name or id to modify.
- "impld" The impairment name or id.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

18.1.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /trafficgen"
    -H "accept: application/json"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /trafficgen&userToken={userToken}"
    -H "accept: application/json"
```

```
{
   "status": {
        "code": 1201,
        "message": "Operation Successful"
   "updatePending": false,
        "trafficGen": {
        "trafficGenMode": "constGenMode",
        "enabled": true,
   "trafficGenSettings": {
        "constGenMode": {
        "dataRate": 64,
        "broadcastTraffic": false
        },
   "rangeGenMode": {
        "minDataRate": 1,
        "maxDataRate": 8,
        "rangeDuration": 5000,
        "broadcastTraffic": false
        },
   "timeConstraints": {
        "enableTimeConstraints": false,
        "startDelay": 1000,
        "duration": 5000
        }
    }
}
```

Updates the current settings of the Traffic Generator.

18.2.1 Parameters

- "item" Json parameter data.
- "mapId"(required) The SNE map name or id to modify.
- "impld" The impairment name or id.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

18.2.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /trafficgen"
    -H "accept: application/json"
    -d "{item}"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/impairments/{impId}
    /trafficgen&userToken={userToken}"
    -H "accept: application/json"
    -d "{item}"
```

```
{
    "code": 1201,
    "message": "Operation Successful"
}
```

18.2.4 JSON Input

```
{
   "trafficGenMode": "constGenMode",
   "enabled": true,
    "trafficGenSettings": {
       "constGenMode":{
           "dataRate": 64,
           "broadcastTraffic": false
       "rangeGenMode": {
           "minDataRate": 1,
           "maxDataRate": 8,
           "rangeDuration": 5000,
           "broadcastTraffic": false
       "enableTimeConstraints": false,
           "startDelay": 1000,
           "duration": 5000
   }
}
```

Global Parameters

Json Key	Accepted Data	Description
trafficgenMode	constGenMode rangeGenMode	
enabled	true false	Sets the enabled status of the impairment

rangeGenMode

Json Key	Accepted Data	Description
minDataRate	1 to maxDataRate	Min amount of background traffic to
		generate in bytes per second.
maxDataRate	minDataRate ¡ to	,
	1,000,000	generate in bytes per second.
rangeDuration	1 to 360000	Delay in milliseconds.
broadcastTraffic	true	Enables/disables broadcast traffic.
	false	

19 Link Commands

19.1 Link Up

Sets the link status to up for a port.

19.1.1 Parameters

- "mapId"(required) The SNE map name or id to modify.
- "port" The physical port number.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

19.1.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}/{port}/linkup"
-H "accept: application/json"
```

Multi-user mode

```
{
    "code": 1201,
    "message": "Operation Successful"
}
```

19.2 Link Down

Sets the link status to Down for a port.

19.2.1 Parameters

- "mapId"(required) The SNE map name or id to modify.
- "port" The physical port number.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

19.2.2 Curl Command

Single user mode

```
curl -X PUT "http://192.168.1.100/api/maps/example_map/1/linkdown" -H "accept: application/json"
```

Multi-user mode

```
curl -X PUT "http://192.168.1.100/api/maps/{mapId}
    /{port}/linkdown?userToken={userToken}"
    -H "accept: application/json"
```

```
{
    "code": 1201,
    "message": "Operation Successful"
}
```

19.3 Link Status/Port

Retrieves the link status of a port.

19.3.1 Parameters

- "mapId"(required) The SNE map name or id to modify.
- "port" The physical port number.
- "userToken" (optional) Specifies a valid user account name for multi-user mode. Not required when multi-user mode is disabled.

19.3.2 Curl Command

Single user mode

```
curl -X GET "http://192.168.1.100/api/maps/{mapId}/{port}"
-H "accept: application/json"
```

Multi-user mode

```
curl -X GET "http://192.168.1.100/api/maps/{mapId}/{port}?userToken={userToken}"
    -H "accept: application/json"
```

```
{
    "status": {
        "code": 1201,
        "message": "Operation Successful"
     },
     "portStatus": "Down"
}
```

20 Capture Replay Commands

20.1 Get Capture replay Files Information

Retrieves information about all loaded capture replay files.

20.1.1 Parameters

• NONE

20.1.2 Curl Command

```
curl -X GET "http://192.168.1.100/api/files/capturereplay" -H "accept: application/json"
```

```
"status": {
    "code": 1201,
    "message": "Operation Successful"
    },
    "availableDiskSpace": null,
    "maxFileSize": null,
    "files": [
        {
             "pcapFile": "CaptureFile",
             "size": 2134512
        },
        {
             "pcapFile": "TrafficCapture.pcap",
             "size": 32145673
        }
        ]
        ]
    }
}
```

20.2 Upload a Capture Replay File

Uploads a capture replay file.

20.2.1 Parameters

• "pcapFile" - The pcap file to be uploaded.

20.2.2 Curl Command

20.3 Get a Capture Replay File

Downloads a capture replay file.

20.3.1 Parameters

• "pcapFile" - The name of the pcap file to be downloaded.

20.3.2 Curl Command

```
curl -X GET "http://192.168.1.100/api/files/capturereplay/{pcapFile}" -H "accept: application/json"
```

20.3.3 Return Value

```
{
    "code": 1201,
    "message": "Operation Successful"
}
```

20.4 Delete a Capture Replay File

Deletes an uploaded capture replay file.

20.4.1 Parameters

• "pcapFile" - The pcap file to be deleted.

20.4.2 Return Value

```
{
    "code": 1201,
    "message": "Operation Successful"
}
```

21 Build Version Commands

Retrieves the system software version information

21.1 Parameters

NONE

21.2 Curl Command

curl -X GET "http://192.168.1.100/api/instrument/software/buildversion" -H "accept: application/json"

21.3 Return Value

Sne build number.