

TamaPoke Mrs. Spock

Game Manual — Mrs. Spock version, firmware 5.91

Raise a Pokémon from an egg: feed it, keep it clean and rested, train it, take it on trips and see what becomes of it. This manual explains how to **operate** the game. What there is to discover along the way is left for you to find out.

Chapter	Contents
1	Getting started
2	Controls at a glance
3	The main screen
4	Caring for your Pokémon
5	Sleep, light and naps
6	The status pages
7	Growing up and evolving
8	Training, ball game and battles
9	Trips and Magic Berries
10	Pokémon Search: two devices meet
11	The Pokédex
12	Medals, banners and the daily streak
13	Saying goodbye
14	Settings: clock, sound, language, name, brightness
15	Quick answers

1 Getting started

What you need

- The device: Waveshare ESP32-S3-Touch-AMOLED-1.75 with the TamaPoke firmware.
- A **microSD card** with the Pokémon images. Copy the *contents* of the supplied folder “SD Karte” into the root of the card (see the flashing guide). Without the images the screen reads “No sprites – Load them onto the SD”.
- A charged battery or a USB cable.

Switching on and choosing a starter

- Press the **PWR** button. On the very first start the screen says “Choose your starter”: tap Bulbasaur, Charmander or Squirtle.
- An **egg** appears. **Keep tapping the egg** until it hatches. The messages “Tap the egg...”, “It moves!” and “Almost there!” show how far along it is. An egg never hatches on its own.

Set the clock first!

Day and night, bedtime, trips and more follow your **local time**, so set the clock before you play:

- Swipe **down** on the main screen. The clock preview appears.
- Hold your finger on the **upper half** for **2 seconds**. The SET TIME screen opens.
- Use the HOUR and MIN buttons (–/+) to set the current time, then tap **OK**. Swiping instead cancels.

Tip: Sound on/off and the language are in this same menu (chapter 14).

2 Controls at a glance

Gestures

Gesture	What it does
Swipe left (main screen)	Opens the Pokédex grid
Swipe right (main screen)	Opens the Pokédex front page (your favorites and rank)
Swipe up	Opens the status pages
Swipe down	Opens the clock preview. Works almost anywhere, even while a question, a banner or a visit is on screen
Tap your Pokémon	Pet it
Hold your Pokémon for 3 seconds, finger still	Starts the “Release?” question
Tap a banner	Dismisses it (after about 2 seconds)
PWR , short press	Screen on / off
PWR , hold about 4 seconds	Switches the device off completely

The four buttons at the bottom

Button	Position	What it does
Food	far left	Opens a short food menu (chapter 4)
Play	left of center	Starts the ball game (chapter 8)
Light	right of center	Lights out, lights on, power nap, or the bedtime question (chapter 5)
Bath	far right	Cleans your Pokémon

Reading the sounds

A **low, short “denied” tone** means: not possible right now. Typical reasons are that your Pokémon is asleep, a question or banner is open, a visit is running, or it is the wrong time of day. Nothing is broken. Fix the reason, or wait, and try again.

3 The main screen

Where	What you see
Top	The name and level (a star in front of the name means a shiny Pokémon). Below it a short message about how your Pokémon feels. Top left a flame with your streak number, top center the battery.
Middle	Your Pokémon in its surroundings, and any droppings it has left.
Lower part	Four bars: FOOD , JOY , ENE (energy) and HYG (hygiene). The emptier a bar, the more urgently your Pokémon needs something.
Bottom	The four buttons: Food, Play, Light, Bath.

Messages you may see: “It’s happy”, “It’s hungry!”, “Needs a bath!”, “Worn out...”, “Feeling sad...”, “A bit chubby...”, “It’s sleeping...” and “It’s SHINY!!”. They tell you what to do next.

4 Caring for your Pokémon

Feeding

- Tap **Food**. For **6 seconds** a menu appears with a **red**, **blue** and **green berry** and a **candy**. Tap one of them.
- Every Pokémon has one **favorite berry color**. The game does not tell you which, and the first page of the status pages shows “BERRY ???” until you have found it. Try them out.
- Candy fills your Pokémon quickly, but it makes it **heavier**. A very round Pokémon (“roly-poly...”) refuses it.

- “Not hungry.” means it is full. “Not yet.” means wait a little before the next berry.
- You cannot feed a sleeping Pokémon.

Bathing and droppings

- During the day your Pokémon leaves droppings. They lower its hygiene until you clean them up.
- Tap **Bath**. The droppings disappear and the hygiene bar fills up. When there is nothing to clean you get “Not yet.”.

Petting

Tap your Pokémon. It enjoys it and a heart appears. After a petting there is a short pause before the next one counts. Sleeping Pokémon and eggs cannot be petted.

Why care matters

- Keep an eye on the four bars morning and evening. If a value is left very low for too long, it counts as a **care miss** (shown on status page 4). Care misses delay evolution and weaken your bond.
- Serious neglect can make your Pokémon run away (chapter 13). Look after it, and you will not see that.

5 Sleep, light and naps

Your Pokémon follows the day. The **Light** button does something different depending on the time:

Time of day	What happens / what to do
about 22:00 – 6:00	Your Pokémon falls asleep by itself . If the light is still on, the message reads “bad dreams...”. Tap Light and it changes to “dreaming...” with the screen dimmed: much better rest.
6:00 – 8:00	Tap Light to wake it (“Lights on”). At 8:00 it wakes up on its own anyway.
8:00 – 20:00	Your Pokémon is awake. Light offers a power nap : a short countdown (“Power nap: ...”) after which it is more rested. It only works when your Pokémon is tired enough and some time has passed since the last nap, otherwise you get “Not yet.”.
20:00 – 22:00	You may put it to bed early: tap Light . The game asks “ Put Pokemon to sleep? ” with “ Yes, lights out! ” and “ No, stay awake! ”. The question closes by itself after 10 seconds ; until then everything else is locked. Once your Pokémon sleeps in the evening you cannot wake it again until the morning.

- While asleep, only the Light button works; food, play and bath are switched off.
- Play, training, battles and trips end at **20:00** (“It’s too late...”).

6 The status pages

Swipe **up** to open them. Swipe **left or right** to flip between the five pages. Close them by swiping up or down, or by tapping outside the buttons. They cannot be opened while a banner, a question, an evolution button or a visit is on screen, nor while you only have an egg.

Page	What it shows	What you can do
1 Profile	Name and level, animated picture, streak (“STREAK n best m”), the BOND bar, favorite berry, age	Tap the name to rename
2 Battle values	ATK, DEF and SPD, and the weight with a word: agile, normal, lazy or fat	Buttons TRAINING and BATTLE
3 Medals	The eight medals; the ones you own are ticked (“MEDALS n/8”)	–
4 Progress	Level, bar to the next level, evolution state (“n levels to go”, “Ready to evolve!”, “Final form”) and “Care Miss”	Green button Ready to evolve! when available
5 Trip	Steps (“Today:”, “Total:”), “Magic Berry:”	Buttons Eat Magic Berry and Go on a trip

Tip: A heavy Pokémon is slower and fights worse. The weight word on page 2 tells you where you stand.

7 Growing up and evolving

- Your Pokémon grows older and gains levels on its own; the level is shown next to the name. Page 4 shows how far it is to the next one.
- When it is ready to evolve, a signal sounds and a **red, pulsing “EVOLVE!” button** appears on the main screen. Tap it. The game asks “Evolve?” – choose **EVOLVE!** or **Keep form**.
- If you pick “Keep form”, the red button does not come back by itself for that form. You can still evolve at any time later with the green **“Ready to evolve!”** button on status page 4.
- A Pokémon that is sad (“Feeling sad...” on page 4) will not evolve. Feed, wash and pet it first.
- While the red button is on screen, the care buttons are locked (denied tone). Only the swipe down to the clock still works.
- Some Pokémon can evolve into different forms. The game decides.
- Medals, bond and trained values stay with your Pokémon through an evolution.

8 Training, ball game and battles

All three work only while your Pokémon is **awake** and **before 20:00**. They tire your Pokémon and make it hungry, but make it happy and stronger.

Training bag

- Swipe up to status page 2 and tap **TRAINING**.
- For **10 seconds** tap the bag as fast as you can (“HIT FAST!”). The result reads “n HITS”. Tapping the top edge cancels.

Ball game

- Tap **Play**. Your Pokémon is the paddle: **drag your finger left and right** to move it. Tap your Pokémon to launch the ball, then catch it again and again.
- The game shows “SCORE: n” and your “BEST: n”. It ends when you miss a ball. Tapping the top edge cancels without reward.

Battle

- On status page 2, tap **BATTLE**. The fight runs by itself; you only watch. The result reads “You won!” or “You lost.”.
- Your opponent is a Pokémon you have **already discovered**. With none yet you see “No opponents. Go on a trip!”.
- Wins and losses are counted and affect how your Pokémon feels.

9 Trips and Magic Berries

Open status page 5 and tap **Go on a trip**. The screen splits in two: tap the **upper half** (“Together with your Pokemon”) to go for a walk with a step counter, or the **lower half** (“Send the Pokemon away on its own”) to send your Pokémon out alone. Trips are possible between **6:00 and 20:00** and only while your Pokémon is awake.

Together: step-counter trip

- Carry the device while you walk. The screen shows the time and your steps. The button **End Trip** ends it: tap it, then tap again within 3 seconds when it says “Really?”.
- After 90 seconds without touching, the screen goes dark, but the device keeps counting and does not shut itself off. Touches are ignored while it is dark; a short press on **PWR** lights the screen again.
- On the way you may meet Pokémon and find Magic Berries. After the trip the game shows each encounter; tap “next” to move on. “NEW” marks a Pokémon you had not met before.

Careful: Never switch the device off completely during a step-counter trip. The trip and its steps would be lost, and the next start warns you with “Do not turn off completely in step counter mode!”. A short PWR press (screen off) is fine.

Alone: Pokémon trip

- Your Pokémon leaves for a while, somewhere around half an hour to an hour. The screen shows the time of day and “Time until return:”. This trip **continues even if the device is switched off**.
- While it is away only the bottom button works: **Call the Pokemon back**. Calling it back early (tap, then tap again at “Really?”) upsets it.
- When the time is up the button reads “Your Pokemon is back”. Tap it and read what happened.
- There is a daily limit; afterwards you see “Tomorrow again...”. If you do not fetch your Pokémon by about 22:00, the trip is cancelled.

Magic Berries

- Status page 5 shows how many you have. The pockets are limited; when full you see “Magic Berry lost. Pockets are full.”.
- Tap **Eat Magic Berry** and choose one of the four fields (Hunger, Joy, Energy or Hygiene). The chosen value is filled up completely. Not possible while your Pokémon sleeps.

10 Pokémon Search: two devices meet

Two TamaPoke devices can meet over Bluetooth. Their Pokémon visit each other for a few minutes.

How to start

- Both devices need a hatched Pokémon (no egg), and it must be between **8:00 and 20:00**. Otherwise you hear the denied tone. Hold the devices close together.
- Open the Pokédex grid (swipe left) and flip to the **last page, page 26**. The pages wrap around, so from page 1 one swipe to the right takes you there. At the bottom of that page is a **radar symbol**.
- **Tap the radar symbol on both devices**, within a few seconds of each other.
- The screen reads “Searching for Pokemon...” for up to 10 seconds. Then you see “Search Successful!”, “Nobody here!” (nothing found: just try again) or “Connection error” (also try again).

The meeting

- The screen shows which Pokémon you met (“NEW” if it was unknown) and a **5-second countdown**. Then the visit begins by itself. You do not need to tap.
- One Pokémon is the host (“It’s playing”), the other is visiting: its Pokémon walks off the screen and the message reads “on the go...”.
- The visit lasts about **three minutes**. During it **all inputs are locked** (denied tone), only the swipe down to the clock works. The care buttons stay visible but do nothing.
- At the end a fanfare plays and the screen lights up if it had gone dark, so you see the Pokémon say goodbye or come home.
- Usually the Pokémon have a good time together. Now and then they quarrel instead (“Confrontation...”). A Magic Berry may also change hands.

Careful: Do not switch the device off during a visit, or its outcome is lost. Start a search with well-filled values.

11 The Pokédex

- **Open** it with a swipe left (grid) or right (front page). The grid opens at the page of your current Pokémon.
- **Grid:** 16 Pokémon per page, 26 pages. Swipe left or right to flip pages (they wrap around). Grey fields are not discovered yet and cannot be tapped. Tap the top or bottom edge to close.

- **Front page:** your three favorites and your rank, which rises as you discover more. Swipe to return to the game.
- **Tap** a discovered Pokémon to see it large, with small medal badges in a circle around it. Tap a badge to see its name.
- Tap the large picture for facts: type, meetings, win rate and how often you have raised it. Tap “tap to go back” at the bottom to return.
- **Favorites:** hold your finger on the large picture for 2 seconds and choose one of the three slots (“Choose slot”). Favorites appear on the front page and can influence which egg you get.
- A Pokémon is discovered when you raise it, meet it on a trip or meet it in a Pokémon Search.

12 Medals, banners and the daily streak

- There are **eight medals** to earn for each Pokémon. Status page 3 lists them. How to earn them is up to you to find out.
- When something special happens, a **banner** appears: “MEDAL!”, “Milestone”, “Streak Record” or “New stage!”. **Tap the banner** to dismiss it (it can be tapped after about 2 seconds). Several banners queue up one after the other.
- While a banner is on the main screen, other actions are locked (denied tone). The swipe down to the clock still works, and the status pages and the Pokédex can be used freely.
- **Daily streak:** look after your Pokémon at least once every day (feeding, playing, training, bathing and petting count, and for an egg, tapping it). The flame at the top left shows your streak.
- The **BOND** bar on status page 1 grows through good care.

13 Saying goodbye

What you see	What to do	What happens
A golden button “... wants to tell you...” (only for a fully evolved, mature Pokémon)	Tap it. The game asks “Say goodbye?”: Goodbye or Stay together .	“Stay together” keeps it; the question comes back later. “Goodbye” ends this Pokémon’s story and a new egg appears.
A dark button “... feels abandoned...”	Tap it to start.	A badly neglected Pokémon leaves you and a new egg appears. This cannot be taken back.
Nothing special: you hold your finger on the Pokémon for 3 seconds , without moving	The game asks “Release ...?” Answer YES or NO within 10 seconds.	You can release only one Pokémon per day (“Already sent one off today. Wait for Tomorrow!”).

While one of these buttons is shown, the care buttons are locked. Only the swipe down to the clock works.

14 Settings: clock, sound, language, name, brightness

Clock preview

- Swipe **down** to see the time and weekday. A swipe in any direction closes it again.
- **Brightness** (battery operation only): in the preview, swipe **left** for brighter, **right** for darker. At the limits, when charging or with the lights out, you hear the denied tone. The setting is kept.
- **Hold 2 seconds on the upper half:** SET TIME. **Hold 2 seconds on the lower half:** set the weekday (arrows, then OK). The weekday advances by itself at midnight.

SET TIME screen

Control	Function
HOUR – / +, MIN – / +	Set the time. The seconds are set to zero when you save
SND ON / SND OFF	Sound on or off
Lang	Language: EN (English text and names), DE (German), EN/DE (English text, German names), DE/EN (German text, English names)
Hold to delete	Erases everything (see below)
OK	Saves (“saved”)
Swipe	“swipe: cancel” – leaves without saving; sound and language changes are undone

Renaming your Pokémon

Open status page 1 and **tap the name** (the hint “tap name: rename” is shown). A keyboard with A–Z appears: “<--” deletes a letter, **OK** saves, and tapping “tap to go back” leaves without saving. A name can be up to 11 characters long.

Erasing everything and starting over

In SET TIME, hold “**Hold to delete**” for 2 seconds. The question “Really delete ALL Data?” appears together with six numbers in a circle. **Tap the numbers in order** (1 to 6 or 6 to 1) within 10 seconds. The game then shows “Data deleted! New game.” and restarts. The SD card is not touched.

Screen and power

- After **90 seconds** without a touch the screen goes dark. Touch it to wake it (that touch does nothing else).
- After **5 minutes** without a touch the device switches itself off (not during a step-counter trip). Press **PWR** to start it again.
- While the device is off, time still passes for your Pokémon. It will be hungrier, older and perhaps asleep when you return.

15 Quick answers

Problem	What to do
“No sprites – Load them onto the SD”	The SD card is missing, or the files are not in the root of the card. Copy the <i>contents</i> of the folder “SD Karte” onto the card, not the folder itself.
The screen is black	It went dark after 90 seconds: touch it. If you pressed PWR, press PWR briefly.
Everything answers with the denied tone	A banner, a question, an evolution button or a visit is open, or your Pokémon is asleep. Finish it or wait. The swipe down to the clock always works.
I cannot feed	Your Pokémon sleeps, it is full (“Not hungry.”), you have to wait a little (“Not yet.”), or it is too round for candy.
It does not wake up	Wake it with Light between 6:00 and 8:00. At 8:00 it wakes up by itself. Is the clock correct?
“Nobody here!” in the Pokémon Search	Both devices must search at the same time, close together, between 8:00 and 20:00. Try again.
Step counter says “Sensor not found”	The motion sensor did not answer. Switch the device off and on again.
The question about saying goodbye never comes	It appears only for a fully evolved, mature Pokémon that is awake. Be patient.