L1: Stress & Strain

Department of Civil Engineering
School of Engineering
Aalto University

Class Rules and Today's Schedule

Class rules

- No recording
- Feel free to turn on or turn off your camera and microphone
- Welcome to join or interrupt a conversation

Today's schedule

- Introduction to this course
- Stress & Strain

Weiwei Lin Dr. Associate Professor (responsible teacher)

Aalto University, School of Engineering, Department of Civil Engineering

Visiting address: Room 247, Rakentajanaukio 4 A, 02150 Espoo, Finland

E-mail: weiwei.lin@aalto.fi

Note: whenever you want a discussion (either online or f2f), feel free to make

a appointment through email.

Rui Hao Doctoral student (Teaching Assistant, Teacher for exercise)

E-mail: rui.hao@aalto.fi

Yifu Lan Doctoral student (Teaching Assistant)

E-mail: <u>yifu.lan@aalto.fi</u>

Note: All materials in this handout are used in class for educational purposes only.

Big Picture

| ▼ First year | | | | |
|---|--|-------------------|-------------------------------------|---|
| 1st AUTUMN | 1st SPRING | | | |
| Differential and integral calculus 1 | First course in probability and statistics | | | |
| Matrix algebra | Differential and integral calculus 2 | | | |
| Programming 1 | Differential and integral calculus 3 | | ▼ Second year | |
| Statics and dynamics | Programming 2 | | 2nd AUTUMN | 2nd SPRING |
| Introduction course for BSc students | Numerical methods in engineering | | Data structures and algorithms | Foundations of Continuum Mechanics |
| Introd. to Industrial Engineering and Management | University Wide Studies* | | Foundations of Solid Mechanics | Thermodynamics and Heat Transfer |
| Compulsory language course | 2nd national lang/Finnish for Foreigners |) '- - | Basic Course on Fluid Mechanics | Finite Element and Finite Difference Methods |
| | | | Materials Science and Engineering | Major optional course |
| ▼ Third year | | | Computer-aided tools in engineering | Elective/ Minor course |
| 3rd AUTUMN | 3rd SPRING | | | |
| Computational Engineering project | BSc thesis and seminar | | Major optional course | Elective/ Minor course |
| | | | Elective/ Minor course | |
| Elective/ Minor course | Elective/ Minor course | | | |
| Elective/ Minor course | Elective/ Minor course | | | |
| Elective/ Minor course | Elective/ Minor course | | | |
| Elective/ Minor course | | | | |

Syllabus

Week 44 2.11 Stress and Strain 3.11 Exercise 1 4.11 Axial load 5.11 Exercise 2 Week 45 9.11 Torsion 10.11 Exercise 3 Mid-term report questions available 11.11 Bending 12.11 Exercise 4 Week 46 16.11 Shear and combined loading 17.11 Exercise 5 18.11 Geometric Section Properties 19.11 Exercise 6

Week 47

- 23.11 Analysis and Design of Beams
- 24.11 Exercise 7 Mid-term report deadline
- 25.11 Plane-Stress Transformation & Mohr's Circle
- 26.11 Exercise 8

Week 48

- 30.11 Deflection of Beams
 - 1.11 Exercise 9
 - 2.11 Statically Indeterminate Beams
 - 3.11 Exercise 10

Week 49

- 7.12 Buckling
- **8.12 Exercise 11**
- 9.12 Summary and discussions
- 10.12 Q & A

Syllabus

◆ Assessment: homework (weekly assignment), mid-term report, and final exam.

Weekly assignment: 25%; Mid-term report: 25%; Final exam: 50%;

Bonus points: (5%) for attendance (both lectures and exercises, you will lose one point for each absence). Minimum point is 0.

Final grade=weekly assignment (25%) + mid-term report (25%) + final exam (50%) + bonus point (5%)

- **♦ Final exam: 16.12.21 Thursday 17.30-20.30**
- Reference books:
 - 1. Gross et al: Engineering Mechanics 2
 - 2. R. C. Hibbeler: Mechanics of Materials
 - 3. Ferdinand P. Beer et al. Mechanics of Materials

Main Principles of Statics

- External Loads: a body is subjected to only two types of external loads, namely, surface forces or body forces, as shown in Fig.1.
 - Surface force: caused by the direct contact of one body with the surface of another;
 - *Body force*: developed when one body exerts a force on another body without direct physical contact between them.





Fig.1 Forces or loads on a body

Main Principles of Statics

> Support reactions: the surface force that develop at the supports or points of contact between bodies.



Equations of Equilibrium

Equilibrium of a body requires a *balance of forces*, to prevent the body from translating or having accelerated motion along a straight or curved path, and a *balance of moments*, to present the body from rotating. These conditions can be expressed mathematically by two vector equations

$$\sum F = 0 \qquad \sum M_0 = 0$$

 \triangleright If an x, y, z coordinate system is established:

$$\sum F_{x} = 0 \qquad \sum F_{y} = 0 \qquad \sum F_{z} = 0$$

$$\sum M_{x} = 0 \qquad \sum M_{y} = 0 \qquad \sum M_{z} = 0$$

➤ Often in the engineering practice, the loading on a body can be represented as a system of coplanar. If this is the case, and the force lie in x-y plane, then the conditions of equilibrium can be specified as:


$$\sum F_x = 0 \quad \sum F_y = 0 \quad \sum M_0 = 0$$

Successful application of the equations of equilibrium requires complete specification of all the known and unknown forces that act on the body, and so the best way to account for all these forces is to draw the body that's *free-body diagram*.

Internal Resultant Loadings


- ➤ Normal force, N. This force acts perpendicular to the area. It is developed whenever the external loads tend to push or pull on the two segments of a body.
- ➤ Shear force, V. The shear force lies in the plane of the area and it is developed when the external loads tend to cause the two segments of the body to slide over one another.
- ➤ Torsional moment or torque, T. This effects is developed when the external loads tend to twist one segment of the body with respect to the other about an axis perpendicular to the area.
- ➤ **Bending moment, M**. The bending moment is caused by the external loads that tend to bend the body about an axis lying within the plane of the area.

Review of Statics




- The structure is designed to support a 30 kN load
- The structure consists of a boom and rod joined by pins (zero moment connections) at the junctions and supports
- ➤ Perform a static analysis to determine the internal force in each structural member

Method of Joints



- The truss member are 2-force members, i.e., the members are subjected to only two forces which are applied at member ends
- For equilibrium, the forces must be parallel to to an axis between the force application points, equal in magnitude, and in opposite directions
- Joints must satisfy the conditions for static equilibrium which may be expressed in the form of a force triangle:




•
$$\sum F_B = 0$$
 $\frac{F_{AB}}{4} = \frac{F_{BC}}{5} = \frac{30kN}{3}$

$$F_{AB} = 40 \text{ kN}$$
 $F_{BC} = 50 \text{ kN}$

Stresses in the Members of a Structure

While the results obtained in the preceding section represents a first and necessary step in the analysis, they do not tell us whether the given load can be *safely supported*. The answer depends not only on the intensity of the internal force but also on the cross-sectional area of the member and the properties of the material of which it is made.



The internal force F_{BC} actually represents the resultant of elementary forces distributed over the entire area A of the cross-section.

The force per unit area, or intensity of the forces distributed over a given section, is called the stress at a point and is denoted by the Greek letter σ .

$$\sigma_{ave} = \frac{P}{A} = \frac{F_{BC}}{A}$$

Stress and Strain

Stress: force of resistance per unit area offered by a body against deformation

$$\sigma = \frac{F}{A} \tag{1.1}$$

F = External force or load A = Cross-sectional area


Strain: change in dimension of an object under application of external force

$$\varepsilon = \frac{dL}{L} = \frac{L' - L}{L} \tag{1.2}$$

dL= change in length L= Length

Modulus of elasticity or Young's modulus:


$$E = \frac{\sigma}{\varepsilon}$$
 (1.3)



Stress and Strain

Normal Stress: The intensity of the force acting normal to $\triangle A$ is defined as the normal stress, σ . Since $\triangle F$ is normal to the area, then,

$$\sigma_{z} = \lim_{\Delta A \to 0} \frac{\Delta F_{z}}{\Delta A} \tag{1.4}$$



Shear Stress: The intensity of the force acting tangent to $\triangle A$ is called the shear stress, τ . Here we have shear stress components,

$$\sigma_{ZX} = \lim_{\Delta A \to 0} \frac{\Delta F_{\chi}}{\Delta A} \tag{1.5}$$

$$\sigma_{zy} = \lim_{\Delta A \to 0} \frac{\Delta F_y}{\Delta A} \tag{1.6}$$

Unit of Stress and Strain

With P expressed in *newtons* (N) and A in square meters (m²), the stress will be expresses in N/ m². This unit is called *pascal* (Pa).


As pascal is an exceedingly small quantity, in practice, multiples of this unit must be used.


1 kPa =
$$10^3$$
 Pa = 10^3 N/ m²
1 MPa = 10^6 Pa = 10^6 N/ m² = 1 N/mm²
1 GPa = 10^9 Pa = 10^9 N/ m²

How about the unit of strain?

Dimensionless

Average Stress





Why to Study Stress


• Analysis: to calculate the stress in the structural members and check whether it is less than the allowable stress of the construction materials

$$\sigma = \frac{P}{A} \qquad \qquad \sigma < \sigma_{all}$$


• Design: according to the stress condition, determine the construction material, the section shape and size of the structural members

$$\sigma_{all} > \frac{P}{A}$$
 $A > \frac{P}{\sigma_{all}}$

Stress Analysis



$$d_{BC} = 20 \text{ mm}$$



Can the rod BC safely support the 30 kN load? $\sigma_{all} = 180 \text{ MPa}$

From a statics analysis

$$F_{AB} = 40 \text{ kN (compression)}$$

$$F_{BC} = 50 \text{ kN (tension)}$$

• At any section through member BC, the internal force is 50 kN with a force intensity or stress of


$$\sigma_{BC} = \frac{P}{A} = \frac{50 \times 10^3 N}{314 \times 10^{-6} m^2} = 159 \text{MPa}$$

• From the material properties for steel, the allowable stress is

$$\sigma_{all} = 180 \text{ MPa}$$

• Conclusion: the strength of member BC is adequate

Design




The circular rod BC is made of aluminium with an allowable stress $\sigma_{all} = 100MPa$. Determine its diameter so that it can safely transmit the force $F_{BC} = 50kN$.

$$\sigma_{all} = \frac{P}{A}$$

$$A = \frac{P}{\sigma_{all}} = \frac{50 \times 10^3 N}{100 \times 10^6 Pa} = 500 \times 10^{-6} mm^2$$

and, since $A = \pi r^2$




$$r = \sqrt{\frac{A}{\pi}} = \sqrt{\frac{500 \times 10^{-6} mm^2}{\pi}} = 12.6 mm$$

$$d_{bc} = 2r = 25.2mm$$

Exercise-1

Determine the average normal stress developed at points A, B, and C. The diameter of each segment is indicated in the figure.



$$A_A = A_C = \frac{\pi d^2}{4} = \frac{3.1415926 \times 0.5^2 \times 10^{-5}}{4} = 1.96 \times 10^{-5} m^2$$

$$A_B = \frac{\pi d^2}{4} = \frac{3.1415926 \times 1.0^2 \times 10^{-5}}{4} = 7.854 \times 10^{-5} m^2$$

$$N_A = 3kN N_B = -6kN N_C = 2kN$$

$$\sigma_A = \frac{N_A}{A_A} = \frac{3000N}{1.96 \times 10^{-5} m^2} = 152.79MPa$$

$$\sigma_B = \frac{N_B}{A_B} = \frac{-6000N}{7.865 \times 10^{-5} m^2} = -76.4MPa$$

$$\sigma_C = \frac{N_C}{A_C} = \frac{2000N}{1.96 \times 10^{-5} m^2} = 101.86MPa$$