Programming Parallel Computers


Chapter 1 Chapter 2 Chapter 3 Chapter 4 Links | About | Index Intro Lectures

Chapter 1: Role of parallelism

How?

Why do we need parallelism?

In 1965, Gordon E. Moore had a data set with five data points: how many components there were in state-of-theart integrated circuits in 1959, 1962, 1963, 1964, and 1965. Here is a visualization of the data from his 1965 paper, "Cramming more components onto integrated circuits", Electronics Magazine (reprinted in Proc. IEEE, vol. 86, issue 1, 1998):



exponentially.

While the original rate of the transistor count doubling every year has slowed down somewhat, it is amazing to see that the exponential growth still continues today — we have seen more than 50 years of exponential growth in the packing density of microprocessors:

Year	Transistors	CPU model
1975	3 000	6502
1979	30 000	8088
1985	300 000	386
1989	1 000 000	486
1995	6 000 000	Pentium Pro
2000	40 000 000	Pentium 4
2005	100 000 000	2-core Pentium D
2008	700 000 000	8-core Nehalem
2014	6 000 000 000	18-core Haswell
2017	20 000 000 000	32-core AMD Epyc
2019	40 000 000 000	64-core AMD Rome
	1975 1979 1985 1989 1995 2000 2005 2008 2014 2017	1975 3 000 1979 30 000 1985 300 000 1989 1 000 000 1995 6 000 000 2000 40 000 000 2005 100 000 000 2008 700 000 000 2014 6 000 000 000 2017 20 000 000 000

But what about performance?

However, the end user of a computer does not really care that much about the number of transistors; what matters is the performance.

Until around 2000, we used to see the performance of CPUs rapidly increasing, primarily for two reasons. First, the **clock speed** of the CPU (the number of clock cycles per second) increased:



instruction that multiplies two 80-bit floating point numbers on Intel CPUs. The total latency of the instruction (roughly speaking, the time it takes to launch multiplication to the time when the result is available) has dropped significantly over the years:

Second, CPUs were using fewer and fewer clock cycles per operation. As a simple example, consider the FMUL

Year	Clock cycles	CPU model
1980	100	8087
1987	50	387
1993	3	Pentium

in the performance. In just a couple of decades, the time it took to complete a floating point multiplication decreased several orders of magnitude, from tens of microseconds to tens of nanoseconds.

The joint effect of increasing clock speeds and decreasing instruction latencies implied massive improvements

After 2000 Around year 2000, everything changed. Moore's law was still doing fine, and the number of transistors kept

increasing. However, clock speeds stopped improving. The clock speed of a modern computer is almost always somewhere in the ballpark of 2–3 GHz:

Year	Transistors	Clock speed	CPU model
1975	3 000	1 000 000	6502
1979	30 000	5 000 000	8088
1985	300 000	20 000 000	386
1989	1 000 000	20 000 000	486
1995	6 000 000	200 000 000	Pentium Pro
2000	40 000 000	2 000 000 000	Pentium 4
2005	100 000 000	3 000 000 000	2-core Pentium D
2008	700 000 000	3 000 000 000	8-core Nehalem
2014	6 000 000 000	2 000 000 000	18-core Haswell
2017	20 000 000 000	3 000 000 000	32-core AMD Epyc
2019	40 000 000 000	3 000 000 000	64-core AMD Rome
Instruc	tion latencies have	not improved mud	ch, either; sometimes tl

Year Clock cycles CPU model

we saw twenty years ago. Here are examples of the latency of the FMUL operation:

1987	50	387	
1993	3	Pentium	
2018	5	Coffee Lake	
0:			
Since 2000, the number of transistors in			

8087

1980

instruction. A single floating point multiplication took roughly 2 nanoseconds in 2000, and it still takes roughly 2 nanoseconds today. So what is happening? And why are the CPU manufacturers packing more and more transistors in the CPUs if it does not seem to help with the performance?

magnitude, but this is not visible in the performance if we look at the time it takes to complete a single

To understand what is happening, we will need to define two terms. • Latency: time to perform an operation from start to finish.

instruction latency.

Time Start

New kind of performance

• Throughput: how many operations are completed per time unit, in the long run.

Example: a massively parallel university

The latency of completing a Master's degree at Aalto University is roughly 2 years. However, the throughput of Aalto is nowadays 1960 degrees/year. If Aalto educated students in a strictly sequential manner, keeping only 1 student at a time in the

"pipeline", we would have a throughput of only approx. 0.5 degrees/year.

this makes it possible to obtain a throughput that is much higher than 1/latency.

Finish

Modern CPUs do exactly the same thing as our university: they are able to keep several instructions in execution simultaneously, and hence they can obtain a much higher throughput than what one would expect based on the

However, Aalto is massively parallel; we have thousands of students in the pipeline simultaneously, and

It is hard to design CPUs that have multiplication units with a very small latency. However, throughput is — at least in principle – relatively easy to improve: just add more parallel multiplication units that can be used simultaneously. Another technique that is heavily used in modern processors is pipelining: Arithmetic units can be seen as a long pipeline. At each clock cycle, we can push one new operation into the pipeline. It takes a while for each individual operation to finish, but in the steady state if we initiate one operation per clock cycle, we will also finish one operation per clock cycle:

In progress operation A operation B operation C B, A operation D C, B, A operation E D, C, B, A operation F E, D, C, B Α operation G F, E, D, C operation H G, F, E, D H, G, F, E operation I D

operation J I, H, G, F operation K J, I, H, G operation L K, J, I, H G

This is a dramatic improvement in comparison with the CPUs from the 1990s, in which the throughput of floating point multiplications was typically in the ballpark of 0.5 operations per clock cycle.

In summary, the performance of modern CPUs is steadily increasing, but it is new kind of performance: the

Thanks to pipelining, each arithmetic unit typically has a throughput of 1 operation per clock cycle, and modern

CPUs have a large number of parallel arithmetic units. For example, in a typical modern CPU there are 16 parallel

units for single-precision floating point multiplications per core. Hence, a modern 4-core CPU can do floating

point multiplications at a throughput of 64 operations per clock cycle, or roughly 200 billion operations per

second (recall that the clock speed is typically around 3 GHz, i.e., 3 billion clock cycles per second).

kind of performance, we will need new kind of software that explicitly takes into account the difference between throughput and latency. With old code, a computer from 2021 is not any faster than a computer from 2000. In this course we will learn how to write new code that is designed with modern computers in mind.

latency of individual operations is not improving at all, only throughput is improving. And to benefit from the new

How?