PINOUT FOR CSM LAYOUT

Say X[7:0] is the multiplier and Y[7:0] is the multiplicand, follow the below convention for bringing out pins to the periphery to make the IP accessible to external connection.

