# Developing Zynq Software with Xilinx SDK

# Lab 5 Connecting SDK to Hardware



August 2016 Version 09



## Lab 5 Overview

At last we will now be able to power up the Zynq hardware. Using the example application projects and the SDK, we will connect to the hardware through a JTAG connection. The bitstream will be programmed into the PL, the ARM processor configured, and the code bootloaded to the appropriate memory. SDK can be used to simply run the application or use a full-featured application debugger to step through the code.

# **Lab 5 Objectives**

When you have completed Lab 5, you will know how to:

- Set up the hardware for operation
- Program a bitstream to the PL
- Configure the ARM PS over JTAG using TCL
- Run an application
- Debug an application



## **Experiment 1: Setup Hardware and Download Bitstream**

Xilinx Zynq SoCs are SRAM-based devices, meaning they are volatile. The PL is volatile and the ARM registers are also volatile. In production, the PL hardware definition (or bitstream) and the ARM PS configuration code (or First-Stage Boot Loader FSBL) are stored in Flash on the board, such as a Quad-SPI Flash or SD Card.

Before storing a hardware/software design to Flash, developers will want to experiment with the code – both PL hardware code as well as software application code. In this experiment, we will focus on software application code experimentation directly from SDK. Making use of a JTAG connection to the hardware, SDK will be able to perform all the functions that would normally be performed from Flash.

The SDK-SoC JTAG interface may be used to accomplish all these things:

- Read and write ARM registers
- Configure the PL with a bitstream
- Program attached QSPI Flash
- Upload application code to on-chip RAM or DDR3
- Application debug



### **Experiment 1 General Instruction:**

Setup the hardware and connect all cables. Determine the COM Port assignment on your PC. Configure the SoC PL with a bitstream.

### **Experiment 1 Step-by-Step Instructions:**

- 1. < ZedBoard & PicoZed Only> Connect the power cable to the ZedBoard or to PicoZed FMC Carrier Card V2, but leave it OFF for now.
- 2. Connect the JTAG as follows:
  - a. ZedBoard Connect a 2<sup>nd</sup> micro-USB cable between the host machine and connector J17 (JTAG)
  - b. MicroZed -- Connect a Platform Cable or Digilent Programming cable from the host machine to the 2x7 JTAG socket on MicroZed, J3.
  - c. PicoZed -- Connect the PicoZed Som to the FMC Carrier Card V2. Connect a Xilinx JTAG Programming cable between host computer and J7

MicroZed

- 3. Set the Boot Mode jumpers to Cascaded JTAG Mode
  - a. ZedBoard and MicroZed

ZedBoard




Figure 1 – Mode Pin Jumpers

b. PicoZed




Figure 1 – PicoZed SW1 Set to JTAG Boot 7010/20 on the Left; 7015/30 on the Right



- 4. Connect a micro-USB cable between the Windows Host machine and the USB-UART:
  - a. ZedBoard connector J14 (UART)
  - b. MicroZed connector J2. Since MicroZed gets power from the USB-UART, you should see the Green Power Good LED (D5) and the Red User LED (D3) light.
  - c. PicoZed FMC Carrier Card V2 microUSB port J1.
- 5. < ZedBoard & PicoZed Only> Slide the ZedBoard or PicoZed power switch to ON. You should see the Green Led turn on.

If this is the first time you've connected your board to this computer, you may see Windows install device drivers for the USB-UART and/or the JTAG cable.

You should have previously installed the USB-UART driver (Cypress USB-UART for ZedBoard; Silicon Labs CP2104 for MicroZed & PicoZed). The Platform Cable and Digilent HS3/HS2/HS1 USB-JTAG drivers were installed during the Xilinx tool installation.



Figure 2 – ZedBoard Powered with micro-USB Cables Connected to JTAG and UART





Figure 3 – MicroZed Powered and Connected to Digilent HS2 (shown with flex adapter) and USB-UART micro-USB cable




Figure 5 – PicoZed Powered and Connected to Digilent HS3 and USB-UART micro-USB cable

6. Use Device Manager to determine the COM port for the USB-UART. In Windows 7, click **Start** → **Control Panel**, and then click **Device Manager**. Click **Yes** to confirm.



7. Expand *Ports*. Note the COM port number for the Cypress Serial device.




Figure 6 - Cypress Serial device on ZedBoard



Figure 7 – SiLabs Serial Device on MicroZed/PicoZed

- 8. In SDK, select **Xilinx Tools** → **Program FPGA** or click the discon.
- 9. SDK will already know the correct .bit file (and .bmm if your future hardware platform includes that) since this was imported with the hardware platform. Click Program. When the DONE LED lights blue (LD12 on ZedBoard; D2 on MicroZed, D3 on PicoZed), the PL has configured successfully. Look for the message "FPGA configured successfully with bitstream" in the Console window.




Figure 8 - Program FPGA



## **Questions:**

Answer the following questions:				
• For what can the JTAG interface be used?				
1				
2				
3				
4				
<ul> <li>Under what conditions must the hardware platform first be downloaded into the PL?</li> </ul>				

## **Experiment 2: Running an Application**

SDK is now ready to run or debug an application. In this experiment, the previous Hello World and Memory Tests will be run.

## **Experiment 2 General Instruction:**

Run the Hello\_Zynq and Test\_Memory applications on the hardware, viewing the results on the stdout Terminal. Run the edited Test Memory to see the expanded test window.

## **Experiment 2 Step-by-Step Instructions:**

Since we previously setup the hardware and configured the hardware platform to FPGA, the blue DONE LED should be lit, and the hardware should be ready to accept an application to run.

1. Right-click on the Hello\_Zynq application and select Run As → Run Configurations...



2. Select Xilinx C/C++ Application (System Debugger) and then click the 'New' icon You may also simply double click Xilinx C/C++ Application (System Debugger).




Figure 9 – Create a New Xilinx C/C++ Application Run Configuration

SDK creates the new Run Configuration and automatically assigns a name to the configuration <application\_name> <active\_configuration>, which in this case is Hello\_Zynq Debug.




Figure 10 – New Run Configuration

Recall that the example code copied over for the Hello\_Zynq application was quite simple. Other than the UART statements, there wasn't much else. There was nothing in



Hello\_Zynq to set up the ARM registers for the designed clocking, peripherals, and I/O connections. If the Hello\_Zynq application doesn't configure the ARM processing system, then how will it get done?

3. Note that by default, the ps7\_init.tcl will be sourced prior to running your application. That is how the ARM gets initialized for proper operation. Recall that this ps7\_init.tcl was one of the outputs reviewed in Lab 1.



Figure 41 – ps7\_init.tcl Script to Source

4. Open Terminal, such as **Tera Term**, and set the **COM port** to active COM setting for your board and set the **Baud Rate at 115,200** 




Figure 5 - STDIO Connection

5. Return back to SDK and Click Run.



You can monitor the progress of the download in the lower right-hand corner.




Figure 63 - Download Progress

SDK will download the Hello\_Zynq ELF to the on-chip RAM (because this is what we set in the linker script in Lab 4) and begin executing the code. You can see the output in Tera Term.




Figure 74 – Hello World

6. Repeat steps 1 through 4 for application Test\_Memory, including setting up a new Run Configuration, confirming the Device Initialization, and setting up the Tera Term Connection. This test completes very quickly as it only tests the first 4 KB in



the three tested memory spaces. Click **Yes** to the Conflict, abort existing launch configuration screen.




Figure 85 – Memory Tests Complete

7. Repeat the run again using the previously edited application Test\_Memory\_FullDDR to see if you successfully edited the Memory Test code to test 1MB of DDR3. Click **Yes** to the Conflict, abort existing launch configuration screen.




Figure 96 - 1MB of DDR3 Tested

The same test runs as before. However, this time it takes slightly longer since a larger space is being tested.



# 8. **Close** Tera Term

# Questions:

Answer the following questions:			
•	How does the ARM get initialized when running an application from SDK over the JTAG connection?		
•	How much memory is tested by default?		



## **Experiment 3: Debug an Application**

Debugging applications is a very important part of the software development process. During this experiment, we will exercise the debugger with the Peripheral Test application.

Xilinx utilizes the SDK System Debugger, based on the Target Communications Framework (TCF). According to Xilinx, System Debugger delivers true multi-processor SoC design and debug. For example, in a Zynq-based design, System Debugger can display both ARM CPUs and multiple PL soft-processors, in the same debug session, through a single JTAG cable for an unprecedented level of insight between the hardened processing system and any additional processing that you've added to the programmable logic.

- Based on the Target Communication Framework (TCF)
- Homogenous and heterogeneous multi-processor support
- Linux application debug on the target
- Hierarchical Profiling
- Bare-metal and Linux development
- Supporting both SMP and AMP designs
- Associate hardware and software breakpoints per core
- NEON™ library support

The traditional XMD/GDB Debugger continues to work with Zynq applications as well.



### **Experiment 3 General Instruction:**

Launch the Peripheral Test application in the Debugger. Step through a few lines of code. Set breakpoints. Observe memory.

#### **Experiment 3 Step-by-Step Instructions:**

Right-click on the Test\_Peripherals application and choose Debug As to view the options. Notice that we have two Launch on Hardware options – GDB and System Debugger. Don't select either of these now. Rather select Debug Configurations...




Figure 107 – Debug As Option

2. Notice that the Configurations menu remembers the previous Run Configurations from the previous experiments. Select **Xilinx C/C++ application (System Debugger)** then click the new icon.




Figure 118 – Create New System Debugger Configuration

3. If you hadn't previously programmed the PL, you could check the **Reset entire system** and **Program FPGA** checkboxes. However, we have already programmed the PL so we will leave these unchecked.






Figure 129 - Target Setup

- 4. Feel free to explore the other tabs, but we will not make any other changes. Click **Debug**.
- 5. The code will be downloaded to the target memory, which in this case is DDR3. However, the application will not be run. Instead, the SDK's windows will be reconfigured to show you what is known as the "debugging perspective." Click **Yes** to confirm the perspective switch.




Figure 20 – Confirm Perspective Switch






Figure 131 – Debugging Perspective

It is important to note that the Zynq processor is now in a halted state; therefore the application is not being executed. In the code editing window, you will now see a green bar, which shows the line of code which will be executed next.

```
Xil_ICacheEnable();

Xil_DCacheEnable();

print("---Entering main---\n\r");

88

60 {
```

Figure 142- Debug Waiting for User Input

6. At the bottom of the SDK screen, select the *SDK Terminal* tab. Click the green "Connect to serial port" icon . Change the *Settings* for 115200 baud, 8 data bits, 1 stop bit, no parity and no flow control. Choose the COM port identified previously. Click **OK**.






Figure 153 – Terminal Settings

7. In the header of the Debug pane at the top of the screen, you should see a number of icons. We shall use the "Step Over" icon to advance the application by one line of code. Click this icon three times and observe the effect on the code editing window and the UART Terminal.



As you can see, the processor has executed the first three lines of code. The green bar indicates the next line of code waiting to be executed. The line of printed text should have appeared in the UART terminal window. If it does not make sure you closed **Tera Term** before you connected to SDK Terminal



Figure 164 – First Line of Text in UART



Each time the green bar is shown in the code window, the Zynq processor has advanced but then stopped executing again. Next, we'll set a breakpoint. For ease of explanation, it would be useful to have the editor show line numbers.

8. If line numbers are not already shown, select **Window** → **Preferences**. Within the *Preferences* dialog, browse to **General** → **Editors** → **Text Editors**. Click the checkbox for **Show line numbers**. Click **OK**.




Figure 175 – Show Line Numbers in the Text Editor



9. Browse to Line 141 in testperiph.c, where the code is beginning the QSPI test. Set a breakpoint on Line 141 by double-clicking in the blue column to the left of the line number. A small "circle with a checkmark" should appear next to the line.

```
137
   138
   139
             int Status;
             print("\r\n Running QspiSelfTestExample() for ps7_qspi_0...\r\n");
   141
             Status = QspiPsSelfTestExample(XPAR_PS7_QSPI_0_DEVICE_ID);
   144
   145
             if (Status == 0) {
   146
                print("QspiPsSelfTestExample PASSED\r\n");
   147
   148
             else {
Double-click here print("QspiPsSelfTestExample FAILED\r\n");
   150
          }
   151
```

Figure 186 – Setting a Breakpoint

10. In the upper right hand area of the perspective, select the *Breakpoints* tab. This area allows you to disable or delete breakpoints. Breakpoints can also be deleted by double-clicking again to the left of the line number.




Figure 197 – Breakpoints

11. Click the "Resume" icon which is depicted by the Green arrow.





12. A few tests have now passed, as indicated by the results in the *SDK Terminal* window. The next sequence of code will test the QSPI. Click the Resume icon again.

Since this application is not in a loop, the application has finished. The complete results from the Peripheral Test application are shown below.




Figure 208 - Complete Peripheral Test



13. Under the *Debug* tab in the upper left-hand corner, right-click on **Test\_Peripherals Debug (Local)** and select **Relaunch**. Click **OK**.




Figure 219 - Relaunch Test\_Peripherals Debug

- 14. Use the *Breakpoints* tab to disable the breakpoint at Line 141. Simply uncheck the box.
- 15. This time, click Resume, wait a few moments, and then click the Suspend icon, which is the yellow "pause" icon.



16. If you end up suspended inside one of the other functions, the SDK debugger will open the function with the green bar showing exactly where you are paused. Click the Step Return icon to get back to the testperiph.c. Depending on where you suspended execution, you may have to click the Step Return several times. Click Resume to continue the test.




17. Click the Disconnect icon to end the debugging session.





18. Finally, in the top-right corner of the screen, click the "C/C++" icon to return the SDK to the code editing perspective. Alternatively, to close the Debug perspective, right-click on Debug and select **Close**.



# **Exploring Further**

If you have more time and would like to investigate further...

- Debug the Test\_Memory application. Make use of the following debugger features from the Window → Show View menu.
  - Memory
  - Variables
  - Registers
- The first Test\_Memory application targets the application code at RAM\_0. Then, the application also runs a destructive memory test on RAM\_0. How is that possible? Can you prove it?

This concludes Lab 5.



# **Revision History**

Date	Version	Revision
12 Nov 13	01	Initial release
23 Nov 13	02	Revisions after pilot
01 May 14	03	ZedBoard.org Training Course Release
30 Oct 14	04	Revised for Vivado 2014.3
31 Dec 14	05	Revised for Vivado 2014.4
09 Mar 15	06	Merge MicroZed and ZedBoard instructions
18 Mar 15	07	Finalize SDK 2014.4
Oct 15	08	Updated to SDK 2015.2
August 16	09	Updated to SDK 2016.2

## Resources

www.microzed.org

www.picozed.org

www.zedboard.org

www.xilinx.com/zynq

www.xilinx.com/sdk

www.xilinx.com/vivado

www.xilinx.com/support/documentation/sw manuals/ug949-vivado-designmethodology.pdf

www.xilinx.com/support/documentation/sw manuals/ug1046-ultrafast-design-methodology-guide.pdf



## **Answers**

## **Experiment 1**

- For what can the JTAG interface be used?
  - 1. Read and write ARM registers
  - 2. Configure the PL with a bitstream
  - 3. Program attached QSPI Flash
  - 4. Upload application code to on-chip RAM or DDR3
  - 5. Application debug
- Under what conditions must the hardware platform first be downloaded into the PL?

If the application only uses the Zynq PS, then programming the PL is not necessary. If the application makes use of something in the PL, then the PL must be programmed first. Unlike an off-the-shelf microprocessor with all built-in peripherals, the Zynq SoC starts out with the PL as a blank hardware device. The hardware identity, or bitstream, must be first downloaded to the PL. Any PL peripherals or co-processors don't exist in the PL until after the hardware platform bitstream is configured to the PL.

## **Experiment 2**

- How does the ARM get initialized when running an application from SDK?
- ps7 init.tcl that was provided with the hardware platform
- How much memory is tested by default?
- 4 KB



# **Troubleshooting**

Any Windows Security Alerts will cause issues. Click Allow Access, reboot, then retry. Hopefully this will not affect anyone since we are covering this in Lab 0.



Figure 22 – Windows Security Alert

