210 mm

148 mm

User Manual



Shaken Massager
SK-M3

Distributed by
OLYLIFE INTERNATIONAL PTE. LTD.
Add: 1 Jalan Kilang Timor, #01-02 Pacific Tech Centre, Singapore 159303
Phone: +65 3129 0528

Thank you for choosing this product.

Please read this manual carefully before using the product. Keep this for future reference.

As part of our continuous product innovation and improvement, the contents of this manual may be updated without prior notice.
All illustrations in this manual are based on the standard model and are for reference only. The actual appearance may vary depending on the product you have purchased.
Some specifications may change due to product enhancements. Updated specifications do not apply retroactively. Please refer to the nameplate on the product for the most accurate parameters.

Table of Contents

Important Notes -- 1–2
Product Components/ Product Specifications -- 3
Instructions for Main Unit Operation -- 3
Troubleshooting/ Watch Operation Guide -- 4
Extension Strap Size Guide -- 5
How to Attach Extension Strap -- 5
Storage and Maintenance -- 5
Product and Component Recycling Instructions -- 6
Battery Removal Diagram -- 6
Product Warranty Card -- 7
Certificate of Conformity -- 7

Important Notes

Description of Symbols

To avoid personal injury or property damage, please observe the following instructions.
The following section explains essential safety instructions and their corresponding symbols for your easy understanding and proper use.

⊘ Do not perform these actions ❗ Follow these actions as instructed

❗ Use With Caution

If you are currently undergoing medical treatment or have any of the following conditions, please consult your physician or physical therapist before using this product.

- Individuals with severe peripheral nerve disorders caused by diabetes
- Individuals with skin injuries or wounds
- Individuals who frequently experience numbness in their hands or feet
- Individuals with respiratory difficulties
- Individuals with acute internal organ conditions such as gastritis, hepatitis, or gastroenteritis
- Individuals with vascular disorders
- Individuals using medical rehabilitation devices
- Individuals with impaired heat sensitivity should only use this product under a doctor's supervision, as the surface of the device may become warm during use

Warnings

1. This product is intended for health and relaxation purposes only. It is not a medical device and must not be used as a substitute for medical treatment.
2. The product features a heating function. Adjust the temperature carefully to a comfortable level to avoid burns.
3. Do not use continuously for more than 30 minutes, as prolonged use may cause low-temperature burns.
4. Do not use on the same area more than twice per day. Allow at least 4 hours between sessions.

⊘ Do Not Use Under the Following Conditions

Individuals who have been advised by a doctor to refrain from physical activity or stretching should not use this product.
Conditions such as thrombosis, severe aneurysm, acute varicose veins, skin inflammation, or infection may worsen with use. Do not use this product in such cases.

- Individuals with implanted medical devices such as pacemakers or artificial hearts, those with swelling, inflammation, or bruising on the head, or those who have undergone brain surgery.
- Individuals with heart disease, severe thrombosis, or cerebral hemorrhage should not use this product unless advised by a physician.
- Individuals who have suffered a stroke, or who have high or low blood pressure, are under medical treatment, or are in poor physical condition.
- Individuals with bleeding tendencies or blood disorders, osteoporosis, soft tissue conditions, malignant tumors, heart disease, or acute illnesses.
- As well as pregnant women, postpartum women, or women during special physiological periods.
- Individuals with limited mobility, physical or mental disabilities, or intellectual impairments.
- Individuals unable to care for themselves, including infants and young children.
- Not recommended for use by children.
- This device should not be used by individuals (including children) with reduced physical, sensory, or cognitive abilities, or by those lacking adequate knowledge of proper use.
- Individuals with a body temperature above 37°C.
- Individuals who are highly sensitive to heat or whose body surface temperature easily rises should not use the heating function.
- Do not use this product if you have inflammation, open wounds, or skin burns.
- If you experience back pain, dizziness, nausea, palpitations, or any abnormal physical discomfort during use, stop immediately.

Do Not Use in the Following Situations.

- When feeling physically fatigued.
- Within 40 minutes before or after eating.
- After consuming alcohol.

Usage Precautions

⊘ Do not use the product if it is damaged.
❗ If you feel any discomfort during use, stop immediately.
❗ Ensure the power cord and plug remain dry and keep them away from heat sources.
❗ If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or any qualified professional to avoid hazards.
⊘ Do not operate the control panel or plug or unplug the power cord with wet hands. Avoid splashing water on the control buttons to prevent malfunction.
⊘ Keep the product out of reach of children. Do not allow children to play with or use the product.
⊘ Do not use this product when intoxicated or feeling unwell.
⊘ Do not drop or insert any objects into the product.
⊘ Do not clean the product with gasoline, thinner, or similar solvents. Do not spray insecticides on it.
⊘ Do not immerse or wash the strap assembly, extension strap A, or extension strap B in water.
⊘ This product is designed for individual use only.
❗ If the power cord becomes damaged, stop using the product immediately.
⊘ Do not damage, excessively bend, pull, twist, or knot the power cord.
⊘ Do not attempt to disassemble, repair, or modify this product yourself. Doing so may cause a malfunction or an electric shock.
❗ If the product malfunctions or operates abnormally during use, stop using it immediately.
⊘ Use only with the rated voltage. Do not operate the product if the casing is cracked or damaged.
⊘ Do not leave the product operating unattended while it is connected to power.
❗ If you have any health concerns, use this product only under a doctor's guidance. If you experience or notice any physical abnormalities during use, stop immediately and consult a physician.
❗ After charging, unplug the power cord from the outlet and store it properly.
⊘ Do not smoke while using the product.
⊘ Do not use the product on swollen, bruised, or inflamed skin.
⊘ Do not use the product if it has been exposed to moisture or immersed in liquid.
❗ After each use, allow the product to rest for 30 minutes to extend its lifespan.

Product Components



Packing List	
Shaken Massager	1PC
OLY-Watch	1PC
USB Type-C Charging Cable	1 PC
Extension Strap A	1 PC
Extension Strap B	1 PC
Arm Sleeve	2 PCS

Product Specifications

Product Name	Shaken Massager
Model Number	SK-M3
Rated Input Voltage	Standard Charge: 5V⎓ Fast Charge: 9V⎓
Rated Input Power	Standard Charge: 10W Fast Charge: 26W
Rated output power	25W
Battery Capacity	3000mAh
Duration (Single Session)	20 min

Instructions for Main Unit Operation

1. Press and hold the Power button [⏻] for 2 seconds to turn on the device. Bluetooth will automatically be activated. When powered on for the first time, the default mode is Body Sculpting Mode.
2. While the device is on, press and hold the Power button [⏻] for 2 seconds to turn it off.
3. Short-press the Power button [⏻] to switch between combined intensity levels. The available combinations include Heat + Radio Frequency (RF) + Vibration (three adjustable levels). The device has a memory function.
A. Level 1: Heat 38 ± 3°C, RF: Low, Vibration: Low
B. Level 2: Heat 40 ± 3°C, RF: Medium, Vibration: Medium
C. Level 3: Heat 42 ± 3°C, RF: High, Vibration: High
4. Short-press the [M] button to change massage modes. The three modes (Body Sculpting, Massage, and Heat Therapy) cycle in sequence. When powered on for the first time, the default mode is Body Sculpting Mode.
The device has a memory function and will automatically resume the mode used before it was last turned off.
A. Body Sculpting Mode: PEMF, red light, heat therapy, RF, ultrasound, air compression massage, and vibration.
B. Massage Mode: PEMF, RF, heat therapy, air compression massage, and vibration.
C. Heat Therapy Mode: PEMF and heat therapy.
5. Press and hold the [M] button for 5 seconds to enter the Language Selection interface. The display screen will show 8 available languages. Short-press the [M] button to scroll through options, then short-press the Power button [⏻] to confirm your selection.
6. While the device is charging, press and hold the Power button [⏻] for about 10 seconds to restore factory settings.During this process, if you short-press either the Power or Mode button within 5 seconds, the reset operation will be canceled.

Bluetooth Pairing between Watch and Main Unit:
1. Ensure the main unit is turned on, then press and hold the watch's Power button to turn it on and select your preferred language.
2. The watch will automatically enter Bluetooth search mode. Locate the device named "Shaken Massager" and connect.
3. Once connected, swipe up or down to browse through the available modes. Tap the screen to enter and switch between modes.
4. From the mode page, tap to adjust intensity levels. If no action is performed within 5 seconds, the screen will automatically return to the mode page.

Troubleshooting

No.	Issue	Possible Cause	Solution
1	Unable to turn on device	Device is charging	Use after charging is complete
		Power is not turned on	Turn on the power
		Low battery	Charge fully before using
2	Device stops working during use	Default operating time has ended	Wait 30 minutes before restarting
		Device shuts down due to low battery	Charge fully before using
3	Weak massage intensity	Low battery	Charge promptly
4	Unable to charge	Faulty charging cable or adapter	Try a different compatible cable or charger
		Charging port is dirty or connection is loose	Gently clean the port with a cotton swab, reconnect, and ensure it is secure

Watch Operation Guide

I. Ensure the main unit is turned on, then press and hold the watch's Power button to power it on.



1.Screen will display the logo
2. Select your preferred language

II. The watch will automatically enter Bluetooth search mode.



1. Bluetooth will search for nearby devices
2. Select the device named "Shaken Massager" to connect
3.Connected successfully

III. Once the device is connected, swipe up or down to cycle through available modes. Tap to enter and switch to the desired mode.



1. Body Sculpting Mode
2. Massage Mode
3. Heat Therapy Mode
4.AI Mode Note: AI mode will only activate when the watch is properly worn on the wrist.

IV. From the mode page, tap to adjust intensity levels. If there is no action for 5 seconds, the screen returns to the mode page automatically.



Body Sculpting Level 1
Body Sculpting Level 2
Body Sculpting Level 3

*Note: The Massage Mode and Heat Therapy Mode operate in the same way.
Settings adjust automatically in the AI Mode through intelligent control.

V. Low battery alerts will appear as pop-up notifications on the watch screen.



Low battery (≤20%)
Critically low battery (≤10%)
Battery depleted (≤0%)

VI. Watch charging interface display.



Charging
Fully charged

Extension Strap Sizing Guide

This product includes extension straps of different lengths to suit various waist sizes.
Please select the appropriate strap combination based on your waist circumference:



Recommended Usage:
Waist Circumference 60–85 cm: Use Extension Strap A.
Waist Circumference 80–125 cm: Use Extension Strap B.
Waist Circumference above 125 cm: Combine Extension Strap A + B (suitable for 90–150 cm).
For waist sizes between 80–125 cm, using both straps together is not recommended, as threading both through the buckle may be difficult and affect ease of wear.
Combination feasibility note: Although it may be a bit difficult to put on, the (A+B) combination can be used if needed — for example, if your waist measures 80–90 cm but you prefer a looser fit, or if it's between 125–150 cm. Please take your time when attaching it.

Extension Strap Reference Table		
Combination Type	Strap Length	Applicable Waist Range
Single Strap A	300mm	60cm - 85cm
Single Stap B	700mm	80cm - 125cm
Combination (A+B)	300 + 700mm	90cm - 150cm

How to Attach the Extension Strap

Both extension straps can be worn using the following two methods:

Method 1:



1. Adjust the device position over the sculpting area.
2. Wrap the extension strap around your back.
3. Thread the strap through the buckle and adjust the tightness according to your body shape.
4.Secure the strap firmly using the hook-and-loop fastener.

Method 2:



1. Adjust the device position over the sculpting area.
2. Wrap the extension strap around your back.
3. Attach the strap directly to the hook fastener and adjust for comfort.
4. Ensure the strap is firmly secured in place.

Caution: Remove clothing from the sculpting area before use. Ensure the device is in direct contact with the skin.

Storage and Maintenance

Please store this product in a cool, well-ventilated place out of children's reach. Please keep it away from moisture, high temperatures, direct sunlight, and water splashes.
Charge the product promptly after each use. If the device will not be used for an extended period, turn off the power and charge it once every three months.
Washing Instructions for the Fabric Cover:
It is recommended that you hand-wash the fabric cover. Use a mild detergent, preferably one designed for intimates or sportswear, and avoid detergents containing bleach, fluorescent agents, or other harsh chemicals. Keep the water temperature below 30°C and do not use hot water to prevent fabric aging or deformation. *Note: If machine washing is necessary, place the cover in a laundry bag to prevent it from being pulled or caught by other garments or the drum of the washing machine.
Cleaning Instructions for the Extension Strap:
For regular maintenance, wipe the surface with a soft cloth and a neutral cleaner. Do not use corrosive cleaning agents, and do not immerse or rinse the strap in water.

Product and Component Recycling Instructions

To protect the environment, you are responsible for keeping the device separate from household waste when this product or its components reach end-of-life. Please take them to a qualified recycling facility, where they can be properly dismantled and processed for material recovery and reuse in accordance with local regulations.

Name and Content of Hazardous Substances or Elements in the Product

Component Name	Hazardous Substances or Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated Biphenyls(PBBs)	Polybrominated Diphenyl Ethers (PBDEs)
Electric Components	×	○	○	○	○	○
Metal Components	○	○	○	○	○	○
Plastic Components	○	○	○	○	○	○
Packaging Materials	○	○	○	○	○	○

This table is prepared in accordance with the requirements of SJ/T 11364.
O: Indicates that the content of the hazardous substance in all homogeneous materials of the component is below the limit set by GB/T 26572-2011.
X: Indicates that the content of the hazardous substance in at least one of the homogeneous materials of the component exceeds the limit set by GB/T 26572-2011.
The environmentally safe service life of this product is 10 years. This duration is determined based on the product's design characteristics and is valid only when the product is used under the normal conditions described in this manual.

Please support the recycling of rechargeable (lithium-ion) batteries when disposing of this product.

Warnings
This symbol indicates that this product should not be disposed of with regular household waste. This applies throughout the European Union. To prevent environmental damage or health hazards caused by improper waste disposal, this product must be taken to a designated recycling center where it can be processed responsibly. For product recycling, please bring it to your local collection point or contact your retailer. They will ensure the product is handled in an environmentally responsible manner.

Battery Removal Diagram

Reminders:
When discarding the product, the battery must be removed.
Ensure the product is powered off before removing the battery.
Dispose of the battery safely after removal.

1. Use a prying tool to carefully open the left and right outer shells.



2. Remove the screws securing the left and right middle shells before detaching the shells.



3. Disconnect the battery connector and remove the battery.
Wrap the battery terminals securely with insulating tape.



Product Warranty Card

Warranty Policy:
1. Under normal use, the product is covered by a one-year warranty from the date of purchase.
2. If a fault occurs under normal use during the warranty period and free repair is required, please bring this warranty card and the purchase invoice to an authorized service center.
3. The following situations are not eligible for free warranty service, but paid repair may be provided:
A. Damage caused by improper use, maintenance, or storage.
B. Damage caused by unauthorized disassembly or repair by non-authorized personnel.
C. Absence of a valid warranty card or purchase invoice.
D. Mismatch or alteration between the warranty card number and the product model.
E. Damage caused by force majeure (such as natural disasters).
4. Lost warranty cards will not be reissued. Please keep this card safe.
5. In addition to the warranty terms stated above, customers holding a valid warranty card are also entitled to other rights provided under applicable national laws and regulations during the warranty period.
6. Please retain this warranty card carefully. If lost, warranty service cannot be provided.

Product Name	
Place of Origin	
Warranty Period	
Invoice Number	
Date of Purchase	

Service Records

Date of Delivery	
Date Checked	
Fault / Repair / Handling Details	
Repair Facility	
Technician Signature	

Product Certificate of Conformity

Certificate of Conformity

Product Name: Shaken Massager
Product Model: SK-M3
Manufacture Date:
Inspector:

Notice
Please follow the safety precautions and usage instructions in this manual strictly. Failure to do so may void the product warranty and release the company from quality responsibility.

使用说明书



Shaken Massager
SK-M3

Distributed by
OLYLIFE INTERNATIONAL PTE. LTD.

使用說明書



Shaken Massager
SK-M3

Distributed by
OLYLIFE INTERNATIONAL PTE. LTD.
Add: 1 Jalan Kilang Timor, #01-02 Pacific Tech Centre, Singapore 159303
Phone: +65 3129 0528

取扱説明書



Shaken Massager
SK-M3

販売元：OLYLIFE INTERNATIONAL PTE. LTD.
所在地：1 Jalan Kilang Timor, #01-02 Pacific Tech Centre, Singapore 159303
電話：+65-3129-0528

사용설명서



Shaken Massager
SK-M3

Distributed by
OLYLIFE INTERNATIONAL PTE. LTD.
Add: 1 Jalan Kilang Timor, #01-02 Pacific Tech Centre, Singapore 159303
Phone: +65 3129 0528

Notice d’ utilisation



Shaken Massager
SK-M3

Distribué par :
OLYLIFE INTERNATIONAL PTE. LTD.
Addresse : 1 Jalan Kilang Timor, #01-02 Pacific Tech Centre, Singapour 159303
Tél :+65 3129 0528

คู่มือการใช้งาน



Shaken Massager
SK-M3

จัดจำหน่าย โดย
บริษัท โอลีไลฟ อินเตอร์เนชันแนล จำกัด
ที่อยู่ : 1 ยาลัน กิลัง ติมอร์, #01-02, อาคารแปซิฟิค เทค เซ็นเตอร์, สิงคโปร์ 159303
โทรศัพท์ : +65 3129 0528

Panduan Pengguna



Shaken Massager
SK-M3

Didistribusikan oleh
OLYLIFE INTERNATIONAL PTE. LTD.
Alamat: 1 Jalan Kilang Timor, #01-02 Pacific Tech Centre, Singapura 159303
Telepon: +65 3129 0528

封底