



acontis technologies GmbH

EC-Master

EtherCAT Master Stack

Feature Pack Real Time Accelerator for Windows

Edition: 2023-10-17

EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

© Copyright acontis technologies GmbH

Neither this document nor excerpts therefrom may be reproduced, transmitted, or conveyed to third parties by any means whatever without the express permission of the publisher. At the time of publication, the functions described in this document and those implemented in the corresponding hardware and/or software were carefully verified; nonetheless, for technical reasons, it cannot be guaranteed that no discrepancies exist. This document will be regularly examined so that corrections can be made in subsequent editions. Note: Although a product may include undocumented features, such features are not considered to be part of the product, and their functionality is therefore not subject to any form of support or guarantee.

Content

1	Introduction	4
1.1	Install.....	4

1 Introduction

1.1 Install

- Install the RealtimeAcceleratorSetup-x86_64Bit.msi from the Bin folder.
- Start the RtaccWinConfig and reserve the CPU you are going to start the Demo on.
- Start the EcMasterDemoRtacc.exe and use as affinity parameter (-a) the CPU you reserved.