
HBC-2 IDE
Instruction Manual



Summary

I. Generalities

II. Instruction format and addressing modes

III. Random Access Memory

IV. I/O interface

V. Hardware interrupts

VI. Software interrupts

VII. Instruction set

Generalities

The HomeBrew Computer 2 (or HBC-2) is a home made 8 bit CPU designed to understand the basics of computer science via a simplified central processing unit.

Specifications

Data bus width	8 bits
Address bus width	16 bits
RAM maximum capacity	64 kB
Clock frequency	2 Mhz
Instruction size	1 – 4 bytes
Instruction set size	54
Architecture	Von Neumann / RISC
Stack	16-bit stack pointer (STK) Grows downward - STK = 0xFE00 at reset *(no under/overflow flag)*
I/O	256 Using a hardware mailbox ESP32 used to handle peripherals

An IDE (Integrated Development Environment) is available to program this CPU in a custom assembly language, and emulate the computer's behavior.

This software allows for a deep insight of the internal mechanisms of the computer. Various windows offer a view of the RAM in real-time, of the CPU registers, and many other elements.

The goal of this manual is to provide detailed explanation about the computer's systems, the IDE and the assembly language that has been developed.

Instruction format

and addressing modes

Instructions



Instructions are 8-32 bits (or 1-4 bytes) long, divided in up to 4 sections :

1. A 6 bits operand (64 instructions maximum, 54 implemented),
2. A 4 bits addressing mode (16 addressing modes maximum, 9 implemented),
3. Two 3 bits register selectors (8 registers, A, B, C, D, I, J, X, Y),
4. Two 8 bits user-defined values.

The CPU first fetches **one** byte, giving it the operand.
→ Some instruction use no addressing mode, thus using only 1 byte.

If necessary to check for the addressing mode, the CPU fetches a **second** byte.
→ Some instruction use only 2 selected registers, which are available in the second byte. Thus taking no more space.

The addressing mode may require **1 or 2** additional bytes.

Bad opcode and bad addressing modes

If the CPU finds an **invalid opcode**:
→ It treats it as the **nop** instruction, and skips no further bytes.

If the CPU finds a **valid opcode** with **invalid addressing mode**:
→ It clear the interrupt flag and halts (**hlt**), thus freezing the computer until reset.

Addressing modes (A.M.)

Many instructions can work in multiple addressing modes. Those modes allow to use pointers, mandatory for a Turing-complete machine.

The instruction set described at the end of this manual gives information about which addressing modes you can use for each instruction.

None	0x0
Reg	0x1
Reg / Imm8	0x2
Reg / Ram	0x3
RamReg / ImmReg / Offset	0x4
Stack / Offset	0x5
Reg16	0x6
Imm16	0x7
Imm8	0x8

None

No data is specified, the operand is sufficient.



Reg

Two 8-bit values retrieved from registers 1 and 2.



Reg / Imm8

One 8-bit value retrieved from register 1 and one user-defined 8-bit value.



Reg / Ram

One user-defined 16-bit value and one 8-bit value retrieved from register 1.



RamReg / ImmReg / Offset

Register 1 and 2 are concatenated as a 16-bit address to retrieve one 8-bit value from memory.

Register 1 is the most significant byte (**MSB**).

V2 is a user-defined 8-bit value that is added to the address as an offset.

The 8-bit value in register 3 is used directly.



Stack / Offset

One 8-bit value read from memory at the stack pointer plus an offset (V1).

Register 1 holds the data.



Reg16

Register 1 and 2 are concatenated in a 16-bit value used directly.

Register 1 is the most significant byte (MSB).



Imm16

One user-defined 16-bit value.



Imm8

One user-defined 8-bit value.



Random Access Memory (RAM)

The microprocessor uses two buses to access data from external devices, one for **data**, and one for the **address**. Those buses are used both to access RAM and I/O devices.

Data bus width	8 bits
Address bus width (RAM)	16 bits *(64 kB)*

Memory map

Address	Content
0x0000	Start of the program: the CPU starts here after power-on
0x0000 – 0xFDFF	Program and data, from 0x0000 up Stack, from 0xFDFF down (STK = 0xFE00 at reset)
0xFE00 – 0xFFFF	Interrupt vector table (512 bytes, see Hardware interrupts)

At power-on, the **boot ROMs** (two AT28C256 of 32 kB) copy **64 kB** into the RAM, which takes 65,548 clock cycles (about 33 ms at 2 MHz). Then the CPU starts at **0x0000**. Programming the computer means writing the program's RAM image into these two ROMs.

Control lines


RAM	RW *(Read / Write)* + RE *(Ram Enable)*
I/O access	RW *(Read / Write)* + IE *(I/O Enable)*

To access data from **RAM**, the CPU sets the R/W pin accordingly, and sets the **RE** pin to **HIGH**.
To access data from **I/O**, the CPU sets the R/W pin accordingly, and sets the **IE** pin to **HIGH**.

When the RE pin is set to HIGH, the IE pin is always set to LOW, and vice versa.

I/O interface

The CPU does not talk to the devices directly. Its **IN** and **OUT** instructions reach the **I/O mailbox card**, a card of 12 TTL chips. Behind it, an **I/O processor (ESP32)** runs the devices: it gives them their ports and queues their interrupts.



The I/O mailbox card and the I/O processor (HBC-2_Input_Output.pdf)

Ports

Address bus width (I/O)	8 bits *(256 ports)*

This means that when accessing **I/O ports**, the CPU only uses the **8 least significant bits** of the address bus. Whatever is on the 8 other bits is left unused. The port number is read by the mailbox, which is triggered by the IE pin (I/O Enable).

The card decodes only 0x00–0x3F: with A1 = 0, A2–A5 are ignored, so ports 0 and 1 repeat (0x04/0x05, 0x08/0x09 … 0x3C/0x3D); 0x40–0xFF are empty.

Port	IN	OUT
0x00	RX: next byte from the I/O processor	TX: one byte to the I/O processor
0x01	STATUS: bit 0 RX_AVAIL, bit 1 TX_FREE, bit 2 EVT_PEND, bits 3-7 = 0	N/A

The mailbox card

The card holds **one byte in each direction** and **one pending event**:

Part	Chips	Role
TX	74HCT165	Loaded by OUT on port 0x00; the ESP32 reads it
RX	74AHCT595	Written by the ESP32; IN on port 0x00 reads it
EVT	2 × 74AHCT595	An event: its port on A0–A7 and its data on D0–D7, during the vector step
STATUS	74HCT244	RX_AVAIL, TX_FREE, EVT_PEND on the data bus
Decoding	74HCT138, 74HCT32	Selects TX, RX or STATUS from IE, RW, A0, A1, A6, A7
Flags	4 × 74HCT74	tx_full, rx_full, evt_pend; INT for the CPU
Levels	74LVC244	5 V to 3.3 V towards the ESP32
Pull-downs	10 kΩ network	Hold A8–A15 at 0 during the vector step

The ESP32 reads TX and writes RX and EVT through a **serial link** (SCK, MOSI, MISO, MBX_SEL, RCLK_RX, RCLK_EVT), and reads the card's flags. It waits at least **1 µs** after the RX or EVT flag went back to 0 before writing that register again.

The I/O processor (ESP32)

The ESP32 keeps **256 device ports** (8-bit latches) and gives each device a block of consecutive ports, from port 1 up. **Port 0 is never given to a device**: a port variable at 0 means "no such device". It keeps a **queue of 256 events** and hands them to the mailbox one at a time. Its devices are the screen (the **native display**, and the old monitor ports on the same picture), the PS/2 keyboard, the clock and the EEPROM (an SD card later). There is no mouse and no audio.

Device	Class	Product ID	Ports
Monitor (old ports)	03 00 (display, VGA)	0x0001	5
Real-time clock	08 03 (system, RTC)	0x0002	7
Keyboard	09 00 (input, keyboard)	0x0003	2
EEPROM	01 80 (storage, other)	0x0004	5
Native display	03 80 (display, other)	0x0006	1

Protocol

The CPU sends **commands** of one or more bytes. To send a byte, it reads STATUS until **TX_FREE** = 1, then writes the byte to port 0x00. To receive a byte, it reads STATUS until **RX_AVAIL** = 1, then reads port 0x00. Replies come in order; events come on EVT and never mix with replies.

Bytes sent	Command	Reply on RX
0x00	NOP	none
0x01 p v	OUT: device port p = v	none
0x02 p	IN: read device port p	1 byte: the value of port p
0x03	INFO: the devices	protocol version, N, then N × 6 bytes
0x10 – 0x7F	Native commands of the screen	only the commands that read

Any other command byte is ignored, as a NOP. An IN after an OUT always sees its result.

Commands 0x10 to 0x7F are the **native commands** of the screen: text, graphics, the VSYNC tick (60 Hz) and the time. The ESP32 does the drawing, so one character costs 2 bytes and clearing the screen 2 bytes, instead of 5 OUT commands per character through the old monitor ports. They are described in the **HBC-2 Monitor Instruction Manual**.

Each command is sent with **interrupts disabled** (CLI), so that an interrupt handler cannot slip its own bytes into it. The library routines **mbx_out** and **mbx_in** do this. The library keeps interrupts

disabled for **one command at a time**, never for a whole call: the longest stretch is one PUTS of 255 characters, 6.7 ms. Meanwhile keys wait in the ESP32's queue; nothing is lost.

INFO replies with the protocol version (2: the native commands), the number of devices N, then one 6-byte descriptor per device, in port order: the **class** (2 bytes: PCI base class and subclass), the **product ID** (2 bytes, high byte first), the **first port** and the **number of ports**. Programs find a device by its class, never by a fixed port number.

Start-up and reset

1. At power-on, the program sends **INFO** and waits for the reply. The ESP32 takes about 1 s to boot; meanwhile the command just waits in TX.
2. The program waits **2 s at most** for each byte. Without an answer, it sees no devices.
3. The **reset button** resets the CPU and the mailbox card only. The ESP32 keeps running and keeps the devices, their ports and the event queue; it drops a command it was halfway through receiving. The program starts again, sends INFO and gets the answer at once.

In assembly, **dev_init** and **dev_find** (devices.has) do this; in C, the start-up code does it before main and sets display_port, monitor_port, keyboard_port, rtc_port and eeprom_port (0 when the device is missing).

The complete description is in HBC-2_Input_Output.md, in the Documentation folder.

Hardware interrupts

To handle interrupts, the microprocessor implements two control lines, **INT** (pending interrupt) and **INR** (interrupt ready), that can be triggered by the CPU and the mailbox.

CPU side

The CPU is not necessarily ready to handle interrupts. An **interrupt flag** is implemented in the flag register. When this flag is **set**, the CPU is capable of handling interrupts. Two instructions control this behaviour : **STI** (Set Interrupt flag), and **CLI** (Clear Interrupt flag).

When the CPU has received an interrupt, and is ready to manage it, it retrieves the I/O port number via the mailbox, and then jumps to a memory location defined by the programmer in the **interrupt vector table (IVT)**.

The interrupt vector table is a **512 bytes** memory block in the RAM, located from address **0xFE00** to address **0xFFFF**. Those address holds pointers that the CPU uses to set the **PC** (Program Counter register). As a reminder, RAM addresses are 2 bytes long, and there are 256 I/O ports that are numbered from 0x00 to 0xFF.

I/O port number	Address in the IVT
0x00 *(reserved: unused)*	0xFE00 << 0xFE01
0x01	0xFE02 << 0xFE03
[...]	*[...]*
0xFE	0xFFFC << 0xFFFD
0xFF	0xFFFE << 0xFFFF

Procedure:

1. The **ESP32** loads an event (port and data) into the mailbox. **EVT_PEND** is set, and the mailbox raises **INT**, synchronised to the clock.
2. If the interrupt flag is set to **HIGH**, the CPU finishes the current instruction and sets the **INR** control line to **HIGH** for one clock cycle,
3. During the vector step, the mailbox drives the port on **A0–A7** and the data on the data bus. **A8–A15** are driven by nobody; **pull-down resistors** on the I/O card hold them at **0**.
4. The CPU then reads the I/O port number on the address bus, pushes the **I register**, pushes the **PC register** to the **stack**, stores the I/O data in the **I register**, sets the **interrupt flag** to **LOW**, sets the **INR** control line to **LOW**, and then jumps to the memory location pointed by the **interrupt vector table**.
5. **EVT_PEND** clears in the step after the vector step. The **ESP32** then sends the next event from its queue, at least **1 µs** after the flag went to **0**. So **INT** can't come back on the very next cycle.
6. When the CPU has finished processing the interrupt (by reaching the IRT instruction), it pops the PC register out of the stack to get back to work on the code that was interrupted, and pops the I register. If INT pin is HIGH, it manages the next interrupt immediately.

I/O processor side (ESP32)

The CPU does not always have enough time to process an interrupt before the next one is triggered. The **I/O processor (ESP32)** keeps the 256-entry queue and hands the events to the mailbox one at a time. The **mailbox** holds **only one event**.

If an interrupt is triggered but the previous one was not processed by the CPU yet, then the I/O port number is stacked in the queue of the **I/O processor (ESP32)**, and the **mailbox** will keep the **INT** control line **HIGH** until the
CPU is ready to manage it.

If the queue is full, any new interrupt will be discarded.

Software interrupts

The CPU implements the **INT** instruction, that triggers a software interrupt on the I/O port number defined by the programmer in the **V1** value of the instruction.

This kind of interrupt does not end up in a dialog between the CPU and the mailbox. Also, they have no priority on hardware interrupts.

__Register I__ will be pushed onto the stack, and the CPU will handle this interrupt just a regular hardware interrupt. Therefore, instruction __INT__ sets the data bus with the content of register I.

Instruction set

Abreviation	Operand	A.M.	Description	Flags
NOP	0x00		No operation	
ADC	0x01	*Reg*	R1 = R1 + R2 + Carry flag	**C N Z**
		Reg / Imm8	R1 = R1 + V1 + Carry flag	
		Reg / Ram	R1 = R1 + $(Vx) + Carry flag	
		RamReg / ImmReg / Offset	R3 = R3 + $((R1 << R2) + V2) + Carry flag	
		Stack / Offset	R1 = R1 + $(STK + V1) + Carry flag	
ADD	0x02	*Reg*	R1 = R1 + R2	
		Reg / Imm8	R1 = R1 + V1	
		Reg / Ram	R1 = R1 + $(Vx)	
		RamReg / ImmReg / Offset	R3 = R3 + $((R1 << R2) + V2)	
		Stack / Offset	R1 = R1 + $(STK + V1)	
AND	0x03	*Reg*	R1 = R1 & R2	**Z N**
		Reg / Imm8	R1 = R1 & V1	
		Reg / Ram	R1 = R1 & $(Vx)	
		RamReg / ImmReg / Offset	R3 = R3 & $((R1 << R2) + V2)	
		Stack / Offset	R1 = R1 & $(STK + V1)	
CAL	0x04	*Reg16*	STK = STK − 1, $(STK) = PC_LSB STK = STK − 1, $(STK) = PC_MSB [1]PC = R1 << R2	
		Imm16	STK = STK − 1, $(STK) = PC_LSB STK = STK − 1, $(STK) = PC_MSB PC = Vx	
CLC	0x05		Clears the Carry flag	**C**

1 PC: Program Counter

CLE	0x06		Clears the Equal flag	**E**
CLI	0x07		Clears the Interrupt flag	**I**
CLN	0x08		Clears the Negative flag	**N**
CLS	0x09		Clears the Superior flag	**S**
CLZ	0x0A		Clears the Zero flag	**Z**
CLF	0x0B		Clears the Inferior flag	**F**
CMP	0x0C	*Reg*	[2]FR = R1 ? R2	**S E F**
		Reg / Imm8	FR = R1 ? V1	
		RamReg / ImmReg / Offset	FR = R3 ? $((R1 << R2) + V2)	
		Stack / Offset	FR = R1 ? $(STK + V1)	
DEC	0x0D	*Reg*	R1 = R1 - 1	**C N Z**
		Imm16	$(Vx) = $(Vx) - 1	
		RamReg / ImmReg / Offset	$((R1 << R2) + V2) = $((R1 << R2) + V2) - 1	
HLT	0x0E		Halts the CPU (if **I** flag is not set, the computer freezes until reset)	**H**
IN	0x0F	*Reg*	Data bus = R1 Address bus = R2 IE = HIGH, RW = read	
OUT	0x10		Data bus = R2 Address bus = R1 IE = HIGH, RW = write	
INC	0x11	*Reg*	R1 = R1 + 1	**C N Z**
		Imm16	$(Vx) = $(Vx) + 1	
		RamReg / ImmReg / Offset	$((R1 << R2) + V2) = $((R1 << R2) + V2) + 1	
INT	0x12	*Imm8*	Software interrupt with port number V1: STK = STK − 1, $(STK) = I STK = STK − 1, $(STK) = PC_LSB STK = STK − 1, $(STK) = PC_MSB PC = $(0xFE00 + 2 × V1) Clears Interrupt flag	**I**

2 FR: Flag Register

Abreviation	Operand	A.M.	Description	Flags
IRT	0x13		[3]PC_MSB = $([4]STK), STK = STK + 1 [5]PC_LSB = $(STK), STK = STK + 1 I = $(STK), STK = STK + 1 Sets Interrupt flag	**I**
JMC	0x14	*Reg16*	PC = $(R1 << R2) if Carry flag	
		Imm16	PC = $(Vx) if Carry flag	
JME	0x15	*Reg16*	PC = $(R1 << R2) if Equality flag	
		Imm16	PC = $(Vx) if Equality flag	
JMN	0x16	*Reg16*	PC = $(R1 << R2) if Negative flag	
		Imm16	PC = $(Vx) if Negative flag	
JMP	0x17	*Reg16*	PC = $(R1 << R2)	
		Imm16	PC = $(Vx)	
JMS	0x18	*Reg16*	PC = $(R1 << R2) if Superior flag	
		Imm16	PC = $(Vx) if Superior flag	
JMZ	0x19	*Reg16*	PC = $(R1 << R2) if Zero flag	
		Imm16	PC = $(Vx) if Zero flag	
JMF	0x1A	*Reg16*	PC = $(R1 << R2) if Inferior flag	
		Imm16	PC = $(Vx) if Inferior flag	
STR	0x1B	*RamReg / ImmReg / Offset*	$((R1 << R2) + V2) = R3	
		Reg / Ram	$(Vx) = R1	
		Stack / Offset	$(STK + V1) = R1	
LOD	0x1C	*RamReg / ImmReg / Offset*	R3 = $((R1 << R2) + V2)	
		Reg / Ram	R1 = $(Vx)	
		Stack / Offset	R1 = $(STK + V1)	
MOV	0x1D	*Reg*	R1 = R2	
		Reg / Imm8	R1 = V1	
NOT	0x1E	*Reg*	R1 = ! R1	**Z N**
		Imm16	$(Vx) = ! $(Vx)	

3 PC_MSB: Program Counter most significant byte
4 STK: Stack pointer
5 PC_LSB: Program Counter least significant byte

Abreviation	Operand	A.M.	Description	Flags
OR	0x1F	*Reg*	R1 = R1 | R2	
		Reg / Imm8	R1 = R1 | V1	
		Reg / Ram	R1 = R1 | $(Vx)	
		RamReg / ImmReg / Offset	R3 = R3 | $((R1 << R2) + V2)	
		Stack / Offset	R1 = R1 | $(STK + V1)	
POP	0x20	*Reg*	R1 = $(STK) STK = STK + 1	
PSH	0x21		STK = STK - 1 $(STK) = R1	
RET	0x22		PC_MSB = $(STK), STK = STK + 1 PC_LSB = $(STK), STK = STK + 1	
SHL	0x23	*Reg*	Left shift on R1	**C Z N**
ASR	0x24		Arithmetical shift on R1	
SHR	0x25		Right shift on R1	**[6]Z N**
STC	0x26		Sets the Carry flag	**C**
STE	0x27		Sets the Equality flag	**E**
STI	0x28		Sets the Interrupt flag (after next instruction is done)	**I**
STN	0x29		Sets the Negative flag	**N**
STS	0x2A		Sets the Superior flag	**S**
STZ	0x2B		Sets the Zero flag	**Z**
STF	0x2C		Sets the Inferior flag	**F**
PSF	0x2D		STK = STK - 1, $(STK) = FR	[7]
POF	0x2E		FR = $(STK), STK = STK + 1	**All**

6 **SHR** is a logical shift (bit 7 = 0).

7 **POF** overwrites all flags, Interrupt and Halt included (popping a value with the Halt flag set halts the CPU). In an interrupt handler, **PSF** first and **POF** just before **IRT** is safe: both flags are cleared when the handler starts.

Abreviation	Operand	A.M.	Description	Flags
SUB	0x2F	*Reg*	R1 = R1 - R2	**C N Z**
		Reg / Imm8	R1 = R1 - V1	
		Reg / Ram	R1 = R1 - $(Vx)	
		RamReg / ImmReg / Offset	R3 = R3 - $((R1 << R2) + V2)	
		Stack / Offset	R1 = R1 – $(STK + V1)	
SBB	0x30	*Reg*	R1 = R1 - R2 - Carry flag	**C N Z**
		Reg / Imm8	R1 = R1 - V1 - Carry flag	
		Reg / Ram	R1 = R1 - $(Vx) - Carry flag	
		RamReg / ImmReg / Offset	R3 = R3 - $((R1 << R2) + V2) - Carry flag	
		Stack / Offset	R1 = R1 – $(STK + V1) - Carry flag	
XOR	0x31	*Reg*	R1 = R1 ^ R2	**Z N**
		Reg / Imm8	R1 = R1 ^ V1	
		Reg / Ram	R1 = R1 ^ $(Vx)	
		RamReg / ImmReg / Offset	R3 = R3 ^ $((R1 << R2) + V2)	
		Stack / Offset	R1 = R1 ^ $(STK + V1)	
ASP	0x32	*Imm8*	STK = STK + V1	
		Imm16	STK = STK + Vx	
[8]SSP	0x33	*Imm8*	STK = STK - V1	
		Imm16	STK = STK - Vx	
[9]RSP	0x34	*Reg16*	R1 = STK_MSB, R2 = STK_LSB	
[10]WSP	0x35	*Reg16*	STK = R1 << R2	
		Imm16	STK = Vx	

8 **SSP** reserves space for local variables when a function starts, and **ASP** frees it before **RET**. The Imm16 mode is for large local arrays (more than 255 bytes).
9 **RSP** copies the stack pointer into a register pair, for the address of a local (&n).
10 **WSP** sets the stack pointer, to place the stack elsewhere than its reset position.