IF YOUR DVD DRIVE IS HIDDEN

HKEY_LOCAL_MACHINE\SYSEM\CurrentControlSet\

Control\Class > Delete UpperFilters & LowerFilters