

Soldier Tracking and Assesment Tactical System (S.T.A.T)

SLAVE NODE, BUILD TWO COPIES: Slave 1 and Slave 2

MASTER NODE

Notes:

1. Use 3.3V-compatible logic for BU01, ST7789, MAX30102, and LSM303DLHC.

2. If BU01 is configured for UART, replace SPI nets with TX/RX nets before firmware bring-up.

3. Confirm battery divider values from ESP32 ADC range and desired sleep current.

4. TP4056 modules with protection are not ideal power-path/load-sharing chargers; test charge-while-running behavior on bench.

Sheet: /
File: STAT.kicad_sch
Title:
Size: A3 Date: Rev:
KiCad E.D.A. 9.0.6 Id: 1/1

1. Use 3.3V-compatible logic for BU01, ST7789, MAX30102, and LSM303DLHC.
2. If BU01 is configured for UART, replace SPI nets with TX/RX nets before firmware bring-up.
3. Confirm battery divider values from ESP32 ADC range and desired sleep current.
4. TP4056 modules with protection are not ideal power-path/load-sharing chargers; test charge-while-running behavior on bench.

Sheet: /		File: STAT.kicad_sch	
Title:			
Size: A3	Date:	Rev:	
KiCad E.D.A. 9.0.6		Id: 1/1	