For detailed guides on setting up the Meshtastic Python CLI on each OS, refer to these resources:

- Windows: Meshtastic Python Setup on Windows
- Linux & macOS: Meshtastic Python CLI Guide

Otherwise, see below

Windows

- 1. Download Python from the official site and ensure to check "Add Python to PATH" during installation: https://www.python.org/downloads/
- 2. Verify pip is installed by running:
- 3. bash

```
pip --version
```

- 4. Install Meshtastic using:
- 5. bash

bash

```
pip install meshtastic
```

Linux

1. Install Python using:

```
sudo apt-get update
sudo apt-get install python3

Install pip using:

bash

sudo apt-get install python3-pip
Install Meshtastic using:
```

```
pip3 install --upgrade meshtastic
```

macOS

- 1. Install Python using Homebrew:
- 2. bash

brew install python3

- 3. Verify pip is installed by running:
- 4. bash

pip3 --version

- 5. Install Meshtastic using:
- 6. bash

pip3 install --upgrade meshtastic