Memory Type	DDR Multiplier					
SDRAM	x1					
DDR	x2					
DDR2	x4					
DDR3	х8					
Memory Transfer Speed Formula						
Effective Clock = Base Clock * DDR Multipler						
Transfer Speed = Effective Clock * 8						

**Practice Questions (fill in the blanks)** 

DDR Type	Base Clock (MHz)	Multipler	Effective Clock (MHz)	Transfer Speed (MB/s)	Also Known As
DDR-200	100	2	200	1600	PC-1600
DDR-266		2	266	2133	PC-2100 (sometimes approximated)
DDR	200	2		3200	PC-3200
DDR2-400	100	_	400	3200	PC2-3200
DDR2	200	_		6400	PC2-6400
DDR3-800	100	8	800		PC3
DDR3-1600		8	1600	12800	PC3

## **Practice Question Answers**

DDR Type	Base Clock (MHz)	Multipler	Effective Clock (MHz)	Transfer Speed (MB/s)	Also Known As
DDR-200	100	2	200	1600	PC-1600
DDR-266	133	2	266	2133	PC-2100
DDR-400	200	2	400	3200	PC-3200
DDR2-400	100	4	400	3200	PC2-3200
DDR2-800	200	4	800	6400	PC2-6400
DDR3-800	100	8	800	6400	PC3-6400
DDR3-1600	200	8	1600	12800	PC3-12800