```
buildBDD(o2,1,false)
\rightarrow o2 = g9 = f * g8 = 1 (controlling value) and isCare = false
     buildBDD(g8,1,false):
     \rightarrow g8 = g4 + g7 = 1 (non-controlling value) and isCare = false
           \rightarrowwitnessBDD(g8, 1)
                \rightarrowlet A = buildBDD(g7,1,true)
                \rightarrow A = g3 * g6 = ab(ec' + d)
                \rightarrowlet B = buildBDD(g4,1,false)
                \rightarrow g4 = g1 * c = 1(controlling value) and isCare = false
                      buildBDD(g1,1,false)
                      \rightarrow g1 = b * d = 1(controlling value) and isCare = false
                            buildBDD(b,1,false) \rightarrow return BDD for b
                            buildBDD(d,1,false) \rightarrow return BDD for d
                      buildBDD(c,1,false) \rightarrow return BDD for c
                \rightarrow B = bcd
                call restrict(A,B) \rightarrow return a
           \rightarrowwitnessBDD(g8, 1) = a
     buildBDD(g8,1,false) = a
     buildBDD(f,1,false) \rightarrow return BDD for f
buildBDD(o2,1,false) = a * f
```

The size of buildBDD(o2,1,false) is smaller than g9 in p6a.





