



DJI Pocket 2 Release Notes

Date:	2021.01.28
Firmware:	V01.03.00.10
DJI Mimo App iOS:	V1.5.11
DJI Mimo App Android:	V1.5.10

What's New?

- Optimized auto focus in low temperature environments.
- Fixed some minor bugs.

Notes:

- If the update fails, restart DJI Pocket 2 and DJI Mimo and retry.
- Contact DJI Support if the update fails again.



DJI Pocket 2 Release Notes

Date:	2021.01.05
Firmware:	v01.02.00.50
DJI Mimo App iOS:	v1.5.8
DJI Mimo App Android:	v1.5.8

What's New?

- Added HDR Video for better dynamic range.
- Added Story mode to the touchscreen. Users can choose from a variety of Story videos where the gimbal moves up, down, left, right, clockwise, counterclockwise, or zooms in or out. Connect to DJI Mimo and enter playback to complete the Story videos using AI Editor.
- Added Wireless Mic In/Earpieces Out. Make sure an external earphone is connected to the 3.5mm port of the Do-It-All Handle and that Pro is enabled in Video mode. The user will be able to check the wireless audio via the earphone while recording.
- Added Trimmed Download (DJI Mimo of v1.5.8 or later required).
- Added ability to lock the gimbal when using with the Mini Control Stick. Press and hold the right button of the Mini Control Stick to lock the gimbal and press again to unlock.
- Added ability to choose the direction the camera is facing when powering on. Press and hold the Power button to power on with the camera facing the user and press and hold the Function button to power on with the camera facing forward.
- Increased the time that the gimbal stays in position in order to fit it into the cover when powering off.
- Optimized software and anti-interference of the wireless mic.
- Fixed some minor bugs.

Notes:

- If the update fails, restart DJI Pocket 2 and DJI Mimo and retry.
- Contact DJI Support if the update fails again.



DJI Pocket 2 Release Notes

Date:	2020.10.30
Firmware:	v01.01.00.30
DJI Mimo App iOS:	v1.5.0
DJI Mimo App Android:	v1.5.0

What's New?

- Added audio zoom.
- Added ability to use Mini Control Stick to adjust zoom speed. Select Control Stick Speed under settings.
- Added Directional Audio mode to Pro mode.
- Added Glamour Effects to touchscreen.
- Added ability to start and stop recording during livestreaming.
- Optimized color for a more realistic and vivid color performance.
- Optimized battery life of the wireless microphone.
- Optimized system stability to improve user experience.
- Optimized focus, metering, and color effects in some situations.
- Optimized white balance effect under water (when using DJI Pocket 2 with Waterproof Case).
- Fixed some minor bugs.

Notes:

- If the update fails, restart DJI Pocket 2 and DJI Mimo and retry.
- Contact DJI Support if the update fails again.