


OSMO

Battery Checker

User Guide

v1.0

2016.05



dji

Disclaimer and Warning

Congratulations on purchasing your new DJI™ product. The information in this document affects your safety and your legal rights and responsibilities. Read this entire document carefully to ensure proper configuration before use. Failure to read and follow instructions and warnings in this document may result in serious injury to yourself or others, damage to your DJI product, or damage to other objects in the vicinity. This document and all other collateral documents are subject to change at the sole discretion of DJI. For up-to-date product information, visit <http://www.dji.com> and click on the product page for this product.

By using this product, you hereby signify that you have read this disclaimer and warning carefully and that you understand and agree to abide by the terms and conditions herein. You agree that you are solely responsible for your own conduct while using this product, and for any consequences thereof. You agree to use this product only for purposes that are proper and in accordance with all applicable laws, rules, and regulations, and all terms, precautions, practices, policies and guidelines DJI has made and may make available.

DJI accepts no liability for damage, injury or any legal responsibility incurred directly or indirectly from the use of this product. The user shall observe safe and lawful practices including, but not limited to, those set forth in this document.


DJI is a trademark of SZ DJI Technology Co., Ltd. (abbreviated as "DJI") and its affiliated companies. Names of products, brands, etc., appearing in this manual are trademarks or registered trademarks of their respective owner companies.

Introduction

The Osmo™ Battery Checker provides battery level indicators for users to instantly check the remaining charge of their Osmo Batteries.

Usage

Place the Osmo Battery into the slot of the Battery Checker and the indicator LEDs will show the current battery level. Refer to the table below for more information about the blinking patterns.



Battery Level Indicator Description

- : The LED is solidly lit
- : The LED is off
- : The LED is blinking

LED1	LED2	LED3	LED4	Battery Level
○	○	○	○	>87.5%
○	○	○	○	75% to 87.5%
○	○	○	○	62.5% to 75%
○	○	○	○	50% to 62.5%
○	○	○	○	37.5% to 50%
○	○	○	○	25% to 37.5%
○	○	○	○	12.5% to 25%
○	○	○	○	<12.5%

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

EU Compliance Statement

SZ DJI TECHNOLOGY CO., LTD. hereby declares that this device is in compliance with the essential requirements and other relevant provisions of the EMC Directive.

A copy of the EU Declaration of Conformity is available online at www.dji.com/euro-compliance



EU contact address: DJI GmbH, Industrie Strasse. 12, 97618, Niederlauer, Germany

DJI Support:

www.dji.com/support

Manufactured by:

SZ DJI Technology Co., Ltd.

14th floor, West Wing, Skyworth Semiconductor Design Building NO.18 Gaoxin South 4th Ave,
Nanshan District, Shenzhen, Guangdong, China

The content in this document is subject to change.

Download the latest version from
www.dji.com/product/osmo

If you have any questions about this document, please contact DJI
by sending a message to DocSupport@dji.com.

OSMO™ is a trademark of DJI.
Copyright © 2016 DJI All Rights Reserved.