	Methods for Clean up		Small spill: Move containers from spill area. Vacuum or sweep up material and place in a designated, labeled waste container. Dispose of via a licensed waste disposal contractor. Large spill: Move containers from spill area. Prevent entry into sewers, water courses, basements, or confined areas. Vacuum or sweep up material and place in a designated, labeled waste container. Dispose of via a licensed waste disposal contractor. Note: See section 1 for emergency contact information and section 13 for waste disposal.			
7.	Handling and Store	ano				
7.	Handling Put on appropriate personal protection equipment (see Eating, drinking, and smoking should be prohibited in a this material is handled, stored, and processed. Wor wash hands and face before eating, drinking, an Remove contaminated clothing and protective equipment entering eating areas.				ohibited in areas where essed. Workers should lrinking, and smoking. ctive equipment before	
	Storage		Store in accordance with local regulations. Store in original container protected from direct sunlight in a dry, cool, and well-ventilated area, away from incompatible materials (see section 10) and food and drink. Keep container tightly closed and sealed until ready for use. Containers that have been opened must be carefully resealed and kept upright to prevent leakage. Do not store in unlabeled containers. Use appropriate containment to avoid environmental contamination.			
8.	Exposure Limits and Personal Protective Equipment					
0.	United States					
			ıpational Exposure L			
		Ingredient	Exposure Limits			
	Canada Occupational Exposure Limits					
	Ingredient	List Name	TWA (8 Hours)	STEL (15 mins)	Ceiling	
			Mexico			
			pational Exposure Limits			
	Ingredient		Exposure Limits			
	Recommended Monitoring Procedures Engineering Measures		If this product contains ingredients with exposure limits, personal, workplace, atmosphere, or biological monitoring may be required to determine the effectiveness of the ventilation or other control measures and/or the necessity to use respiratory protective equipment.			
			No specific ventilation requirements. Good general ventilation should be sufficient to control worker exposure to airborne contaminants. If this product contains ingredients with exposure limits, use process enclosures, local exhaust ventilation or other engineering controls to keep worker exposure below any recommended or statutory limits.			
	Hygiene Measures		Wash hands, forearms and face thoroughly after handling chemical products, before eating, smoking or using the lavatory and at the end of the working period. Appropriate techniques should be used to remove potentially contaminated clothing. Wash contaminated clothing before reusing. Ensure that eyewash stations and safety showers are close to the workstation location.			