Chimera5 机架组装示意图 Frame Assembly Guide

1.	M3X20网纹铝柱 M3X20 Al. standoff	x6	21.	机线集线管(附赠) Motor wire protector
2.	M3X28网纹铝柱 M3X28 Al. standoff	x2		电池防滑垫(附赠) Battery Pad
3.	M3X22网纹铝柱 M3X22 Al. standoff	x1		侧板 Cam mount
4.	M2X25网纹铝柱 M2X25 Al. standoff	x2	24.	顶板 Top plate
5.	M3X8内六角螺丝 M3X8 hex screw	x30	25.	中板 Counter plate
6.	M3X10内六角螺丝 M3X10 hex screw	x4	26.	底板 Bottom plate
7.	M3X14内六角螺丝 M3X14 hex screw	x4		后机臂 Rear arm
8.	M3X30内六角螺丝 M3X30 hex screw	x4	28.	图传天线座(模拟) Antenna/RX (Analog) TPU
9.	M2X25内六角螺丝(附赠) M2X25 hex screw	×4	29.	竖立安装款T型天线座 打印件(附赠) Vertical 900 antenna TPU
10.	M2X12内六角螺丝(附赠) M2X12 hex screw	×4	30.	GPS座侧板 TPU打印 Horiz. 900 ant. + GPS TPU
11.	M2X8带垫内六角螺丝 washer head hex screw	×4	31.	电池扎带 (附赠) Battery strap
12.	M2X4内六角螺丝 M2X4 hex screw	×4		小天线保护管 4CM(附赠) Antenna tube
	M2X6内六角螺丝 M2X6 hex screw	x2	33.	小天线保护管帽(附赠) Antenna cap
	M2X8内六角螺丝 M2X8 hex screw	x4	34.	GPS座 固定碳板 GPS carbon mount
15.	M2尼龙螺母(附赠) M2 Nylon nut	x8	35.	前机臂 Front arm
16.	M3尼龙螺母 M3 Nylon nut	x16	36.	GPS座 TPU打印 GPS mount TPU
17.	图传天线座打印件(HD) Antenna (HD) TPU	x1	37.	侧板打印件 Spacer TPU
	GoPro可调底座(附赠) GoPro mount seat TPU	x1		M3X10内六角螺丝(附赠) M2X25 hex screw
19.	脚垫 Arm guard TPU	x1		
20.	摄像头保护罩(附赠) Lens protector	x1		

x4

x2

x1

x1

x1

x1

x1

x1

x2

x2

x2

x1

x1

x1

x1

x4



