AOS 4 V5

机架组装示意图

Frame Assembly Guide

1. 顶板 Top plate	x1
2. 底板 Bottom plate	x1
3. 机臂	x4
4. 中板 Counter plate	x1
5. 支撑板 Supporting plate	x1
6. O3 摄像头固定侧板 6. O3 camera side plate	x2
7. CNC 摄像头侧板 7. CNC camera side plate	x2
8. 脚垫打印件 8. Arm guard TPU	x4
9. 图传天线座打印件 9. Antenna TPU	x1
+ ± 1/5+0 ct + ± C0 /4-	x1
10. 接收机座打印件 Receiver mount TPU 11. 固定XT60上盖打印件	x1
11. XT60 upper mount TPU 12. 固定XT60下盖打印件	x1
12. 图定X160 下盖打印件 XT60 bottom mount TPU 13. 摄像头硅胶侧板	
13. Silicone camera side plate	x2
14. M3*20 圆形网纹铝柱 M3*20 Al. standoffv	х7
15. M2*23 圆形网纹铝柱 M2*23 Al. standoffv	x2
16. M3*6 沉头内六角螺丝 M3*6 countersunk hex screw	x7
17. M2*8 内六角螺丝 M2*8 hex screw	x14
18. M2*6 内六角螺丝 M2*6 hex screw	x10
19. M3*10 沉头内六角螺丝 M3*10 countersunk hex screw	х3
20. M3*12 沉头内六角螺丝 M3*12 countersunk hex screw	x5
21. M1.6*10 杯头内六角螺丝 M1.6*10 socket head cap	x5
22. M3*6 内六角螺丝 M3*6 hex screw	х3
23. M3*20 内六角螺丝 M3*20 hex screw	x5
24. M2*10 内六角螺丝 M2*10 hex screw	х3
25. M2*14 内六角螺丝 M2*14 hex screw	х3
·M2*14 hex screw	

26. M2 防松自紧螺母 M2 lock nut	хЗ
27. M2*5 内六角螺丝 M2*5 hex screw	х5
28. M2*3 沉头内六角螺丝 M2*3 countersunk hex screw	х5
29. M2 螺母 M2 nut	х3
30. O4 Pro 支架 TPU O4 Pro bracket TPU	x2
31. O4减震垫 TPU O4 Vibration DampersTPU	x2
(附幢)/(Additional parts)	

1.模拟摄像头固定侧板 Analog camera side plate х2 2. M2*5 沉头内六角螺丝 х5 M2*5 countersunk hex screw 3. M3 防松自紧螺母 M3 lock nut х5 **4.** 电源线+插头 Power cable + plug х1 5. 集线管 Motor wire protecto х4 6. 15*250 超纤皮电池扎带 15*250 Battery strap х1 7. 20*250 超纤皮电池扎带 20*250 Battery strap х1 8. 电池硅胶防滑垫 Battery pad х2 9. 自锁尼龙扎带 х4 * Self-locking nylon zip ties 10. M3 螺母 M3 nut х5 11. ^{通用贴纸} Sticker x1 12. M1.6*7 带垫内六角螺丝 12. M1.6*7 hex screw head screw х5 13. M2*6 沉头内六角螺丝 13. M2*6 countersunk hex screw х5 14. O4 Pro支架(ND镜) TPU 14. O4 Pro bracket (ND filter)TPU x2 04 支架 TPU 15. O4 bracket TPU x2

