## AOS HS5

## 机架组装示意图

## Frame Assembly Guide

	1.	顶板 Top plate	x1
		底板 Bottom plate	x1
	3.	- · · ·	x1
	4.	机臂上盖 Arm upper cover	х4
	5.	机臂下盖 Arm lower cover	х4
	6.	电机整流罩 Motor fairing	х4
		头罩 Drone hood	x1
		机身 Body	x1
	9.	电池支架 Battery holder	x1
1		M2*6 内六角螺丝 M2*6 hex screw	х5
		M2*8 内六角螺丝 M2*8 hex screw	х5
		M3*10 内六角螺丝 M3*10 hex screw	x17
		M3*8 沉头内六角螺丝 M3*8 countersunk hex screw	х4
1	4.	M3 防松自锁螺母 M3 lock nut	х5
1	5.	M3*30 圆形网纹铝柱 M3*30 Al. standoff	х5
		M3*15 圆形无纹铝柱 M3*15 Al. standoff	х5
1	7.	M3*25 内六角螺丝 M3*25 hex screw	х5
1	8.	金属垫片 M3*8*2 Metal washer M3*8*2	х5
1	9.	M3*26 内六角螺丝 M3*26 hex screw	х5

(附赠)/(Additional parts)	
<b>1.</b> 纳米双面胶 400*10mm 400*10mm double-sided adhesive tape	x1
2. XT60 插头 2. XT60 Plug	x1
3. 电解电容50V 1000uf Electrolytic capacitance 50V 1000uf	x1
4. 0.8MM 热缩管 0.8MM Heat shrink tube	х3
5.自锁尼龙扎带 Self-locking nylon zip ties	хб
6. 电池硅胶防滑垫 Battery pad	x2
7. 通用贴纸 V4 Sticker V4	x1

