## Defender 20 机架组装示意图

## Frame Assembly Guide

1. 上盖 1. Top plate	x1
2. 保护圈 2. Props guard	x1
3. O3 Lite镜头罩 3. O3 Lite camera cover	x1
4. 快拆扣 4. Quick release buckle	x1
电源按键帽 5. Button cover	x1
电源按键板 6. Power button board	x1
7. USB转接板 7. USB adapter	x1
8. LED导光件 8. LED light strip	x4
9. 防尘塞 9. Dust-proof cover	x1
10. M2*4 内六角螺丝 10. M2*4 hex screw	x16
11. M1.2*4 十字自攻螺丝 11. M1.2*4mm phillips screw	x14
12. M2*7*5 十字带垫自攻螺丝 M2*7*5 screw phillips screw with pad	х6
13. M2*5 内六角自攻螺丝 13. M2*5mm hex screw	х6
14. M2*10 内六角螺丝 14. M2*10 hex screw	x8
15. M1.6*16 内六角自攻螺丝 15. M1.6*16 hex phillips screw	х6
减震球 <sup>16.</sup> Damper ball	x8
17. O3 Lite散热片 O3 Lite heatsink	x1
18. O3 Lite导热片 O3 Lite thermal pad	x1
O3 Lite防滑垫A 19. O3 Lite pad A	x1
20. O3 Lite防滑垫B O3 Lite pad B	x1
21. O3 Lite防滑垫C O3 Lite pad C	x1

, (附赠)/(Additional parts)	、
电源线 <sup>1.</sup> Power cable	x1
斯楽器 <sup>2.</sup> Propeller removal tool	x1
3. 电池防滑垫 Battery pad	x2
4. Allen wrench	x1
S. 保护圈LED灯板 5. Props guard LED strip	x1
6. O3 Lite定位柱A 6. O3 Lite fixed column A	x2
7. O3 Lite定位柱B 7. O3 Lite fixed column B	x2
黑色十字小螺丝刀 8. Phillips screwdriver black	x1
9.5线 端子线 9.5 Pin cable	x1
10.6线 端子线 6 Pin cable	x1
11. O3 Lite导热硅胶垫 11. O3 Lite thermal silicone pad	x1
``	/



