
Windshield Wipers and Washers*

Windshield Wipers & Washers Controls:

Rotate ring to adjust Intermittent Wipe Speed.




Pull to spray and wipe.

Move lever Up/Down to change Wiper modes.

MIST: Single wipe OFF: Wiper off **INT:** Intermittent wipe

AUTO*: Auto Control function LO: Slow wipe

HI: Fast wipe




Move lever Up/Down to change Wiper modes.

MIST: Single wipe **OFF:** Wiper off INT: Intermittent wipe AUTO*: Auto Control function LO: Slow wipe

HI: Fast wipe


Rear Wiper & Washer Controls*:



Rotate Rear Wiper Switch to change Wiper modes.

ON: Normal wipe **INT*:** Intermittent wipe

OFF: Wiper off



Rotate Rear Wiper Switch to change Wiper modes.

ON: Normal wipe **INT*:** Intermittent wipe

OFF: Wiper off

For any questions regarding the features of your vehicle, please contact your preferred Kia dealer, or contact Kia Consumer Affairs at (800) 333-4Kia (4542)

Reference your Owner's Manual for more information on these features.

Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving. Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe personal injury and death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and use of any handheld devices, other equipment or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or that are not permissible by law should never be used during operation of the vehicle.

Safety Features: No system, no matter how advanced, can compensate for all driver error and/or driving conditions. Always drive responsibly.

Tilt/Telescoping Steering Wheel: Never attempt to adjust steering wheel position when vehicle is in motion.

Front Seat Headrest Adjustment: Never attempt to adjust headrests when vehicle is in motion.

Bluetooth® Wireless Technology: A compatible Bluetooth® wireless technology-enabled cell phone is required to use Bluetooth® wireless technology. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Kia is under license. Other trademarks and trade names are those of their respective owners. A Bluetooth® enabled cell phone is required to use Bluetooth® wireless technology.

SiriusXM®: SiriusXM Satellite Radio, SiriusXM Traffic and SiriusXM Travel Link each require a subscription sold separately, or as a package, by SiriusXM Radio Inc. If you decide to continue your service at the end of your trial subscription, the plan you choose will automatically renew and bill at then-current rates until you call 1-866-635-2349 to cancel. See SiriusXM Customer Agreement for complete terms at www.siriusxm.com. Other fees and taxes will apply. All fees and programming are subject to change. Not all vehicles or devices are capable of receiving all services offered by SiriusXM. Data displays and individual product availability vary by vehicle hardware. Current information and features may not be available in all locations, or on all receivers. Weather Forecast, Current Conditions may not be available in all locations. Images above are for representative purposes only and are not real products. For actual features and images of real products, consult the vehicle manufacturer. SiriusXM is not responsible for any errors or inaccuracies in the data services or their use in the vehicle. Travel Link Stocks displays current price and daily delta of around 7,000 actively reported securities traded on the NYSE®, NASDAQ® and AMEX®. The service is delayed approximately 20 minutes, SiriusXM satellite service is available only to those at least 18 years of age in the 48 continuous USA, DC, and Puerto Rico (with coverage limitations). SiriusXM Internet Radio service is available throughout our satellite service area and in AK and HI. © 2014 SiriusXM Radio Inc. Sirius, XM and all related marks and logos are trademarks of SiriusXM Radio Inc.

iPod® is a registered trademark of Apple Inc. iPod® mobile digital device sold separately

While the information contained in this guide is accurate at the time of printing, Kia may change vehicle specifications without notice in advance or after the fact, and assumes no liability in connection with such changes

A Quick Start Guide to Some of Your Kia Vehicle's Features

For Sedona and Soul vehicles equipped with Standard Audio Systems

Pair Your Phone via *Bluetooth*® Wireless Technology*

NOTE: Vehicle MUST be in "P" or Park

- Ensure Bluetooth® wireless technology is turned "on" on your phone
- 2 On your Audio system, press the PHONE key next to the display
- Select the name of your vehicle (KIA MOTORS) displayed on your phone
- A Follow the instructions on your device to confirm the passkey displayed. Press Ok or Pair to complete pairing. The contact download may take a few minutes

NOTE: Contact download will occur automatically at initial pairing

NOTE: Be sure to allow phonebook download and future auto-connection on your phone

NOTE: Ensure that only the "phone contact list" is selected for contact download (not Twitter, Facebook, or e-mail contact lists)

Using Steering Wheel Control Buttons^{†*}



Voice button (with iPhone only) Press to activate Siri. Press and hold to cancel Siri.



Call button

Press the button to display the Dial Number screen. Press again to display the most recently made call number. Press a third time to initiate making the call to the number displayed

END CALL Button

Press to end a call or reject an incoming call

Steering Wheel Adjustment*

NOTE: iPhone must be paired and connected

through Bluetooth prior to use

When adjusting the steering wheel in and out, the effort is reduced if the wheel is lifted upward when pulling out/pushing in.




Standard Audio System Video

To view a video on your mobile device, SNAP this QR code




*If equipped UA160-KU-016 *If equipped See next page for Voice Recognition tips

Front Seat Headrest Adjustment*




To adjust headrest forward*: Pull headrest forward at an angle to one of several positions.

To adjust headrest back*: Pull headrest completely forward at an upward angle, then release.



To raise headrest: Pull headrest up.

To lower headrest: Press lock, then press the headrest down.



To raise headrest, pull headrest up to the desired position

To lower headrest, press and hold the release button and lower headrest to the desired position

Media Mode*

Media mode includes a variety of modes, such as USB, iPod*, *Bluetooth** Audio, Aux, and My Music **NOTE**: Only MP3 and WMA files may be played or copied to My Music

• Insert your media. Press the MEDIA key repeatedly to scroll through a list of connected devices.

Copying Songs to My Music

Media Mode allows you to copy songs from USB Devices, and store them in My Music

- 1 Press the (MENU) key and select the desired function
- 2 Save to My Music: Songs on your USB device can be saved to My Music
- **3** File: Select a file to save
- 4 Mark All: Select all files
- **6** Unmark All: Deselect all files
- 6 Save: Save the selected files

Listening to your iPod®

Connect an iPod® device or, if an iPod® device is already connected, repeatedly press the MEDIA key until iPod® appears on the display

NOTE: Use the iPod® cable that was supplied with your device

Listening to Music from your Bluetooth® Wireless Technology Device

- 1 If not already done, pair your Bluetooth® wireless technology device to the Audio System
- 2 Press the (MEDIA) key, until Bluetooth® Audio is displayed on the screen
- 3 Press the Seek/Track A key to scroll through music songs
- To pause a track or song streaming from your Bluetooth* wireless technology device, press PLAY/PAUSE button on screen

NOTE: Make sure that the listening volume on your mobile device is turned up

Climate Control Systems

Climate Control System functions differ between systems and vehicles. Presented below are descriptions of the most common control functions:

Fan speed control switch/knob*

Air conditioning ON/OFF button

 \cap

Temperature control switch/knob*

REAR

Rear windshield defroster button*

FRONT

Front windshield defroster button*

Automatic climate control button*

PUSH DUAL

Dual temperature control mode*

✓ MODE ∧ Mode selection button(s)*

Recirculated air button

OFF

System OFF*

Climate information screen*

NOTE: Climate Control System options and the appearance and location of icons on the system in your vehicle may differ, as equipped

() QUICK **TIPS**

- · Keep interior glass surfaces as clean as possible to reduce window fogging
- Defrost W Mode activates A/C and opens Fresh Air Vent
- When Automatic Climate Control is set to Auto Operation, the A/C indicator will NOT illuminate. The fan speed, air intake, air flow and air conditioning may automatically be engaged at any time to reach desired temperature and reduce humidity.

(1) QUICK **TIPS**

Automatic and Manual Defrosting / Defogging

Max Defrost:

Defogging:

• Select Defrost W Mode

Select Defrost W Mode

Select Max Fan Speed

2 Select Max Fan Speed

3 Set **Temperature** to **Hot**

❸ Select desired **Temperature**[†]

Sound Settings

To adjust the UVO eServices System with Navigation sound settings:

- Press the SETUP key on the audio control unit or the on-screen MENU button, when in MEDIA mode
- 2 Select the on-screen SOUND button, or SOUND SETTINGS
- 3 Select the menu item (Position, Tone, Speed Dependent Volume, Touch Screen Beep)
- 4 Use the onscreen buttons to adjust settings
- **⑤** Press the return button **□** to save settings

DISPLAY key turns the display on/off

Your Features and Functions Guide, located in your glove box, contains much more information on these, and other available features of your Kia vehicle.

You can also view Features and Functions Videos to learn more about using the many new features of your vehicle by visiting https://www.youtube.com/KiaFeatureVideos

*If equipped

 $^{^{\}dagger}$ If moisture appears on windshield, adjust **Temperature Control Knob** to a warmer temperature