
Your Features and Functions Guide, located in your glove box, contains much more information on these, and other available features of your Kia vehicle.

You can also view Features and Functions Videos to learn more about using the many new features of your vehicle by visiting https://www.Youtube.com/KiaFeatureVideos

Wipers and Washers*

Windshield Wipers & Washers Controls:

Rotate ring to adjust Intermittent Wipe Speed



Pull to spray and wipe

Move lever Up/Down to change Wiper modes

MIST: Single wipe OFF: Wiper off INT: Intermittent wipe

AUTO*: Auto Control function LO: Slow wipe



Move lever Up/Down to change Wiper modes

MIST: Single wipe **OFF:** Wiper off

INT: Intermittent wipe


AUTO*: Auto Control function

LO: Slow wipe HI: Fast wipe

Pull lever


to spray and wipe

Rear Wiper & Washer Controls*:



Rotate Rear Wiper Switch to change Wiper modes

ON: Normal wipe INT*: Intermittent wipe OFF: Wiper off



Rotate Rear Wiper Switch to change Wiper modes

ON: Normal wipe INT*: Intermittent wipe OFF: Wiper off

For any questions regarding the features of your vehicle, please contact your

Reference your Owner's Manual or Car Multimedia System User's Manual, for more information on these features and other features that may be equipped on your vehicle

preferred Kia dealer or Kia Consumer Affairs at (800) 333-4542

Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving. Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe personal injury and death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and any handheld devices, other equipment or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or that are not permissible by law should never be used during operation of the vehicle.

Safety Features: No system, no matter how advanced, can compensate for all driver error and/or driving conditions. Always drive responsibly.

Tilt/Telescoping Steering Wheel: Never attempt to adjust steering wheel position when vehicle is in motion.

Front Seat Headrest Adjustment: Never attempt to adjust headrests when vehicle is in motion.

Bluetooth® Wireless Technology: A compatible Bluetooth® wireless technology-enabled cell phone is required to use Bluetooth® wireless technology. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Kia is under license. Other trademarks and trade names are those of their respective owners. A Bluetooth® enabled cell phone is required to use Bluetooth® wireless technology.

Apple CarPlay™ is a trademark of Apple Inc. iPhone®, Lightning® and iPod® are registered trademarks of Apple Inc.

Android Auto™, Android™ and Google Play™ are trademarks of Google, Inc.

While the information contained in this guide is accurate at the time of printing, Kia may change vehicle specifications without notice in advance or after the fact, and assumes no liability in connection with such changes.

A Quick Start Guide to Some of **Commonly Used Kia Vehicle Features**

For vehicles equipped with Standard Audio Systems

Pair Your Phone via *Bluetooth*® Wireless Technology

NOTE: Vehicle MUST be in Park

- Ensure Bluetooth® wireless technology is turned "on" on your phone in order to search
- Press the PHONE key next to the display or the CALL button on the steering wheel
- 3 On your phone display, select the vehicle name and pair (confirm passkey matches, or enter passkey if instructed)
- A Follow the instructions on your device to confirm the passkey displayed. Press Ok or Pair to complete pairing. Be sure to allow phonebook download and future autoconnection on your phone

NOTE: Ensure that only the "phone contact list" is selected for contact download (not Twitter, Facebook, or e-mail contact lists)

For any questions regarding the features of your vehicle, please contact your preferred Kia dealer or Kia Consumer Affairs at (800) 333-4542

Using Steering Wheel Control Buttons^{†*}



Voice button

If Android Auto is connected, activates or ends the device's voice recognition.

If Apple CarPlay is connected, activates or ends Apple CarPlay Siri recognition.



CALL button

Press to initiate or answer a call



END CALL Button

Press to end a call or reject an incoming call

Steering Wheel Adjustment*

When adjusting the steering wheel in and out, the effort is reduced if the wheel is lifted upward when pulling out/pushing in

Standard Audio System Video



To view this video on your mobile device, SNAP this QR code, or visit the listed website below


NOTE: If your phone is paired and connected through Bluetooth® Wireless Technology, it is necessary to select media mode to hear the video's audio

www.Youtube.com/KiaFeatureVideos




*If equipped UA190-KU-022 D. Audio 2 *If equipped

Front Seat Headrest Adjustment*




To adjust headrest forward*: Pull headrest forward at an angle to one of several positions

To adjust headrest back*: Pull headrest completely forward at an upward angle, then release



To raise headrest: Pull headrest up

To lower headrest: Press lock, then press the headrest down



To raise headrest, pull headrest up to the desired position

To lower headrest, press and hold the release button and lower headrest to the desired position

Apple CarPlay & Android Auto

Android Auto™* - Setting up Android Auto™

- 1 From an Android Auto™ compatible device, download the Android Auto™ app from the Google Play™ Store
- 2 Open the Android Auto[™] app and proceed with the on-screen instructions to complete setup on the mobile device

How to start Android Auto™:

- 1 Press the (SETUP) key on the head unit
- 2 Press the **Phone Projection** button, select Android Auto™ then select **ENABLE ANDROID AUTO**. Accept all terms, conditions and requests on the head unit and phone in order to use Android Auto™
- 3 Connect the Android™ device with the vehicle's USB port using the manufacturer's cable provided with your phone
- ◆ From the vehicle's home screen, select the Android Auto™ button, where you'll see all the Android Auto™ supported apps

REMINDER: Android Auto compatibility requirements: Micro-USB cable that came with your phone, OS Android™ 5.0 or higher, compatible Android smartphone and data and wireless plan for applicable feature(s). It is recommended to always update your phone to the latest operating system release

Apple CarPlay** - Setting up Apple CarPlay*:

- 1 On the head unit, press the SETUP key
- Press the Phone Projection button, select Apple CarPlay® then select ENABLE APPLE CARPLAY. [Accept all terms, conditions and requests on the head unit and phone in order to use Apple CarPlay®]
- 3 Connect the Apple CarPlay® compatible iPhone with the vehicle's USB port using the manufacture's cable provided with your iPhone
- 4 From the vehicle's home screen, select the Apple CarPlay® button, where you'll see all the Apple CarPlay® supported apps

REMINDER: Apple CarPlay compatibility requirements: Apple Lightning® cable, iPhone 5 or later and data and wireless plan for applicable feature(s). It is recommended to always update your phone to the latest operating system release

Radio Presets

How to Save a Preset

1 Tune to the desired station and press and hold one of the preset buttons to save the AM/FM preset *If equipped

QR CODE

Apple CarPlay Quick Start Guide

To view the Apple CarPlay Quick Start Guide on your mobile device, snap this QR Code



Android Auto Quick Start Guide

To view the Android Auto Quick Start Guide on your mobile device, snap this QR Code



NOTE: If playing a video with your smart phone connected, audio may not be played or may be heard through the head unit

Custom Key*

 (\star) is a programmable key to provide quick access to one of several available system features

To Program the Custom Key

- Press and hold the (☆) Custom Button
- 2 Select one of the available features you would like the Custom Key to open

Climate Control Systems


Climate Control System functions differ between systems and vehicles. Presented below are descriptions of the most common control functions:

Fan speed control switch/knob*

Temperature control switch/knob*

FRONT WINDShield defroster button*

Automatic climate control button*



Air conditioning ON/ OFF button

Rear windshield defroster button* Mode selection



button(s)* **Dual temperature** control mode* System OFF*

NOTE: Climate Control System options and the appearance and location of icons on the system in your vehicle may differ, as equipped

QUICK TIPS

- · Keep interior glass surfaces as clean as possible to reduce window fogging
- Defrost W Mode activates A/C and opens Fresh Air Vent
- When Automatic Climate Control is set to Auto Operation, the A/C indicator will NOT illuminate. The fan speed, air intake, air flow and air conditioning may automatically be engaged at any time to reach desired temperature and reduce humidity

Automatic and Manual Defrosting / Defogging

Max Defrost:

Defogging:

● Select Defrost W Mode

Select Defrost W Mode

2 Select Max Fan Speed **6** Set **Temperature** to **Hot** 2 Select Max Fan Speed 3 Set desired Temperature

Media Mode*

Media mode includes a variety of modes, such as USB, iPod®, Bluetooth® Audio, and Aux

- 1 Insert your media. Press the MEDIA key repeatedly to scroll through a list of connected devices Listening to your iPod®
- Connect an iPod® device or, if an iPod® device is already connected, repeatedly press the (MEDIA) key until iPod® appears on the display

NOTE: Use the iPod® cable that was supplied with your device

Listening to Music from your Bluetooth® Wireless Technology Device

- 1 If not already done, pair your Bluetooth® wireless technology device to the Audio System
- 2 Press the (MEDIA) key, until Bluetooth® Audio is displayed on the screen
- 3 Press the V Seek/Track A key to scroll through music songs
- To pause a track or song streaming from your Bluetooth® wireless technology device. press PLAY/PAUSE button on screen

NOTE: Make sure that the listening volume on your mobile device is turned up

Sound Settings

- 1 Press the (SETUP) key
- 2 Select the on-screen SOUND button, SOUND SETTINGS or use the tuning knob.
- 3 Select the menu item (Position, Volume, Tone, Priority*, Navigation Volume*, Advanced*, Default)
- 4 Use the onscreen buttons or tuning knob to adjust settings
- **⑤** Press the return button <u>→</u> to save settings. <u>OISPLAY</u> key turns the display on/off

[†] If moisture appears on windshield, adjust **Temperature Control Knob** to a warmer temperature