Your Features and Functions Guide, located in your glove box, contains much more information on these, and other available features of your Kia vehicle.


You can also view Features and Functions Videos to learn more about using the many new features of your vehicle by visiting https://www.Youtube.com/KiaFeatureVideos.

A Quick Start Guide to Some of Commonly Used Kia Vehicle Features

For vehicles equipped with Standard Audio Systems

Wipers and Washers*

WINDSHIELD WIPERS & WASHERS CONTROLS



Move button to adjust Intermittent Wipe

Faster

Pull lever to spray and wipe

Slower


MIST: Single wipe OFF: Wiper off


INT: Intermittent wipe **LO:** Slow wipe

HI: Fast wipe

AUTO*: Auto Control function

REAR WIPER & WASHER CONTROLS*





ON: Normal wipe

INT: Intermittent wipe

OFF: Wiper off

For any questions regarding the features of your vehicle, please contact your preferred Kia dealer or Kia Consumer Affairs at (800) 333-4542.

Reference your Owner's Manual or Car Multimedia System User's Manual, for more information on these features and other features that may be equipped on your vehicle.

¹Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving.

Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe personal injury and death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and any handheld devices, other equipment or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or that are not permissible by law should never be used during operation of the vehicle.

Safety Features: No system, no matter how advanced, can compensate for all driver error and/or driving conditions. Always drive responsibly.

Bluetooth® Wireless Technology: A compatible Bluetooth® wireless technology-enabled cell phone is required to use Bluetooth® wireless technology. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Kia is under license. Other trademarks and trade names are those of their respective owners. A Bluetooth® enabled cell phone is required to use Bluetooth® wireless technology.

Apple CarPlay $^{\text{TM}}$ is a trademark of Apple Inc. iPhone® and iPod® are registered trademarks of Apple Inc.

Android Auto™, Android™ and Google Play™ are trademarks of Google, Inc.

While the information contained in this guide is accurate at the time of printing, Kia may change vehicle specifications without notice in advance or after the fact, and assumes no liability in connection with such changes.

Pair Your Phone via Bluetooth® Wireless Technology

NOTE: Vehicle MUST be in Park.

- 1 Ensure Bluetooth® wireless technology is turned "on" on your phone in order to search
- 2 Press the PHONE key next to the display or the C CALL button on the steering wheel
- 3 On your phone display, select the vehicle name and pair (confirm passkey matches, or enter passkey if instructed)
- 4 Follow the instructions on your device to confirm the passkey displayed. Press OK or PAIR to complete pairing. Be sure to allow phonebook download and future autoconnection on your phone

NOTE: Ensure that only the "phone contact list" is selected for contact download (not Twitter, Facebook, or e-mail contact lists).

For any questions regarding the features of your vehicle, please contact your preferred Kia dealer or Kia Consumer Affairs at (800) 333-4542.

Using Steering Wheel Control Buttons^{†*}



VOICE BUTTON

If Android Auto is connected, activates or ends the device's voice recognition.

If Apple CarPlay is connected, activates or ends Apple CarPlay Siri recognition



CALL BUTTON

Press to initiate or answer a call



END CALL BUTTON

Press to end a call or reject an incoming call

QR CODE

Standard Audio System Video

To view this video on your mobile device, SNAP this QR code, or visit the listed website below.

www.Youtube.com/KiaFeatureVideos

NOTE: If your phone is paired and connected through Bluetooth® Wireless Technology, it is necessary to select media mode to hear the video's audio.





*IF EQUIPPED UA220-KU-122 D. Audio 2

Android Auto™ / Apple CarPlay® Setup*

Android AutoTM compatible smartphone setup - Download the Android AutoTM app from the Google PlayTM Store. Open the Android AutoTM app and proceed with the onscreen instructions to complete setup on the mobile device.

Wireless Connection setup for Android Auto™ & Apple CarPlay® (Standard Audio System-Value only):

- 1 Press the SETUP key on the audio head unit
- 2 Press DEVICE CONNECTION SETTINGS
- 3 Press PHONE PROJECTION, then ADD NEW

REMINDERS:

- Android Auto[™] compatibility requirements: OS Android[™] 5.0 or higher, compatible Android[™] smartphone and data and wireless plan for applicable feature(s)
- Apple CarPlay® compatibility requirements: Latest iOS software (above iOS 10) and data and wireless plan for applicable feature(s)
- · It is recommended to always update your phone to the latest operating system release
- Due to the smartphone's battery draw when using wireless Android Auto™ or Apple CarPlay®, recommend connecting the phone's USB charger or using the wireless charger, if equipped

Radio Presets

HOW TO SAVE A PRESET

1 Tune to the desired station and press and hold one of the preset buttons to save the AM/FM preset

Sound Settings

- 1 Press the SETUP key
- 2 Select the on-screen SOUND button, SOUND SETTINGS or use the tuning knob
- 3 Select the menu item (Position, Volume, Tone, Priority*, Navigation Volume*, Advanced*, Default)
- 4 Use the onscreen buttons or tuning knob to adjust settings
- 5 Press the RETURN button = to save settings. DISPLAY key turns the display on/off

Custom Key*

is a programmable key to provide quick access to one of several available system features.

TO PROGRAM THE CUSTOM KEY

- 1 Press and hold the 🖈 CUSTOM Button
- 2 Select one of the available features you would like the Custom Key to open

Climate Control Systems

Climate Control System functions differ between systems and vehicles. Presented below are descriptions of the most common control functions:

- Fan speed control switch/knob*
- Temperature control switch/knob*
- Front windshield defroster button*
- Automatic climate control button*
- Recirculated air button
- Climate information screen*
- Air conditioning ON/
 OFF button
- Rear windshield defroster button*
- Mode selection button(s)*
- Dual temperature control mode*
- OFF System OFF*

NOTE: Climate Control System options and the appearance and location of icons on the system in your vehicle may differ, as equipped.

QUICK TIPS

- Keep interior glass surfaces as clean as possible to reduce window fogging
- Defrost W Mode activates A/C and opens Fresh Air Vent
- When Automatic Climate Control is set to Auto Operation, the A/C indicator will NOT illuminate. The fan speed, air intake, air flow and air conditioning may automatically be engaged at any time to reach desired temperature and reduce humidity

AUTOMATIC AND MANUAL DEFROSTING / DEFOGGING:

Max Defrost: Defogging:

- 1. Select **Defrost Mode**2. Select **Max Fan Speed**1. Select **Defrost Mode**2. Select **Max Fan Speed**2. Select **Max Fan Speed**
- 3. Set **Temperature** to **Hot** 3. Set desired **Temperature**

Media Mode*

Media mode includes a variety of modes, such as USB, iPod®, and Bluetooth® audio.

1 Insert your media. Press the MEDIA key repeatedly to scroll through a list of connected devices

LISTENING TO YOUR iPod®

2 Connect an iPod® device or, if an iPod® device is already connected, repeatedly press the MEDIA key until iPod® appears on the display

LISTENING TO MUSIC FROM YOUR BLUETOOTH® WIRELESS TECHNOLOGY DEVICE

- 1 If not already done, pair your Bluetooth® wireless technology device to the Audio System
- 2 Press the MEDIA key, until Bluetooth® Audio is displayed on the screen
- 3 Press the SEEK/TRACK key to scroll through music songs
- 4 To pause a track or song streaming from your Bluetooth® wireless technology device, press PLAY/PAUSE button on screen

NOTE: Use the iPod® cable that was supplied with your device.

*IF EQUIPPED *IF EQUIPPED

[†] If moisture appears on windshield, adjust **Temperature Control Knob** to a warmer temperature.