TELLURIDE

Car Multimedia System User's Manual



- I The functions and services described in this guide are subject to change without prior notice for performance improvement. If the system software is updated, the screenshots in this guide may appear different than the actual images on the system.
- The functions and services described in this guide may differ from those provided in your vehicle. For precise information related to your vehicle, refer to the owner's manual or catalog of your vehicle.
- The design and specification of the system may change without prior notice for performance improvement.
- This multimedia system contains open source software, including without limitation, software distributed and/ or modified under the GNU General Public license, Version 2, June 1991, and the GNU lesser General Public License, Version 2.1, February 1999.

For additional information and to obtain related materials including without limitation, the previous referred to licenses and software, please contact us at MOBIS OSSrequest@mobis.co.kr

Available information for users



Car Multimedia System User's Manual

This guide introduces your system's functions and explains how to use them. To use your system correctly and safely, read this guide before using the system.



Car Multimedia System Quick Reference Guide

This guide combines key information into a quick reference. Use this guide to refer to descriptions and instructions more quickly and easily.



Ouick Guide

This guide is the help built into the system. You can access basic information on how to control the system and a brief description of major functions directly on the system screen.

 How to access the guide: On the Home screen, touch All Menus > Quick Guide.

For safety, this quick guide will not be displayed while the vehicle is moving. Park your vehicle in a safe location before accessing the quick guide.

Symbols used in this guide



Warning

Indicates important information related to user safety. Failure to follow warnings may result in death or serious personal injury.



Caution

Indicates important information related to user safety. Failure to follow cautions may result in personal injury, or damage or malfunction your vehicle.



Note

Indicates helpful information for convenient use.

*if equipped

Indicates descriptions for optional features.

This guide covers all specifications, including all trim models and optional specifications. It may include descriptions for features that are not equipped in your vehicle.

Safety warnings

For safety, follow the instructions below. Failure to do so may increase the risk of a traffic accident, which may result in death or personal injury.



About driving

Do not operate the system while driving.

· Driving while distracted may result in a loss of vehicle control, potentially leading to an accident, severe personal injury, or death. The driver's primary responsibility is the safe and legal operation of a vehicle, and any handheld devices, equipment, or vehicle systems which divert the driver's attention from this responsibility should never be used during operation of the vehicle.

Avoid watching the screen while driving.

- · Driving while distracted may lead to a traffic accident.
- · Stop your vehicle in a safe location before using functions that require multiple operations.

Stop your vehicle first before using your mobile phone.

• Using a mobile phone while driving may lead to a traffic accident.

Keep the volume low enough to hear external sounds.

- · Driving without the ability to hear external sounds may lead to a traffic accident.
- Listening to a loud volume for a long time may cause hearing damage.

About handling the system

Do not disassemble or modify the system.

· Doing so may result in an accident, fire, or electric shock.

Do not allow liquids or foreign substances to enter the system.

· Liquids or foreign substances may cause noxious fumes, a fire, or a system malfunction.

Stop using the system if it malfunctions, such as no audio output or display.

· If you continue using the system when it is malfunctioning, it may lead to a fire, electric shock, or system failure.



If you experience any problems with the system, contact your place of purchase or dealer.

Safety cautions

For safety, follow the instructions below. Failure to do so may result in personal injury or damage to the system.



About operating the system

Use the system with the engine running.

• Using the system for a long time when the engine is stopped may discharge the battery.

Do not install unapproved products.

- · Using unapproved products may cause an error while using the system.
- · System errors caused by installing unapproved products are not covered under the warranty.

About handling the system

Do not apply excessive force to the system.

· Excessive pressure on the screen may damage the LCD panel or the touch panel.

When cleaning the screen or button panel, make sure to stop the engine and use a soft, dry cloth.

• Wiping the screen or buttons with a rough cloth or using solvents (alcohol, benzene, paint thinner, etc.) may scratch or chemically damage the surface.

If you attach a liquid-type air freshener to the fan louver, the surface of the louver may become deformed due to the flowing air.




Note

If you experience any problems with the system, contact your place of purchase or dealer.

Contents

System over	/iew	Ra Ra	dio
Component names and functions	1-2	Turning on the radio	3-2
Turning the system on or off	1-5	Changing the radio mode	3-2
Controlling the touch screen	1-6	Scanning for available radio stations	3-3
Getting to know the Home screen	1-8	Searching for radio stations	3-3
Getting to know the driving assistance screen Rear view screen (common)	1-8 1-8	Saving radio stations Listening to saved radio stations	3-4 3-4 3-4
Steering-interactive camera Surround view monitor (*if equippe	1-10 d)1-10	Coarshing for Cirius VM radio shannels	
Using the rear seat climate control system (*if equipped)	1-12	numbers Viewing the program schedule Listening to Featured Favorites	3-6 3-6
2 Useful feat	ures	channels	3-7
Setting up My Menu	2-2	4 Media pla	yer
Editing My Menu	2-2		-
Using the quiet mode	2-2	Using the media player Controlling the media player	4-2 4-3
Using Voice Memo	2-3	Using the USB mode	4-3 4-4
Using phone projection	2-4	Listening to music	
C .: 'DI ' A I		LISTELLING TO LINGSIC	4-4
Connecting your iPhone via Apple CarPlay Connecting your Android smartpho		Using the iPod mode	4-4 4-6
CarPlay	- '	•	4-6

Using a Bluetooth audio device	5-5	8	Settings
Using a Bluetooth phone	5-6		3
Making a call	5-7	Setting the vehicle enviro	
Answering calls	5-10	equipped)	8-2
Using options during a call	5-11	Setting sounds	8-2
Setting up your favorites list	5-12	Setting the system sound	d 8-2
		Setting the system screen	n 8-3
C	• , •	Setting the Home screen	8-4
6 Voice recogn	nition	Setting the screen saver	8-4
Starting voice recognition	6-2	Setting voice recognition	8-5
Adjusting the voice guidance volu	me 6-4	Setting Bluetooth	8-5
Viewing the voice recognition hel	р 6-4	Setting the system enviro	nments 8-6
Available voice commands	6-6	Setting the system langu	
Call commands	6-6	Setting the time and date	e 8-6
Radio commands	6-7	Setting the keyboard	8-6
Media commands	6-7	Setting advanced options	
UVO commands	6-8	Viewing system informat	ion 8-7
Other commands	6-8		
Using Siri Eyes Free	6-9		
		9 Troub	leshooting
7	UVO	Solutions	9-2
/	000	Sound and display	9-2
UVO services	7-2	USB playback	9-3
Activating the service	7-2	iPod/iPhone playback Bluetooth connection	9-2 9-5
Service limitations	7-3	Phone projection	9-5
Locating the UVO buttons	7-4	System operation	9-7
Using the UVO menu	7-4		
Viewing driving information	7-5		
Contacting roadside assistance	7-6	10	Appendix
Diagnosing your vehicle	7-6	10	препал
Contacting the UVO Center	7-7	System status icons	10-2
Using 911 Connect	7-8	FAQ	10-3
		System specifications	10-7
		Important information	10-13
		Index	10-14
		IIIGCA	10 1-



System overview

Component names and functions

Turning the system on or off

Controlling the touch screen


Getting to know the Home screen

Getting to know the driving assistance screen

Using the rear seat climate control system (*if equipped)



Component names and functions



Note: Depending on vehicle models and specifications, the illustration above may differ from the product's actual appearance and layout.



6 HOME button

• Press to access the Home screen.

? PHONE button

- Press to start connecting a mobile phone via Bluetooth.
- After a Bluetooth phone connection is made, press to access your call history.

8 Custom button (☆)

- Press to use a custom function.
- Press and hold to access the settings screen for the custom button.


SETUP button

• Press to access the settings screen.

Tune knob/File knob

- While listening to the radio, turn to adjust the frequency or change the channel.
- While playing media, turn to search for a track/file (except for the Bluetooth audio mode).
- During a search, press to select the current track/file.

Note: Depending on vehicle models and specifications, the illustration above may differ from the product's actual appearance and layout.



1 Voice recognition button ((6))

- Press to start voice recognition. Press and hold to end voice recognition.
- If the system does not support voice recognition, press to start or end voice recognition of a connected smartphone via phone projection. (The button's operation may vary depending on smartphone specifications.)

MODE button

- Press to switch between AV (radio/media) modes.
- · Press and hold to turn AV (radio/media) on or off.

③ Volume lever (+/-)/Mute button (火)

- Push up or down to adjust the volume.
- Press to mute or unmute the system.
- While playing media, press to pause or resume playback (except for the iPod mode).

④ Up/Down lever (∧/∨)

- While using an AV function, change the station/track/file.
- While listening to the radio, push and hold to search for a station.
- While playing media, push and hold to rewind or fast forward (except for the Bluetooth audio mode).

6 Call/Answer button (**(**

- Press to start connecting a mobile phone via Bluetooth.
- After a Bluetooth phone connection is made, press to access your call history. Press
 and hold to dial the most recent phone number. When a call comes in, press to answer
 the call.
- During a call, press to switch between the active call and the held call. Press and hold to switch the call between the system and the mobile phone.

6 Call end button (**△**)


Note: Depending on vehicle models and specifications, the illustration above may differ from the product's actual appearance and layout.

Turning the system on or off

- 1 To turn on the system, start the engine.
- 2 When the safety warning appears, read it and touch **Confirm**.
 - To change the system language, touch **Language**.



 If you do not want to use the system while driving, you can turn off the screen and the sound by pressing and holding the [O] button on the control panel. To use the system again, press the O] button.



The system turns off when you stop the engine (ACC Off).

 When you turn back on the system, the previous mode and settings will remain intact.

M Warning

- Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe bodily injury, or death. The driver's primary responsibility is the safe and legal operation of the vehicle, and the use of any vehicle systems, including the touch screen and steering wheel controls, which take the driver's eyes, attention, and focus away from the safe operation of the vehicle, or which are not permissible by law, should never be used during the operation of the vehicle.
- Some functions may be disabled for safety reasons while the vehicle is moving. They work only when the vehicle stops. Park your vehicle in a safe location before using any of them.
- Stop using the system if it malfunctions, such as no audio output or display. If you continue using the system when it is malfunctioning, it may lead to a fire, electric shock, or system failure.

Caution

- · You can turn on the system when the key ignition switch is placed in the "ACC" or "ON" position. Using the system for an extended period without the engine running drains the battery. If you plan on using the system for a long time, start the engine.
- If you turn on your system without starting the engine, a battery warning will appear. Once the engine starts, the battery warning will disappear.





Note

To avoid having audio play at an excessive volume when you start the engine, adjust the volume level before stopping the engine. You can also set the system to decrease the volume level automatically. On the Home screen, touch All Menus ▶ **Setup** ► **Sound** ► **Priority** and activate the Start-up Volume Limit option.

Controlling the touch screen

Your system is equipped with a touch screen. You can perform various functions via touch inputs.



Warning

Do not use the touch screen while driving as this will divert your attention away from the safe operation of the vehicle. You may lose your steering control which could cause an accident and severe bodily injuries.




- Do not apply excessive pressure to the touch screen or touch it with a pointed object. Doing so may damage the touch screen.
- Do not let any electrically conductive material contact the touch screen. A shock from static electricity may cause the system or the touch screen to malfunction.



If you wear regular gloves, you will not be able to control the touch screen. Remove your gloves or wear gloves designed for use with a touch screen.


Touch

Touch an object lightly and lift your finger. You can perform a function or select an option.




Touch and hold

Touch an object and hold it for at least one second without lifting your finger. You can rewind or fast forward media by touching and holding an appropriate button.




Drag

Touch and hold an object, drag it, and then drop it on a new location. You can move the selected object to another location or skip ahead or replay part of a song.



Swipe

Swipe the screen lightly in an appropriate direction. This is an easy way to scroll through a menu or list quickly.



Getting to know the Home screen

From the Home screen, you can access various functions.



- Current time and date
- 2 System status icons ► See p.10-2 "System status icons."
- 3 AV information. Touch to activate the corresponding AV mode in full screen.
- 4 Connection information. The connection status and function icons are displayed.
- 6 Access the All Menus screen.
- 6 Access the My Menu screen. ▶ See p.2-2 "Setting up My Menu."
- Run applications and view the quick quide.
- **8** Access the settings screen.



To move to the Home screen from another screen, touch 🏠.

Getting to know the driving assistance screen

You can view the outside of your vehicle on the system screen. Depending on vehicle models, the screens displayed in this section may differ from the actual screen.




Caution

The distance shown in the rear view screen may differ from the actual distance. For safety, be sure to visually check the rear, left, and right sides of your vehicle.

Rear view screen (common)

When you shift to "R" (Reverse) while the engine is running, the system screen will automatically display the rear view and the parking guides.



- Driving direction lines (yellow) ① ②
 These lines show the directions of the vehicle according to the steering angle.
- Neutral direction lines (blue)
 These lines indicate your vehicle's expected path with the steering wheel in the neutral position. It can help you determine whether the vehicle is in the correct position in a parking space and prevent you from parking too close to the next vehicle
- Crash warning lines (red) 4
 These lines are to help prevent a collision.

Warning


When backing up, make sure to follow the guidelines below:


- Before entering your vehicle, always check the area behind your vehicle.
- Do not solely rely on the rear view camera when backing up. Always ensure that it is safe to back up by checking behind you and looking in the rearview mirrors.
- Always back up slowly and stop immediately if you suspect that a person, especially a child, might be behind you.



Note

- The rear view screen remains active even if you shift to any position other than "R" (Reverse) after backing up. However, the parking guides do not appear on the screen. When you shift to "P" (Park) or drive at a predetermined speed or faster, the rear view screen will be deactivated and the system will display the previous screen automatically.
- You can change the operation setting for the rear view camera. On the Home screen, touch All Menus ➤ Setup
 Advanced ➤ Rear Camera (*if equipped).
- The parking guides show your vehicle's path according to the steering angle.





If an object comes too close to your vehicle as you are parking the vehicle, a warning beep will sound. To prevent an accident that might result if you do not hear the beep, you can set the system to decrease the volume level of any media playing automatically when you are parking the vehicle. On the Home screen, touch All Menus ➤ Setup ➤ Sound ➤ Priority ➤ Proximity Warning.

Steering-interactive camera

I Checking the rear top view

With the rear top view feature, you can look down at what is behind you.

On the rear view screen, touch [].





- These lines indicate the space necessary to open the tailgate of your vehicle. It can help you see if there is enough space to open the tailgate after parking and if there is any obstacle to opening it.
- 2 This line represents an extension of your vehicle's center. It shows the path of your vehicle's center according to the steering angle.

Surround view monitor (*if equipped)

The surround view monitor feature enables you to view the surroundings of your vehicle by using multiple cameras installed in the vehicle.

Checking your surroundings while driving

Press the [;;] button.

- The front view with the surround view is displayed on the screen.
- The feature is activated only in the following conditions:
 - When you are driving at 9 mph or less in "D" (Drive)
 - When you stop in "D" (Drive) or "N" (Neutral)

Touch one of the icons at the bottom of the screen to check the corresponding direction.

Icon	Description
1	Check the front view and the surround view.
	Check the front view in full screen.
1	Check the front view and front- left view.
	Check the front view and front- right view.
(3)	Change the surround view screen settings.

To deactivate the surround view screen, press the [button.



Note

If an open door or tailgate or a folded outside rearview mirror is detected while the surround view monitor is active, an alert icon will appear on the left side of the screen.

Checking your surroundings while backing up

When you shift to "R" (Reverse), the rear view will appear on the screen automatically.

Touch one of the icons at the bottom of the screen to check the corresponding direction.

Icon	Description
(2)	Check the rear view and the surround view.
3	Check the rear view in full screen.
	Check the rear view and rear- left view.
	Check the rear view and rearright view.
	Check the rear top view. ▶ See p.1-11 "Checking the rear top view."

Icon Description



Change the surround view screen settings.




Note

If you shift to "P" (Park), the surround view monitor will not work.

I Checking the rear top view

On the surround view screen, touch a to look down at what is behind you.



- 1 These lines indicate the space necessary to open the tailgate of your vehicle. It can help you see if there is enough space to open the tailgate after parking and if there is any obstacle to opening it.
- 2 This line represents an extension of your vehicle's center. It shows the path of your vehicle's center according to the steering angle.

Setting the surround view screen

To change the screen settings, touch on the surround view screen.

- **Display Guidelines**: Set to display the parking guides on the rear view screen.
- **F/R Proximity Warnings**: Set to receive a warning message when the surround view monitor detects an object close to the front or rear of your vehicle.
- Front View Mode: Select a default view to be displayed when you activate the surround view monitor while driving.
- Rear View Mode: Select a default view to be displayed when the surround view monitor is activated while backing up.

Using the rear seat climate control system

(*if equipped)

You can check the current status and control the rear seat climate control system via the system screen.

On your vehicle, press the [**REAR**] button.

 If the climate control system supports the AUTO mode, you will see the climate control screen shown below.



- Lock the climate control system. When this feature is activated, passengers in the rear seats are not able to operate the climate control system.
- **2** Adjust the interior temperature.
- **3** Adjust the air direction.
- 4 Adjust the air volume.
- **6** Activate or deactivate the AUTO mode.
- **1** Turn off the climate control system.

• If the climate control system does not support the AUTO mode, you will see the climate control screen shown below.






- For more information on how to use the climate control system, refer to the owner's manual of your vehicle.
- Depending on vehicle models or specifications, some functions may not be supported.



7 Useful features

Setting up My Menu
Using the quiet mode
Using Voice Memo
Using phone projection
Using SiriusXM™ data services



Setting up My Menu

Add your frequently used functions or favorites to My Menu to access them quickly from the Home screen. You can add up to 24 items to My Menu.

- 1 On the Home screen, touch **My** Menu ► Add to My Menu.
 - If you have already added items, on the My Menu screen, touch Menu ► Add.
- 2 Select items to add and touch Add ► Yes.

Editing My Menu

You can rearrange the items added to My Menu.

- 1 On the Home screen, touch My Menu ▶ Menu ▶ Rearrange.
- 2 Drag an item to a desired location

You can delete the items added to My Menu.

- 1 On the Home screen, touch My Menu ▶ Menu ▶ Delete.
- 2 Select items to delete and touch **Delete** ► Yes.

Marning

Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe bodily injury, or death. The driver's primary responsibility is the safe and legal operation of the vehicle, and the use of any vehicle systems, including the touch screen and steering wheel controls, which take the driver's eyes, attention, and focus away from the safe operation of the vehicle, or which are not permissible by law, should never be used during the operation of the vehicle.

Using the guiet mode

You can control the system volume in the rear seats for sleeping or resting.

On the Home screen, touch All Menus ▶ Quiet Mode ▶ Quiet Mode

- The rear seat audio is muted. When the driver's seat audio volume is high, it is automatically reduced.
- To turn the rear seat volume back up, touch **Quiet Mode** again.

Using Voice Memo

You can record voice memos using the microphone installed in your vehicle and play voice memos on your system.

On the Home screen, touch All Menus ► Voice Memo.



- Display the options list.
 - · Delete: Delete voice memos.
 - Save to USB Device: Save voice memos to a USB storage device. This option is available only for USB storage devices formatted in FAT16/32 formats.
 - Storage Info: View information on the storage space used for your voice memos.
- 2 List of your voice memos. Touch a voice memo to play it.
- Record/Pause button
 - Touch to start recording.
 - Touch III to pause recording.

4 Stop button

- Touch to stop recording. The recorded memo is added to the voice memos list on the left of the screen.
- You can also press the [] button on the steering wheel.

⊳ Note

- · Voice memo recording mutes the function in operation or pauses media playback.
- · If you make or answer a call while recording a voice memo, the recording pauses. If an emergency call is connected, the recording will stop and the recorded voice memo will be saved automatically.

Using phone projection

Phone projection enables you to connect your Android smartphone or iPhone to your system and use their functions via the system. You can perform and control your smartphone applications by using the larger screen and enhance your use of the system.

A

Warning

Do not adjust or set up any phone settings while driving. You may lose your steering control which could cause an accident and severe bodily injuries.

\triangle

Caution

- Use only applications that are compatible with phone projection.
 Using incompatible applications may cause problems for your system or smartphone.
- Only compatible applications will be displayed on the phone projection screen. You can also check compatible applications by visiting the following websites:
 - Apple CarPlay: https://www.apple. com/ios/carplay
 - Android Auto: https://www.android. com/auto

Connecting your iPhone via Apple CarPlay

Before using Apple CarPlay, be sure to check the following:

Apple CarPlay support on your iPhone


Visit the Apple homepage (https://www.apple.com/ios/carplay) and check the iPhone models that support Apple CarPlay.

Apple CarPlay activated or updated on your iPhone

On your iPhone, ensure that Apple CarPlay is activated. If your iPhone does not have the function, update the iPhone's operating system to the latest version.

Start Apple CarPlay by following the steps below:

1 On the Home screen, touch
All Menus ▶ Setup ▶ Phone
Projection ▶ Apple CarPlay ▶
Enable Apple CarPlay.



- 2 Connect your iPhone to the USB port in your vehicle via the cable supplied with the iPhone.
 - If you are connecting the device for phone projection for the first time, read the message on the notification pop-up window and touch **OK**.

∴ Caution

Do not connect and disconnect a USB connector repeatedly in a short time. Doing so may cause an error in the device or a system malfunction.

- 3 If your iPhone is locked, unlock it and agree to use phone projection.
 - When the iPhone is recognized successfully, Apple CarPlay appears on the Home screen.

4 On the Home screen, touch **Apple CarPlay**.



- 5 Use your iPhone's functions, such as calling and messaging, on your system.
 - Touch an icon on the screen to run an application or perform a function.
 Touch the KIA icon (((ID))) to move to the Home screen of your system.
 - Press the [底] button on the steering wheel to start Siri.
 - Press the [MODE] button on the steering wheel to select and start a media player installed on your smartphone, in addition to the system's AV modes.
 - Press the [] button on the steering wheel to answer an incoming call.
- 6 To end Apple CarPlay, remove the USB cable from your system.



Note

- When a USB cable is connected to your system, you cannot change the phone projection settings.
- Depending on Apple's policies, applications or functions that are compatible with Apple CarPlay, such as navigation apps or media players, may change. To check compatible applications, visit the Apple homepage (https://www.apple.com/ios/carplay).
- To use phone projection in optimized environments, update your smartphone's operating system to the latest version.
- Depending on the connected device's hardware, firmware, and operating system versions, the recognition time may vary.
- Using phone projection may result in mobile communication charges.
- Depending on the network signal status, some functions may not work correctly.
- Avoid controlling your smartphone while phone projection is in use.
- While you are using Apple CarPlay, the following functions are unavailable:
 - Bluetooth
 - UVO calls
 - System's voice recognition (iPhone's voice recognition is available.)
 - USB and iPod modes
 - Searches using the tune/file knob
 - Android Auto

Connecting your Android smartphone via Android Auto

Before using Android Auto, be sure to check the following:

Android Auto support on your smartphone


Visit the Google homepage (https://www.android.com/auto) and check the regions, device types, and models that support Android Auto.

Android Auto installed on your smartphone

Download and install the Android Auto application from Google Play. If you are in a region where Android Auto is not supported, you cannot install the application.

Start Android Auto by following the steps below:

1 On the Home screen, touch All Menus ► Setup ► Phone Projection ► Android Auto ► Enable Android Auto.



- 2 Connect your smartphone to the USB port in your vehicle via the cable supplied with the smartphone.
 - If you are connecting the device for phone projection for the first time, read the message on the notification pop-up window and touch **OK**.

↑ Caution

Do not connect and disconnect a USB connector repeatedly in a short time. Doing so may cause an error in the device or a system malfunction.

- 3 If your smartphone is locked, unlock it and agree to use phone projection.
 - When the smartphone is recognized successfully, Android Auto appears on the Home screen.
- 4 On the Home screen, touch **Android Auto**.
- 5 Use your smartphone's functions, such as calling and messaging, on your system.
 - Touch an icon on the screen to run an application or perform a function.
 - Press the [6] button on the steering wheel to start Google voice recognition.
 - Press the [MODE] button on the steering wheel to select and start a media player installed on your smartphone, in addition to the system's AV modes.
 - Press the [] button on the steering wheel to start using Bluetooth call functions.
- 6 To end Android Auto, remove the USB cable from your system.



Note

- · When a USB cable is connected to your system, you cannot change the phone projection settings.
- · Depending on Google's policies, the icons on the main screen of Android Auto may change.
- Depending on Google's policies, applications or functions that are compatible with Android Auto may change. To check compatible applications, visit the Android homepage (https://www.android.com/ auto).
- To use phone projection in optimized environments, update your smartphone's operating system to the latest version.
- Depending on the connected device's hardware, firmware, and operating system versions, the recognition time may vary.
- Using phone projection may result in mobile communication charges.
- Depending on the network signal status, some functions may not work correctly.
- · Avoid controlling your smartphone while phone projection is in use.
- While you are using Android Auto, the following functions are unavailable:
 - Bluetooth audio
 - UVO calls
 - System's voice recognition (smartphone's voice recognition is available.)
 - USB and iPod modes
 - Searches using the tune/file knob
 - Apple CarPlay

Using SiriusXM™ data services

You can access an array of information with SiriusXM data services.



SiriusXM is a paid satellite radio service.

On the Home screen, touch All Menus ► SiriusXM Data.



- View weather information. ► See p.2-9 "Viewing weather information."
- 2 View sports information. ► See p.2-11 "Viewing sports information."
- 3 Stay on top of current stock values and trends in the stock market. ▶ See p.2-10 "Viewing stock information."
- 4 View fuel price information and search for a nearby service station. ▶ See p.2-9 "Viewing fuel price information."
- **5** See what is playing now and search for a nearby theater. ► See p.2-12 "Viewing the latest movie information."

Viewing weather information

- On the Home screen, touch All Menus ➤ SiriusXM Data.
- 2 Touch Weather.
- 3 View today's weather information in your city.
 - To view weather forecasts for today and the next four days, touch 5 Days.
 - To view weather information of another area, touch **Other City**.
 - To view warnings and advisories for adverse weather conditions, such as tornadoes, tropical storms, and blizzards, touch Warnings and Advisories.



Viewing fuel price information

- 1 On the Home screen, touch All Menus ► SiriusXM Data.
- 2 Touch Fuel Prices ➤ Nearby Stations.



- 3 Search for nearby gas stations and check or compare fuel prices.
 - To sort the search results, touch the option menu (▼) and select a sorting option.
 - To set a service station as one of your favorites, touch ☆.





Note

To access your list of favorite gas stations, touch **Favorite Stations** on the main screen.

Setting a filter for searching for gas stations

- On the Home screen, touch All Menus ➤ SiriusXM Data.
- 7 Touch Fuel Prices ➤ Filters.
- 3 Select the type of fuel your vehicle uses and your favorite brands.

Viewing stock information

- On the Home screen, touch All Menus ➤ SiriusXM Data.
- 7 Touch Stocks ► Add.
- 3 Search for your favorite stock by entering a stock symbol in the search bar and then touch to add it to the list.
 - Repeat this step to add more stock symbols.



Now you can check information on your stock every day by touching **All Menus** ► **SiriusXM Data** ► **Stocks**.





Note

To delete a stock symbol from your favorites list, touch .

Viewing sports information

- 1 On the Home screen, touch All Menus ► SiriusXM Data.
- 2 Touch Sports.
- 3 Select the sport that interests you.
 - To set up a list of your favorite teams and check their daily results and schedules, touch My Teams.



4 View real-time scores and schedules for major events and games.

Creating a list of your favorite teams

- 1 On the Home screen, touch All Menus ► SiriusXM Data.
- 2 Touch **Sports** ▶ **My Teams** ▶ Add.
- **3** Search for your favorite team by entering its full name in the search bar and then touch 🟠 to add it to the list.
 - · Repeat this step to add more teams.



Now you can check your favorite team's scores and schedules every day.





To delete a team from your favorites list, touch 🏠.

Viewing the latest movie information

- On the Home screen, touch All Menus ➤ SiriusXM Data.
- 2 Touch Movies ► Top Movies.



- 3 View information about the latest movies.
 - To reorder the titles on the list, touch the option menu (▼) and select an option.
 - To view detailed information about a movie, touch .



Searching for nearby theaters

- On the Home screen, touch All Menus ➤ SiriusXM Data.
- 2 Touch Movies ► Nearby Theaters.
- 3 Search for nearby theaters and view their location information.
 - To sort the search results, touch the option menu (▼) and select a sorting option.
 - To set a theater as one of your favorites, touch ☆.



Creating a list of your favorite theaters

- 1 On the Home screen, touch All Menus ➤ SiriusXM Data.
- 2 Touch Movies ► Favorite
 Theaters ► Add.
- 3 Find your favorite theater from the list and touch ☆.
 - Repeat this step to add more theaters.





3 Radio

Turning on the radio

Changing the radio mode


Scanning for available radio stations

Searching for radio stations

Saving radio stations

Listening to saved radio stations

Listening to SiriusXM™ radio



Turning on the radio

On the Home screen, touch All Menus ► Radio.



- Display the options list.
 - · Station List: Access the list of available radio stations.
 - Delete Presets: Delete saved radio stations from the preset list.
 - Sound Settings: Customize the system sound settings. ▶ See p.8-2 "Setting the system sound."
- 2 Return to the previous level.
- Radio station information
- Preset list
- 6 Select a radio mode.
- 6 Set to display text information received from the current broadcasting station.
- Preview each radio station for five seconds and select the station you want.

Warning

Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe bodily injury, or death. The driver's primary responsibility is the safe and legal operation of the vehicle, and the use of any vehicle systems, including the touch screen and steering wheel controls, which take the driver's eyes, attention, and focus away from the safe operation of the vehicle, or which are not permissible by law, should never be used during the operation of the vehicle.

Changing the radio mode

On the radio screen, touch Band and select a desired mode.

• Alternatively, press the [RADIO] button on the control panel or the [MODE] button on the steering wheel. Each time you press the button, the radio mode switches to FM ▶ AM ▶ SiriusXM in order.



Scanning for available radio stations

You can listen to each radio station for a few seconds and select the one you want.

- 1 On the radio screen, touch **Scan**.
 - The system provides a preview of each radio station on the available stations list for five seconds.
- 2 When you find the radio station you want to listen to, touch **Scan** to stop the scan.
 - You can continue listening to the current radio station.

Searching for radio stations

To search for the previous or next available radio station, press the [TRACK] or [SEEK] button on the control panel.

- To select a radio station from the available stations list, touch Menu ► Station List on the radio screen.
- You can also press and hold the
 [> TRACK] or [> SEEK] button to
 search for frequencies quickly. When
 you release the button, the next
 available radio station is selected
 automatically.

Saving radio stations

You can save your favorite radio stations and listen to them by selecting them from the preset list.

On the radio screen, touch and hold an empty slot from the preset list.

 The radio station you are listening to will be added to the selected slot.





Note

- You can save up to 40 radio stations.
- If a station is already saved to the selected preset number, the station will be replaced by the station you are listening to.
- To delete saved radio stations from the preset list, touch Menu ➤ Delete Presets.

Listening to saved radio stations

Select one of the radio stations in the preset list.

 Alternatively, push the [^/V] lever on the steering wheel to change the radio station.

Listening to SiriusXM™ radio

You can listen to radio channels provided by SiriusXM, a satellite radio service. Various kinds of channels, such as music, sports, and news, are available via streaming or live broadcast.

On the radio screen, touch **Band SiriusXM**.



- Access the list of available SiriusXM radio channels.
- ② Display the options list.
 - Delete Presets: Delete saved radio stations from the preset list.
 - · What is on My Presets?: View broadcast schedule.
 - Featured Favorites: Listen to groups of channels provided by SiriusXM.
 - Sound Settings: Customize the system sound settings. ▶ See p.8-2 "Setting the system sound."
- 3 Return to the previous level.
- Switch to the live broadcast mode. This button is activated only when a live broadcast is available on the selected channel.
- 6 Move to the previous segment. Touch and hold to rewind the broadcast by five second decrements
- O Pause or stop the broadcast.
- Move to the next segment. Touch and hold to fast forward the broadcast by five second increments.
- Weak reception indicator
- Ochange the radio mode.
- Select a channel by entering its channel number.
- Scan through all available SiriusXM radio channels.



The **REC** icon will be shown next to the first 10 SiriusXM channels saved. Once preset channels are saved, broadcasts from these channels will be buffered automatically for your convenience each time you start your vehicle.

Searching for SiriusXM radio channels

You can select a channel from the available SiriusXM channels list.

- 1 On the radio screen, touch Band ► SiriusXM.
- 2 On the SiriusXM radio screen, touch Channel List.
- 3 Select a category and a channel.
 - To skip a channel when scanning with the [➤ TRACK] and [▲ SEEK] buttons or the tune knob, touch Skip.



Selecting channels by using channel numbers

If you know the exact channel number, you can enter it to select the channel directly.


- 1 On the radio screen, touch Band ► SiriusXM.
- 2 On the SiriusXM radio screen. touch **Direct Tune**.
- 3 Enter a channel number and touch OK.



Viewing the program schedule

You can view the program schedule and information for the channels stored in your preset list.

- 1 On the radio screen, touch Band ► SiriusXM.
- 2 On the SiriusXM radio screen, touch Menu ▶ What is on My Presets?
- 3 Set a date and time on the top line of the screen
 - To select a date, touch the date display field at the top left of the preset list and select a date and time zone.
 - To select a time, touch \triangleleft or \triangleright .



4 Select a channel and a program to view its detailed information.



Note


If there is hidden information, an arrow will appear next to the program. Touch the arrow to view the hidden information.

Listening to Featured Favorites channels

You can listen to Featured Favorites channels on SiriusXM radio. Multiple sets of channels can be broadcast and can be changed by SiriusXM.

- 1 On the radio screen, touch **Band** ▶ **SiriusXM**.
- 2 On the SiriusXM radio screen, touch Menu ► Featured Favorites.
- 3 Select a channel.





4

Media player


Using the media player
Using the USB mode
Using the iPod mode



Using the media player

You can play music stored in various media storage devices, such as USB storage devices, smartphones, and iPods.

- 1 Connect a device to the USB. port in your vehicle.
 - Playback may start immediately depending on the device that you connect to the system.



- 7 Touch the AV information area on the Home screen or press the [MEDIA] button on the control panel.
 - If you have multiple media storage devices, press the [MEDIA] button again and select a media mode from the media selection window.





Warning

Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe bodily injury, or death. The driver's primary responsibility is the safe and legal operation of the vehicle, and the use of any vehicle systems, including the touch screen and steering wheel controls, which take the driver's eyes, attention, and focus away from the safe operation of the vehicle, or which are not permissible by law, should never be used during the operation of the vehicle.



Note

- · When you connect an Apple device, playback does not start automatically and the AV information area remains in the previous mode. You cannot touch the AV information area to start playback. To start the media player in the iPod mode, press the [MEDIA] button on the control panel.
- You can also change the mode by pressing the [MODE] button repeatedly on the steering wheel.
- Depending on vehicle models and specifications, available buttons or the appearance and layout of the USB port in your vehicle may vary.

Controlling the media player

Use the buttons at the bottom of the playback screen to control the media player.



Pausing/Resuming playback

Touch \prod to pause playback. Touch \triangleright to resume playing your music.

Rewinding/Fast forwarding

Touch and hold **【** or **】** to rewind or fast forward. Alternatively, press and hold the [**▼ TRACK**] or [**↑ SEEK**] button on the control panel.

 You can also push and hold the [^/>] lever on the steering wheel.

Restarting the current playback

After the song has played for 3 seconds, touch or press the **TRACK** button on the control panel to restart the current song.

 You can also push the [∧/∨] lever downward on the steering wheel.

Playing the previous or next song

To play the previous song, touch or press the **TRACK** button on the control panel within the first 3 seconds of the current song. To play the next song, touch or press the **SEEK** button on the control panel.

 You can also use the [∧/∨] lever on the steering wheel.



Note ■

- If more than 3 seconds of playback have elapsed, touch twice or press the TRACK button on the control panel twice to play the previous song.
- On the control panel, turn the file knob to find the desired song and press the knob within five seconds to play the file.
- If no control is detected within five seconds, the search is canceled and the screen displays information about the song currently playing.

Playing repeatedly

Touch **Repeat** to play a file on repeat. The repeat play mode changes each time you touch it. The corresponding mode icon will be displayed on the screen. Depending on the current media or playlist, available repeat play modes may vary.

Playing in random order

Touch **Shuffle** to shuffle an album or playlist. The shuffle play mode is activated or deactivated each time you touch it. When you activate the shuffle mode, the corresponding mode icon will be displayed on the screen. Depending on the current media or playlist, available shuffle play modes may vary.



Note

For specific descriptions of each media mode, refer to the corresponding section. The description on the Bluetooth audio mode is included in the "Bluetooth" chapter.

Using the USB mode

You can play media files stored in portable devices, such as USB storage devices and MP3 players. Check compatible USB storage devices and file specifications before using the USB mode. ▶ See p.10-7 "USB mode."

Listening to music

- 1 Connect your USB device to the USB port in the vehicle.
- 2 Touch the AV information area on the Home screen or press the [MEDIA] button on the control panel.
 - The media player is displayed in full screen.
 - If you have multiple media storage devices, press the [MEDIA] button again and touch USB Music from the media selection window.



- Access the files list.
- ② Display the options list.
 - Hide Current File: Delete the file that is playing currently from the system.
 - Sound Settings: Customize the system sound settings. ▶ See p.8-2 "Setting the system sound."
- 3 Return to the previous level.
- 4 Information about the song currently playing
- 6 Repeat play mode
- 6 Shuffle play mode
- Number of files on the current playlist
- 8 Playback time and playback position



Only USB storage devices formatted in FAT16/32 formats support deleting files. You can find the deleted files in the "Hidden_" folder.

Caution

- · Start the engine of your vehicle before connecting a USB device to your system. Starting the engine with a USB device connected to the system may damage the USB device.
- Be careful of static electricity when connecting or disconnecting a USB device. A static discharge may cause a system malfunction.
- · Be careful not to let your body or external objects contact the USB port. Doing so may cause an accident or a system malfunction.

- Do not connect and disconnect a USB connector repeatedly in a short time. Doing so may cause an error in the device or a system malfunction.
- Do not use a USB device for purposes other than playing files. Using USB accessories for charging or heating may cause poor performance or a system malfunction.



- · When connecting a USB storage device, do not use an extension cable. Connect it directly to the USB port. If you use a USB hub or an extension cable, the device may not be recognized.
- · Fully insert a USB connector into the USB port. Failure to do so may cause a communication error.
- · When you disconnect a USB device, a distorted noise may occur.
- The system can play only files encoded in a standard format.
- The following types of USB devices may not be recognized or work correctly:
 - Encrypted MP3 players
 - USB devices not recognized as removable disks
- · A USB device may not be recognized depending on its condition.
- Some USB devices may be incompatible with your system.
- Depending on the USB device's type, capacity, or the format of files, USB recognition time may be longer.
- Depending on the specification, some USB devices may not support charging via a USB connection.

Searching for music files on a file list

Access a file list to search for and select a song.

- On the music playback screen, touch **List**.
- 2 Touch the screen to open a folder, move to another category, or play a music file.



- 1 Display the options list.
 - Now Playing: Return to the currently playing file if it is not visible on the current screen.
- Return to the previous level.
- **3** Move up to another folder/category.
- Search for a song based on categories.
- Scroll bar

Using the iPod mode

You can listen to music stored on your Apple devices, such as an iPod or an iPhone. Check compatible Apple devices and iOS specifications before using the iPod mode. ▶ See p.10-9 "iPod mode."

- Connect your Apple device to the USB port in your vehicle using the cable supplied with the Apple device.
 - When connected, the device will begin charging. Music playback will not start automatically.
- 2 On the control panel, press the [MEDIA] button.
 - If you have multiple media storage devices, press the [MEDIA] button again and touch iPod from the media selection window.



- Access the files list.
- 2 Display the options list.
 - Sound Settings: Customize the system sound settings. ► See p.8-2 "Setting the system sound."

- 3 Return to the previous level.
- Information about the song currently playing
- 6 Repeat play mode
- 6 Shuffle play mode
- Number of files on the current playlist
- Playback time and playback position

Do not connect and disconnect a USB connector repeatedly in a short time. Doing so may cause an error in the device or a system malfunction.

Searching for music files on a file list

Access a file list to search for and select a song.

 On the music playback screen, touch **List**. 2 Touch the screen to move to another category or play a music file.



- Return to the previous level.
- 2 Move up to another category.
- Search for a song based on categories.
- 4 Scroll bar

Notes on connecting Apple devices

- Ensure that the iOS and firmware of your device is up-to-date before connecting it to your system.
 Outdated devices may cause a system error.
- If your device's battery is low, the device may not be recognized. Check the battery level and, if necessary, charge the battery before connecting the device to your system.
- Use an Apple-approved cable. Using an unapproved cable may cause a distorted noise or an error during playback.

- Fully insert a USB connector into the USB port. Failure to do so may cause a communication error.
- If you connect your device to the system while playback is in progress on the device, you may hear a high pitch sound just after the connection. Connect the device after stopping or pausing playback.
- Connecting your device during a download or synchronizing with iTunes may cause an error. Connect the device after the download or synchronization is complete.
- If you connect an iPod nano (except for the 6th generation) or an iPod classic, the brand logo will be displayed on the device screen. For an iPhone and an iPod touch, the logo will not be displayed.


Notes on playing Apple devices

- Depending on the model, your device may not be recognized due to unsupported communication protocols.
- The order of the songs displayed or played on the system may differ from the order of the songs stored in your device.
- Podcasts and audiobooks will play on your system if the dedicated applications are not installed on your Apple device. You can access those files in the **Other** category.

- Podcasts and audiobooks may not play or may not be displayed on your system if your Apple device has iOS 6.0 or later installed.
- In an iPhone, the audio streaming function and iPod mode control may conflict. If an error occurs, disconnect and reconnect the USB cable.
- When using an iPhone or an iPod touch, do not control the device while it is connected to your system. An error may occur.
- If you make or receive a call during playback via an iPhone, the music may remain paused after you end the call. If you do not hear the music after ending a call, check the device to see if the music is paused.
- Do not duplicate a song in multiple folders. One song saved in multiple folders may cause an error with search and playback functions.
- If you perform a media control function, such as stop or repeat, just before a song ends, the song information displayed on the screen may not match the song currently playing. This is not a system error. Restart the iPod mode on the system or pause and resume playback on your device.

Bluetooth

Connecting Bluetooth devices
Using a Bluetooth audio device
Using a Bluetooth phone



Connecting Bluetooth devices

Bluetooth is a short-range wireless networking technology. Via Bluetooth, you can connect nearby mobile devices wirelessly to send and receive data between connected devices. This enables you to use your devices effectively.

To use Bluetooth, you must first connect a Bluetooth-enabled device to your system, such as a mobile phone or an MP3 player. Ensure that the device you want to connect supports Bluetooth.

Warning

Park your vehicle in a safe location before connecting Bluetooth devices. Distracted driving can cause a traffic accident and lead to personal injury or death.



- On your system, you can use only Bluetooth Handsfree and Audio features. Connect a mobile device that supports the Bluetooth Handsfree or Audio feature.
- · For more information on Bluetoothenabled devices and their functional compatibility, visit the KIA Motors America website (https://www.kia.com).

Pairing devices with your system

For Bluetooth connections, first pair your device with your system to add it to the system's list of Bluetooth devices. You can register up to five devices.

- 1 On the Home screen, touch **All** Menus ▶ Setup ▶ Bluetooth ▶ Bluetooth Connection ▶ Add New
 - If you are pairing a device with your system for the first time, you can also press the [] button on the steering wheel. Alternatively, on the Home screen, touch All Menus ▶ Phone.
- 2 On the Bluetooth device you want to connect, activate Bluetooth, search for your vehicle's system, and then select it.
 - Check the system's Bluetooth name, which is displayed in the new registration pop-up window on the system screen.



- 3 Ensure that the Bluetooth passkeys displayed on the Bluetooth device screen and the system screen are the same and confirm the connection from the device.
- 4 Choose whether or not to connect the Bluetooth device to your system prior to other devices.
 - If you grant priority to the Bluetooth device, it will be connected automatically to the system when you turn on the system.
- 5 If you are connecting a mobile phone, permit the system to access and download your data from the device.
 - Downloading data is only for Bluetooth call functions. Permission is not required if you are connecting an audio device.



Note

- It may take a while for the system to connect with the device after you permit the system to access the device. When a connection is made, the Bluetooth status icon appears at the top of the screen.
- You can change the permission settings via the mobile phone's Bluetooth settings menu. For more information, refer to your mobile phone's user guide.
- To register a new device, repeat steps 1 to 5.
- When a device is connected to the system via Bluetooth, you cannot pair another device.
- If you do not want the system to connect with the device automatically, deactivate Bluetooth on your device.

Connecting a paired device

To use a Bluetooth device on your system, connect the paired device to the system. Your system can connect with only one device at a time.

- On the Home screen, touch All
 Menus ➤ Setup ➤ Bluetooth
 ▶ Bluetooth Connection.
- 2 Touch Connect next to the device you want to connect.
 - If another device is already connected to your system, disconnect it. Touch **Disconnect** next to the device.



- View Bluetooth help.
- 2 Connect the device.
- Object the device.
- 4 Pair a new device with your system.
- Delete paired devices. Downloaded data from devices will also be deleted.



Note

- If a connection ends because a device is out of the connection range or a device error occurs, the connection will be restored automatically when the device enters the connection range or when the error is cleared.
- If a connection is unstable due to a communication error, reset Bluetooth by touching All Menus ➤ Setup ➤ Bluetooth ➤ Default Factory Settings, and then re-connect the device.

Disconnecting a device

If you want to stop using a Bluetooth device or connect another device, disconnect your currently connected device.

- 1 On the Home screen, touch All
 Menus ➤ Setup ➤ Bluetooth
 ➤ Bluetooth Connection
- 2 Touch **Disconnect** next to the device.
- 3 Touch Yes.

Deleting paired devices

If you no longer want a Bluetooth device paired or if you want to connect a new device when the Bluetooth device list is full, delete paired devices.

- 1 On the Home screen, touch All Menus ➤ Setup ➤ Bluetooth
 ➤ Bluetooth Connection ➤ Delete Devices.
- 2 Select the devices you want to delete and touch **Delete**.
 - To delete all paired devices, touch Mark All ➤ Delete.
- 3 Touch Yes.

Using a Bluetooth audio device

You can listen to music stored in the connected Bluetooth audio device via your vehicle's speakers.

On the control panel, press the **[MEDIA]** button.

 If you have multiple media storage devices, press the [MEDIA] button again and touch Bluetooth Audio from the media selection window.



- Search for and connect another
 Bluetooth device.
- ② Display the options list.
 - **Change Device**: Search for and connect another Bluetooth device.
 - Sound Settings: Customize the system sound settings. ▶ See p.8-2 "Setting the system sound."
- 3 Return to the previous level.
- Information about the song currently playing

- 6 Repeat play mode
- 6 Shuffle play mode
- **7** Restart the current playback. Touch twice to play the previous file. You can also press the [**∨ TRACK**] button on the control panel or use the $\lceil \wedge / \vee \rceil$ lever on the steering wheel.
- Pause or resume playback.
- 9 Play the next file. You can also press the [SEEK] button on the control panel or use the $\lceil \wedge / \vee \rceil$ lever on the steering wheel.
- ① Change the repeat play mode.
- Activate or deactivate the shuffle play mode.



- · Depending on the connected Bluetooth device, mobile phone, or the music player you are using, playback controls may differ.
- · Depending on the music player you are using, streaming may not be supported.
- Depending on the connected Bluetooth device or mobile phone, some functions may not be supported.
- · If you connect a media device or mobile phone to your system via both Bluetooth and a USB cable, your system or device may not operate correctly. To use a Bluetooth connection, disconnect any cable connection to the device.

Using a Bluetooth phone

You can use Bluetooth to talk on the phone hands free. View call information on the system screen, and make or receive calls safely and conveniently via the vehicle's built-in microphone and speakers.

Warning

- · Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe bodily injury, or death. The driver's primary responsibility is the safe and legal operation of the vehicle, and the use of any vehicle systems, including the touch screen and steering wheel controls, which take the driver's eyes, attention, and focus away from the safe operation of the vehicle, or which are not permissible by law, should never be used during the operation of the vehicle.
- · Park your vehicle in a safe location before connecting any Bluetooth devices. Distracted driving can cause a traffic accident and lead to personal injury or death.
- Never dial a phone number or pick up your mobile phone while driving. Use of a mobile phone may distract your attention, making it difficult to recognize external conditions and reducing the ability to cope with unexpected situations, which may lead to an accident.


Making a call

If your mobile phone is connected to the system, you can make a call by selecting a name from your call history or contacts list. You can also enter a phone number on the keypad.

- On the Home screen, touch All Menus ➤ Phone.
 - Alternatively, press the [] button on the steering wheel.



2 If you have multiple paired mobile devices, select a mobile phone from your list of paired devices.



- 3 Select a phone number from your call history.
 - You can find the number you want by pushing the [^/~] lever on the steering wheel. You do not need to touch the screen.
 - To select a phone number from your contacts list, touch .



4 To end the call, press the [_] button on the steering wheel or touch **End** on the call screen.

Using your call history

- 1 On the Bluetooth phone screen, touch 6.
- 2 Select a call record from the list to make a call.



- Search for and connect another Bluetooth device.
- ② Display the options list.
 - Download: Download your call history.
 - Privacy Mode: Activate the privacy mode to protect your personal information. In the privacy mode, personal data will not be displayed.
 - Change Device: Search for and connect another Bluetooth device.
- O View all call records.
- 4 View only dialed calls.
- 6 View only received calls.
- **6** View only missed calls.



Note

- Some mobile phones may not support the download function.
- Up to 50 call records will be downloaded per individual list.
- Call durations do not appear on the system screen.
- Permission is required to download your call history from the mobile phone. When you attempt to download data, you may need to permit the download on the mobile phone. If the download fails, check the mobile phone screen for any notification or the mobile phone's permission setting.
- When you download your call history, any old data will be deleted.

Using the contacts list

- 1 On the Bluetooth phone screen, touch **.**
- 2 Select a contact from the list to make a call.



- Search for and connect another Bluetooth device.
- ② Display the options list.
 - · Download: Download your mobile phone contacts.
 - · Search: Enter a contact's name or phone number to search the list.
 - · Privacy Mode: Activate the privacy mode to protect your personal information. In the privacy mode, personal data will not be displayed.
 - Change Device: Search for and connect another Bluetooth device.
- Select an initial letter to find contacts quickly.



- Only contacts in the supported format can be downloaded and displayed from the Bluetooth device. Contacts from some applications will not be included.
- Up to 5,000 contacts can be downloaded from your device.
- Some mobile phones may not support the download function.
- Contacts stored both in the phone and in the SIM card are downloaded. With some mobile phones, contacts in the SIM card may not be downloaded.

- If you have set up speed dial numbers on the mobile phone, you can make a call by touching and holding a speed dial number on the keypad. Depending on the mobile phone type, the speed dialing function may not be supported.
- · Permission is required to download contacts from the mobile phone. When you attempt to download data, you may need to permit the download on the mobile phone. If the download fails, check the mobile phone screen for any notification or the mobile phone's permission setting.
- Depending on the mobile phone type or status, downloading may take longer.
- When you download your contacts, any old data will be deleted.
- You cannot edit or delete your contacts on the system.
- · When you connect a new mobile phone, your contacts downloaded from the previous mobile phone will not be displayed, but they will remain in your system until you delete the previous phone from the device list.

Using the keypad

- 1 On the Bluetooth phone screen, touch 圖.
- 2 Enter a phone number on the keypad and touch for to make a call.



- Search for and connect another
 Bluetooth device.
- ② Display the options list.
 - Privacy Mode: Activate the privacy mode to protect your personal information. In the privacy mode, personal data will not be displayed.
 - Change Device: Search for and connect another Bluetooth device.
- 3 Change the settings for Bluetooth connections.

Answering calls

When a call comes in, a notification popup window of the incoming call appears on the system screen.



To answer the call, touch **Accept**.

 Alternatively, press the [] button on the steering wheel.

To reject the call, touch **Reject**.

 Alternatively, press the [] button on the steering wheel.



Note

- Depending on the mobile phone type, call rejection may not be supported.
- Once your mobile phone is connected to the system, the call sound may be output through the vehicle's speakers even after you exit the vehicle if the phone is within the connection range.
 To end the connection, disconnect the device from the system or deactivate Bluetooth on the device.

Using options during a call

During a call, you will see the call screen shown below. Touch a button to perform the function you want.



- Turn off the microphone so the other party cannot hear you.
- 2 Adjust the microphone volume.
- Switch the call to your mobile phone. Depending on the mobile phone type, this function may not be supported.
- 4 End the call.
- **6** Display the keypad.



Note

- If the caller information is saved in your contacts list, the caller's name and phone number will be displayed. If the caller information is not saved in your contacts list, only the caller's phone number will be displayed.
- You cannot switch to any other screen, such as the AV screen or the settings screen, during a Bluetooth call.
- Depending on the mobile phone type, call quality may vary. On some phones, your voice may be less audible to the other party.
- Depending on the mobile phone type, the phone number may not be displayed.

Switching between calls

If your mobile phone supports call waiting, you can accept a second call. The first call is put on hold.

To switch between the active call and the held call, touch **Switch** or touch the phone number displayed on the call screen.





Note

Depending on the mobile phone type, this function may not be supported.

Setting up your favorites list

If you register frequently used phone numbers as your favorites, you can find them and dial them quickly.

- On the Home screen, touch All Menus ➤ Phone.
 - Alternatively, press the [] button on the steering wheel.
- 2 On the Bluetooth phone screen, touch ☆.



- 3 Touch Menu ► Edit and select a contact from your contacts list.
 - If you have not yet added any favorites, touch Add New.
- 4 Touch ☆ next to the phone number you want.
 - The star icon changes to orange and the phone number is added your favorites list.



Note

- You can register up to 10 favorites for each device.
- To delete one of your favorites, on the favorites list, touch **Menu** ▶ **Delete**.
- When you connect a new mobile phone, your favorites set for the previous mobile phone will not be displayed, but they will remain in your system until you delete the previous phone from the device list

6

Voice recognition

Starting voice recognition

Viewing the voice recognition help

Available voice commands

Using Siri Eyes Free



Before starting voice recognition

- The system can recognize only specified voice commands. ► See p.6-6 "Available voice commands" or the on-screen help of the voice recognition.
- To increase the recognition rate, keep in mind the following when saying a voice command:
 - Say a command naturally and clearly.
 - Say a command in the direction of the microphone, keeping your body straight in the driver's seat. The microphone is located in the overhead console lamp.
- Voice recognition will end automatically in the following situations:
 - When a call comes in or when you make a call
 - When you connect or remove a media storage device
 - When the front view or rear view camera turns on (*if equipped)
 - When you start another function by pressing a button, such as the [RADIO] or [MEDIA] button.
- Voice recognition will be affected by the ambient noise in the following situations:
 - When a window or the sun roof is open, causing a loud sound made by the wind
 - When the air conditioner or heater is set to a high air volume level (level 3 or lower is recommended)
 - While you are driving through a tunnel
 - When severe vibrations and noises occur while driving on a unpaved or uneven road
 - When severe noises occur due to heavy rain or a storm

Starting voice recognition

With voice recognition, you can use your system's functions without controlling the screen or buttons. This can help you maintain focus while driving and avoid any dangerous situations.

Use voice recognition to perform functions safely and conveniently.


On the steering wheel, press the [﴿] button. Voice recognition starts with a voice guidance.



- 1 Voice recognition status
 - **(**): Waiting for your command
 - ₵: Playing a voice guidance
 - : Processing your command
- Recognized command. The voice volume level is indicated as a bar graph while you are saying a command.
- 3 Primary voice commands you can use
- 4 End voice recognition.

Use voice recognition by following the steps below.

- 1 On the steering wheel, press the [6] button.
 - Voice recognition starts with a voice guidance.



- 2 After the voice guidance ends and you hear a beep, say a command. ► See p.6-6 "Available voice commands" or the on-screen help of the voice recognition.
 - The system displays the recognized command at the top of the screen and performs the corresponding function.
 - If an additional command is required for performing the function, available commands for the next step are displayed on the screen. Say or touch a command.

 When there are multiple commands similar to the recognized command, the system displays the numbered candidates on the screen. Say the number corresponding to the command you want.



- 3 To end voice recognition, say "Exit" while the system is waiting for your command.
 - Alternatively, press and hold the [%] button on the steering wheel or touch **Exit** on the voice recognition screen.




Note

- To skip a voice guidance, press the [6] button on the steering wheel.
- To extend the waiting time, press the [[4]] button while the system is waiting.

Adjusting the voice guidance volume

You can adjust the volume of the voice guidance to an appropriate level for using voice recognition while driving.

While you are using voice recognition, turn the volume knob on the control panel.



Viewing the voice recognition help

You can see how to perform various functions by voice commands.

\mathbb{A}

Caution

For safety, voice recognition help will not be displayed while the vehicle is moving. Park your vehicle in a safe location to view the on-screen help.


- 1 On the steering wheel, press the [4] button.
- 2 Touch **Help** on the voice recognition screen or say "Help" while the system is waiting for your command.



3 To view full help information on how to use voice commands, touch 2 at the bottom of the screen.



• To view help on how to use voice commands for a specific function, touch @? next to the function name vou want.



4 To close the help screen, touch **Exit** on the voice recognition screen or say "Exit" while the system is waiting for your command.



Note

- · To view a list of available voice commands for each function, say or touch a function name you want.
- · After accessing a list of voice commands, you can perform a function by saying or touching a command.
- · You can view a list of available voice commands without activating voice recognition. On the Home screen, touch All Menus ▶ Voice Commands.

Available voice commands

Call commands

Command	Function
Call	You can make a call to one of your mobile phone's contacts. Say a contact's name to begin a call.
Call <name></name>	The system dials the phone number of that contact. If the contact has multiple phone numbers, select a phone number.
Call <name> on Mobile</name>	The system dials the phone number saved as "Mobile" for that contact.
Call <name> at Work</name>	The system dials the phone number saved as "Work" for that contact.
Call <name> at Home</name>	The system dials the phone number saved as "Home" for that contact.
Call <name> on Other</name>	The system dials a phone number saved as other than "Mobile", "Work", or "Home" for that contact.

Command	Function
Dial Number	You can make a call. Say a phone number to begin a call.
Dial <phone #=""></phone>	You can make a call immediately to that phone number.
Redial	You can make a call to the most recent phone number.
Call History	The system displays your call history. Say a phone number on the call history to begin a call.
Change Bluetooth Device	You can search for and connect another Bluetooth device.



Note

To use call commands, your mobile phone must be connected to the system via Bluetooth and your contacts must be downloaded.

Radio commands

Command	Function
Radio	Turn on the most recent radio channel.
FM	Turn on the FM radio.
FM <87.5 to 107.9>	Turn on the FM radio with that frequency.
AM	Turn on the AM radio.
AM <530 to 1710>	Turn on the AM radio with that frequency.
SiriusXM	Turn on the SiriusXM radio.
SiriusXM <0 to 999>	Turn on the SiriusXM radio with that frequency.
Preset <1 to 40>*	Turn on one of the saved radio stations from the preset list.
Channel <0 to 999>*	Turn on the SiriusXM radio channel with that number.

^{*}These commands are available only when the radio is turned on.

Media commands

Command	Function
Music	Play music with the most recently used media player.
USB	Play music from the connected USB device.
iPod	Play music from the connected Apple device.
Bluetooth Audio	Play music from the connected Bluetooth audio device.
Pause*	Pause playback.
Play*	Resume playback.
Shuffle*	Activate the shuffle play mode.
Shuffle Off*	Cancel the shuffle play mode.
Repeat*	Activate the repeat play mode.
Repeat Off*	Cancel the repeat play mode.

^{*}These commands are available only when the media player is turned on.



Note

- · When you use a Bluetooth audio device, some commands may not be supported depending on the connected device.
- If you use a voice command when there is no related media or no playable file, the system will play a voice guidance explaining the situation.

UVO commands

Command	Function
Roadside Assist	The system calls the UVO Center. You can request vehicle towing and services.
Vehicle Diagnostics	You can check your vehicle's abnormal conditions and view the diagnosis result.
Virtual Assistant	The system calls the UVO Center. You can request help or make inquiries about using the UVO service.

Other commands

Command	Function
Help	Move to the help screen.
Line <1 to 4>*	Select an item with the designated number on a list. Simple numbers, such as "One" or "Two," can be recognized.
Yes*	Accept a notification asking for your confirmation in an exceptional situation.
No*	Deny a notification asking for your confirmation in an exceptional situation.
Next*	If there are more than five items on a list, scroll to the next page.
Previous*	If you scroll to the next page of a list, scroll back to the previous page.
Manual Input*	When using the Dial Number command, open the keypad to enter a phone number manually.
Go Back*	Return to the previous level.
Exit	End voice recognition.

^{*}These commands are available only in certain situations.

Using Siri Eyes Free

When you connect an Apple device that is compatible with Siri to your system via Bluetooth, you can use Siri Eyes Free. This allows you to perform the functions of your system and Apple device with voice commands so that you can devote your attention to driving.

First, ensure that your Apple device supports Siri and that you have activated Siri.

- 1 Connect your Apple device to your system via Bluetooth.
 - ► See p.5-2 "Connecting Bluetooth devices."
- 2 On the steering wheel, press and hold the [66] button.
- 3 On the Siri screen, touch Speak.




- 4 Say a command.
 - You can perform the functions related to Bluetooth calls on the system and other functions on your Apple device.
 - Press the [66] button to restart Siri.
- 5 To end Siri, press and hold the [ks] button.

Siri Eyes Free is enabled only while you are driving. When you shift to "P" (Park) or apply the parking brake, you disable this function.



Different Apple devices may have different functions enabled and may vary in how they respond to Siri commands, depending on the type of device and the iOS version.



7 UVO

UVO services
Activating the service
Locating the UVO buttons
Using the UVO menu
Using 911 Connect



UVO services

UVO provides connected car services, such as roadside assistance and emergency rescue, via the latest IT and communication technologies.

Once subscribed, you can access UVO services via the buttons on the overhead console lamp. You can also access other useful features using the UVO menu on your system.



Note

- You must be an active UVO subscriber or within the initial free trial period to receive UVO services.
- Depending on conditions, such as the vehicle type, the system type, or the subscribed service package, available services may vary.
- Some services may incur additional charges.
- Services may be modified, added, or deleted according to changes in the company's policies.

Activating the service

You must activate the service to use it on the system. An account with MyUVO. com is required to activate the service. If you do not have an account, create a new account to activate the service. If you already have an account, enter the verification code you received from MyUVO.com.

- 1 Park your vehicle in a safe location.
 - You cannot enter information for service activation while your vehicle is moving.
- On the Home screen, touch All Menus ➤ UVO ➤ UVO Settings
 ➤ Service Activation.
- 3 Enter your phone number or email address and touch **Submit**
 - If you have a registered account and your verification code, touch I already have a code.



- 4 Enter the verification code you received from MyUVO.com and touch Submit.
 - · Activation will begin. While the activation is in progress, the system buttons will be locked.

↑ Caution

Do not stop the engine while the activation is in progress. Doing so may cause a system malfunction.



- If the activation fails, contact the UVO Center at (844) UVO-9411.
- If your UVO service has expired, you can reactivate the service by renewing your subscription on MyUVO.com and entering your verification code again in the Service Activation menu.

Service limitations

Because the UVO service is provided via mobile networks, use of the service may be restricted depending on the mobile network status. Check the network signal icon () at the top line of the screen to see if the network signal strength is adequate.




Note

- It is recommended to use the service when the network signal icon has more than four signal bars.
- · Depending on the mobile network status, the use of the UVO service may be affected in the following places:
 - In a building or tunnel
 - In a mountain or dense forest
 - On a road close to cliffs
 - In an area with a lot of high buildings
 - On a highway or a road under an overpass
 - Out of a service area based on the mobile network service provider's coverage policy

Locating the UVO **buttons**

You can access the UVO services via the buttons on the overhead console lamp.



- Call the UVO Center.
- 2 Call for roadside assistance.



- · Depending on vehicle models and specifications, the illustration may differ from the product's actual appearance and layout.
- Use the [UVO] button to start the navigation application installed on your smartphone via phone projection.

Using the UVO menu

You can use the UVO service via the UVO menu on the system.

On the Home screen, touch All Menus ▶ UVO.



- 1 Call the UVO Center for vehicle towing and services. ▶ See p.7-6 "Contacting roadside assistance."
- 2 Check your vehicle's abnormal conditions and view the diagnosis result. ► See p.7-6 "Diagnosing your vehicle."
- 3 Call the UVO Center to request help or make inquiries about using the UVO service. ► See p.7-7 "Contacting the UVO Center."
- 4 Access the UVO service to use it on the system, activate the automatic 911 connection feature, or access modem information.

Marning

Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe bodily injury, or death. The driver's primary responsibility is the safe and legal operation of the vehicle, and the use of any vehicle systems, including the touch screen and steering wheel controls, which take the driver's eyes, attention, and focus away from the safe operation of the vehicle, or which are not permissible by law, should never be used during the operation of the vehicle.



Note

Use the UVO features on the system when your vehicle is stationary with the engine running.

Viewing driving information

You can see your driving patterns by checking information such as driving time, distance, idling time ratio, and speed distribution. Use driving information for safe and economical vehicle operation.

- On the Home screen, touch All Menus ➤ Driving Info.
- 2 View your vehicle's driving information.
 - To view the latest information, touch **Update**.



Contacting roadside assistance

When you encounter a disabled vehicle or another problem on the road, you can directly contact the UVO Center for roadside assistance and receive vehicle towing or services.

Touch All Menus ▶ UVO ▶ **Roadside Assist** or press the [\hat{\lambda}] button on the overhead console lamp.






Depending on the network status, this feature may not work correctly.

Diagnosing your vehicle

If you are curious about whether or not there is a problem with your vehicle, you can diagnose your vehicle. With the diagnosis result, you can also reserve a maintenance service.

- 1 Park your vehicle in a safe location.
 - · You can start a diagnosis only when the vehicle stops, because some components cannot be diagnosed while the vehicle is moving.
- 2 On the Home screen, touch All Menus ► UVO ► Vehicle Diagnostics.
 - A remote diagnosis will begin. Refrain from using your system until the diagnosis is complete and the result is displayed on the screen. If you move to another screen while a diagnosis is in progress, the diagnosis will be canceled.

3 Check the result displayed on the screen.



- Schedule a maintenance service from your preferred Kia dealership or the nearest one.
- 2 Call the UVO Center for roadside assistance.



Note

- A diagnosis result provided by this service is only an estimated result based on the signals from your vehicle. Visit a Kia Motors dealership for a detailed diagnosis.
- If a critical diagnostics issue is detected on your vehicle, an automatic diagnosis will start when a warning light comes on the instrument cluster. You will be notified of the diagnosis result.
- Your preferred dealership must be registered on MyUVO.com for you to schedule maintenance service with it.

Contacting the UVO Center

You can contact a UVO Center representative directly to request help or make inquiries about using the UVO service.

On the Home screen, touch

All Menus ► UVO ► Virtual

Assistant or press the [②] button
on the overhead console lamp.

- When connected to the UVO Center, ask a representative for the service you need.
- To end the call, touch **End** on the screen or press the [②] button.



Note

This feature is not available during a Bluetooth call.

Using 911 Connect

This feature provides you with immediate assistance when an accident occurs and an airbag is deployed.

First, activate the 911 Connect feature.

- On the Home screen, touch
 All Menus ➤ UVO ➤ UVO
 Settings.
- 2 Touch **911 Connect** to activate it.



- 3 Read the terms of use and touch **Agree**.
 - The feature will be activated and will appear at the top right of the screen.

If an airbag is deployed, the system will make a call to 911 and send your location to a 911 operator automatically.



Settings

Setting the vehicle environment (*if equipped)

Setting sounds

Setting the system screen


Setting the Home screen

Setting the screen saver

Setting voice recognition

Setting Bluetooth

Setting the system environments



Setting the vehicle environment (*if

equipped)

You can change the settings related to driving or the interior and exterior environment of your vehicle.

On the Home screen, touch All Menus ▶ Setup ▶ Vehicle.

Drive Mode

Drive Mode Change Alert: Set to display a notification when you change your vehicle's drive mode.

Heated/Ventilated Features

Set the steering wheel heater and the driver seat heater or ventilation to be controlled automatically.

The auto control mode will be deactivated if you operate the heater or ventilation controls manually. Selecting this option again or restarting the vehicle will reactivate the auto control mode.

Seat Position Change Alert

Set to show an alert when the driver's seat position is changed.



- · Any changes to the settings of the vehicle should be done while the vehicle is safely parked.
- · Depending on vehicle models and specifications, available options may vary.

Setting sounds

You can change the settings related to sounds, such as the speaker volume and sound effects.

Setting the system sound

On the Home screen, touch All Menus ► Setup ► Sound.



Note

- · Depending on vehicle models or specifications, available options may vary.
- Depending on the system or amplifier specifications applied to your vehicle, available options may vary.

Position

Select a location where sound will be concentrated in the vehicle. Touch a desired location on the seat image or touch the arrow buttons to move the focus. To set sound to be centered in the vehicle, touch .

Volume

Adjust the volume levels for various system features, including phone projection.

Tone

Adjust the output level for each sound tone mode.

Priority

- Proximity Warning: Set to decrease the audio volume to hear a proximity warning prior to other sounds while parking your vehicle.
- Start-up Volume Limit: Set the system to automatically decrease the volume when turned on, if the volume has been set to too high of a level.

Advanced (*if equipped)

Set the advanced sound options or apply various sound effects.

Depending on the amplifier specifications, available sound options and effects may vary.

Default

Reset your sound settings to the default values.



To turn the touch sound on or off, touch **Beep** at the top of the sound settings screen.

Setting the system screen

You can change the settings for the screen display.

On the Home screen, touch All Menus ▶ Setup ▶ Display.

Mode

Set the screen brightness to be adjusted automatically according to ambient lighting conditions or set the screen to stay bright or dark continuously.

Illumination

Link to Cluster Illumination Control enables the system brightness to be adjusted according to the instrument cluster's brightness. If this feature is deactivated, you can adjust the brightness for the day or night mode according to your setting in the **Mode** option.

Default

Reset your screen settings to the default values.

Setting the Home screen

You can change the menus displayed on the Home screen. Personalize the Home screen by adding your favorite menus.

- 1 On the Home screen, touch All Menus ➤ Setup ➤ Home Screen.
- 2 Find a desired menu from the list on the right and drag it to the location you want.
 - The existing menu moves to the list on the right and the new menu is added to its previous location.
 - Touch **Default** to reset your home screen settings to the default values.





Note

Once you change the menus displayed on the Home screen, it may affect how to access or perform some functions. If you cannot find a function you want from the Home screen, touch **All Menus** to access or perform it.

Setting the screen saver

You can select a screen saver option to be displayed when you turn off the screen by pressing and holding the [**b**] button on the control panel.

- 1 On the Home screen, touch All Menus ➤ Setup ➤ Screen Saver.
- 2 Select a screen saver option.
 - Digital: The digital clock is displayed.
 - Analog: The analog clock is displayed.
 - None: No screen saver is displayed.

Setting voice recognition

You can change the guidance type for voice recognition.

- On the Home screen, touch
 All Menus ➤ Setup ➤ Voice
 Recognition.
- 2 Select a guidance type you want.

Setting Bluetooth

You can change the settings for Bluetooth connections.

On the Home screen, touch **All Menus** ▶ **Setup** ▶ **Bluetooth**.

Bluetooth Connection

Pair new Bluetooth devices with your system, or connect or disconnect a paired device. You can also delete paired devices.

Auto Connection Priority

Select a paired device to connect to your system automatically when it turns on.

Bluetooth Voice Prompts

Set whether to hear voice prompts for events related to Bluetooth connections.

Privacy Mode

Activate the privacy mode to protect your personal information. In the privacy mode, personal data will not be displayed.

Bluetooth System Info

View or edit your system's Bluetooth information.

Default Factory Settings

Delete all paired Bluetooth devices and reset your Bluetooth settings to default values. All data related to Bluetooth devices will also be deleted.



Note

Some options will be displayed only when a mobile phone is connected to the system.

Setting the system environments

You can customize system environment settings, such as the time and date. system language, and more.

Setting the system language

- 1 On the Home screen, touch **All** Menus ► Setup ► Language.
- 2 Select a language.



- This setting will not affect user data, such as MP3 file names.
- Depending on the system language, voice recognition may not be supported.

Setting the time and date

- 1 On the Home screen, touch **All** Menus ▶ Setup ▶ Date/Time.
- 2 Set the current date and time in the input fields.
 - Touch 24 Hours to set the time in the 24 hour format.
 - Touch Daylight Saving Time to apply daylight saving time.

Setting the keyboard

You can customize the keyboard settings for text input.

On the Home screen, touch **All** Menus ► Setup ► Keyboard.

Keyboard Type - English

Select a default keyboard type for English.

Default Keyboard

Select a default character type for the keyboard.



This setting will be applied to all text input on your system.

Setting advanced options

You can customize additional settings, such as notifications or button functions.

On the Home screen, touch **All** Menus ▶ Setup ▶ Advanced.

Custom Button

Select a function to access when you press the custom button [☆] on the control panel.

Steering Wheel Mode Button

Select AV modes to access when you press the [MODE] button on the steering wheel.

Media Change Notifications

Set to briefly display media information at the top of the screen when the next item starts playing if you move from the media player to another function screen.

Rear Camera (*if equipped)

Set the rear view screen to remain active even if you shift to any position other than "R" (Reverse) after backing up. When you shift to "P" (Park) or drive at a predetermined speed or faster, the rear view screen will be deactivated and the system will display the previous screen automatically.

Viewing system information

On the Home screen, touch All Menus ▶ Setup ▶ System Info.

SW Info

View your system's version information or update it to the latest version. To update your system, visit your local dealership.

Storage

View storage information of your system's memory.

Default

Reset your system settings to the default values. All user data stored in the system will also be deleted.



- Depending on the total data amount, an update may take several minutes.
- · Do not turn off the system or remove the storage device while the update is in progress. If the power supply is cut off or the storage device is removed from the system, it may damage the data or cause a system malfunction.



9 Troubleshooting

Solutions



Solutions

Before reporting a malfunctioning system, refer to the following table and see if you can identify and fix the problem. If the problem persists or you are unable to locate your specific need, contact your place of purchase or dealer.

Sound and display

Symptom	Possible cause	Solution
No sound	System turned off	 Ensure that the engine start/stop button is set to "ACC" or "ON." Press the [ひ] button to turn on the system.
	Low volume level	Turn the volume knob on the control panel to adjust the volume.
	System muted	Press the [¶] button on the steering wheel to unmute the system.
Sound is heard from only one speaker.	Unbalanced sound output	On the Home screen, touch All Menus ► Setup ► Sound ► Position and change the settings to adjust the sound balance.
Sound is cut off or a distorted noise is heard.	System vibration	It is not a malfunction. If the system vibrates, the sound may be cut off or a distorted noise may occur. When the vibration stops, the system will operate normally.
The image quality is deteriorated.	Misaligned screen	On the Home screen, touch All Menus ► Setup ► Display ► Illumination and adjust the brightness.
	System vibration	It is not a malfunction. If the system vibrates, the image may be distorted. When the vibration stops, the system will operate normally.
	Aged or deteriorated screen	If the problem persists, contact your place of purchase or dealer.

Symptom	Possible cause	Solution
Small red, blue, or green dots appear on the screen.		Because the LCD is manufactured with technology requiring extremely high pixel density, pixel deficiency or constant lighting may occur within the permitted range of less than 0.01 % of the total pixels.

USB playback

Symptom	Possible cause	Solution
The files on the USB storage device are not	File format not compatible	Copy compatible media files to the USB device and reconnect the device. ► See p.10-7 "USB mode."
recognized.	Poor connection	Disconnect the USB storage device from the USB port and reconnect it correctly.
	Contaminated USB connectors	Remove foreign substances from the USB connector of the storage device and the contact surface of the USB port.
	USB hub or extension cable used	Connect the USB storage device directly to the USB port.
	Non-standard USB storage device used	Use a USB storage device that is compatible with the system. ► See p.10-7 "USB mode."
	Corrupt USB storage device	Format the USB storage device on a PC and reconnect it. Format the device in FAT16/32 format.

iPod/iPhone playback

Symptom	Possible cause	Solution
An iPod or iPhone is not recognized in the system.	Poor connection	Disconnect the cable from the USB port and reconnect it correctly.
	Device not ready or malfunctioning	 Check if the device's battery is low. If the battery is low, the smartphone may not be recognized. Check if the device's firmware is up-to-date. If not, update the firmware via iTunes and reconnect the device. Reset the device and reconnect it.
	Unapproved cable used	Use an Apple-approved cable.
	Device not supported	Use the device types and models that can be played in the system. ► See p.10-9 "iPod mode."
No sound is heard during music playback from an iPod or iPhone.	Playback paused during a call	If you make or receive a call while playing music from an iPhone, the device pauses playback. The playback may remain paused after you end the call. Check the playback status on the device and resume the audio.

Bluetooth connection


Symptom	Possible cause	Solution
The system is not detected on the Bluetooth device.	Pairing mode not activated	On the Home screen, touch All Menus ► Setup ► Bluetooth ► Bluetooth Connection ► Add New to switch the system to the pairing mode. Then, try searching for the system again on the device.
The Bluetooth device is not	Bluetooth deactivated	Activate Bluetooth on the device.
connected to the system.	Bluetooth error	 Deactivate Bluetooth and reactivate it on the device. Then, reconnect the device. Turn the device off and on. Then, reconnect it. Remove the battery from the device and reinstall it. Then, turn the device on and reconnect it. Unregister the Bluetooth pairing on both the system and the device and then reregister and connect them.

Phone projection

Symptom	Possible cause	Solution
Phone projection does not start when a smartphone is	Phone projection not supported by the phone	Visit the following websites and ensure that the smartphone supports the corresponding function.
connected via a USB cable.		 Android Auto: https://support.google.com/ androidauto
		 Apple CarPlay: https://www.apple.com/ios/ carplay
	Phone projection disabled	 On the Home screen, touch All Menus Setup ▶ Phone Projection, select a function you want to use, and activate it. Check if the function is disabled in the application settings or restriction settings on the smartphone.
	Smartphone not ready or malfunctioning	 Check if the smartphone's battery is low. If the battery is low, the smartphone may not be recognized. If the network signal is weak, phone projection may not work correctly. If the smartphone is locked, unlock it. Reset the smartphone and reconnect it.
When phone projection starts or is in use, a black screen is displayed.	Smartphone malfunctioning	 Disconnect the USB cable from the smartphone and reconnect the cable. Reset the smartphone and reconnect it.

System operation

Symptom	Possible cause	Solution
The previously used media mode is not activated after the system turns off and back on.	Poor connection or playback error	If the corresponding media storage device is not connected or has a problem in playback when you turn on the system, the AV mode you previously used will be activated. Reconnect the media storage device or restart playback.
The system is slow or it does not respond.	Internal system error	 Press and hold the reset button with a suitable tool, such as a pen or a paperclip. If the problem persists, contact your place of purchase or dealer.
The system does not turn on.	Fuse shorted	 Visit a repair shop and replace with a suitable fuse. If the problem persists, contact your place of purchase or dealer.



10

Appendix

System status icons
FAQ
System specifications
Important information
Index



System status icons

Status icons appear at the top right of the screen to display the current system status.

Familiarize yourself with the status icons that appear when you perform certain actions or functions and their meanings.



Mute and voice recording





Bluetooth



[IIII]:	Battery level of connected Bluetooth device
₿ ე	Mobile phone connected via Bluetooth
*1	Audio device connected via Bluetooth
8 1	Mobile phone and audio device connected via Bluetooth
C:	Bluetooth call in progress

Microphone turned off during Bluetooth call

Downloading call history from a mobile phone connected via Bluetooth to the system

Downloading contacts from a mobile phone connected via Bluetooth to the system


UVO



UVO call in progress
911 Connect activated

Signal strength





Data



Connected to LTE network

Rear seat status



Quiet mode activated



Note

- · The battery level displayed on the screen may differ from the battery level displayed on the connected device.
- · The signal strength displayed on the screen may differ from the signal strength displayed on the connected mobile phone.
- · Depending on vehicle models and specifications, some status icons may not be displayed.

FAO

Bluetooth



What kinds of functions can I use with Bluetooth?

A You can connect your mobile phone to make or answer calls hands free. You can also connect audio devices, such as MP3 players and mobile phones, to listen to music in your vehicle. ► See p.5-6 "Using a Bluetooth phone," p.5-5 "Using a Bluetooth audio device."



What is the difference between pairing a device and connecting a device?

Pairing occurs through authenticating the system and a mobile device. Devices paired with the system can be connected and disconnected until they are deleted from the system. Bluetooth Handsfree features, such as making or answering calls or accessing contacts, are supported only in mobile phones connected with the system.

Q How do I pair a Bluetooth device with the system?

A On the Home screen, touch All

Menus ➤ Setup ➤ Bluetooth ➤

Bluetooth Connection ➤ Add New.

From the Bluetooth device you

want to connect, search for and pair

with your system. When you enter

or confirm a Bluetooth passkey

displayed on the system screen, the

device is registered to the system's

Bluetooth device list and connected

to the system automatically. ➤ See

p.5-2 "Connecting Bluetooth devices."

What is a passkey?

A passkey is the password used to authenticate the connection between the system and the mobile device. The passkey needs to be entered only once when you pair a mobile phone for the first time.

The initial passkey is "0000." You can change it by touching All Menus ► Setup ► Bluetooth ► Bluetooth System Info ► Passkey.

Q I changed my mobile phone that was registered to the system via Bluetooth. How can I register my new mobile phone?

You can register additional devices to your system by following the instructions to pair a device. Up to five devices can be added to your system's Bluetooth device list. To delete a registered device, on the Bluetooth device list, touch **Delete**Devices, select the devices to delete, and touch Delete. See p.5-2

"Connecting Bluetooth devices."

O How do I answer a call?

When a call comes in and a notification pop-up window appears, press the [] button on the steering wheel or touch **Accept** on the screen.

To reject the call, press the [] button on the steering wheel or touch **Reject** on the screen.

- Q What should I do if I want to switch the call to my mobile phone while on a call via the system?
- A Press and hold the [] button on the steering wheel or touch **Use**Private on the screen to switch the call to your mobile phone.
- Q How do I access the contacts in my mobile phone from the system?

- Q What is the range of my wireless connection?
- A wireless connection can be used within about 10 m (about 33 ft). The maximum Bluetooth range may be affected by the usage environment, such as the vehicle type, the system platform, or the connected mobile phone.
- Q How many mobile devices can be paired?
- A Up to five devices can be paired with your system.
- **Q** Why is call quality sometimes poor?
- A Check your mobile phone's reception sensitivity when call quality deteriorates. The call quality may deteriorate when the signal strength is low.

Call quality may also become poor if metal objects, such as beverage cans, are placed near the mobile phone. Check to see if any metal objects are near the mobile phone.

The call sound and quality may differ depending on the type of mobile phone.

AV function

Q What kinds of AV functions does my system have?

A Your system provides you with the radio and media player (USB, iPod, etc.). For more information, see the corresponding chapters.

Q I want to move to the previous or next song without touching the screen while driving. How do I do this?

A Push the [^/] lever on the steering wheel to move to the previous or next song.

Broadcast reception

Q No sound is heard or a distorted noise is heard when listening to the radio while driving.

Depending on the location, the reception may deteriorate due to obstacles. If the reception diminishes, change the radio station to another one.

Attaching a window film including metal components to the rear window equipped with a glass antenna may lower radio reception.

How to self-check a system fault

Q My system does not operate normally. What should I do?

A Check your system by referring to the solutions explained in the troubleshooting sections. ► See p.9-2 "Solutions."

If the system still does not operate normally after following the relevant instructions, press and hold the reset button.

If the problem persists, contact your place of purchase or dealer.

System specifications

Media player

USB mode

Music

Item	Specifications		
Audio file specification		MPEG-1/2 Layer3, OGG (Vorbis), FLAC, WMA (Standard/ Professional), WAV	
Bit rates/Sampling frequency	MP3	8 to 320 kbps (CBR/VBR), to 48 kHz (ID3 tag version: Ver. 1.0, Ver. 1.1, Ver. 2.2, Ver. 2.3, Ver. 2.4)	
	OGG	Q1 to Q10, to 48 kHz	
	FLAC	8/16/24 bit, to 48 kHz	
	WMA	• Standard (0x161): to L3 Profile, to 385 kbps, to 48 kHz	
		 Professional (0x162): to M0b, to 192 kbps, to 48 kHz 	
	WAV	8/16 bit, to 48 kHz	
Detailed specifications	 Maximum number of directory layers: 20 Maximum length of folder/file names: 255 byte Supported characters for folder/file names: Alphanumeric characters, Korean standard character set 2,350 characters, Simplified Chinese 4,888 characters Maximum number of folders: 2,000 (including ROOT) Maximum number of files: 8,000 		



- You cannot play the following types of files:
 - Modified files (files whose file format has changed)
 - Variant files (for example, MP3 files encoded with WMA audio codec)
 - Files with digital rights management (DRM)
 - Files with no index
- Sound quality of music files using a bit rate in more than 192 kbps is not guaranteed.
- For files that do not use a fixed bit rate, some functions may not work or the playback time may be incorrect.
- If an error occurs when you play a file or the file is not in supported format, change the file format by using the latest encoding software.

USB storage devices

Item	Specifications	
Byte/Sector	64 kbyte or less	
Format system	FAT16/32 (recommended), exFAT, NTFS	



- Operation is guaranteed only for a metal cover type USB storage device with a plug type connector.
 - USB storage devices with a plastic plug may not be recognized.
 - USB storage devices in memory card types, such as CF card or SD cards, may not be recognized.
- · Any problem caused by the use of USB storage devices not listed in the following table are not covered by the warranty.

Product name	Manufacturer
XTICK	LG Electronics Inc.
ВМК	BMK Technology Co., Ltd.
SKY-DRV	Sky Digital Co., Ltd.
TRANSCEND JetFlash	Transcend Information, Inc.

Product name	Manufacturer	
Sandisk Cruzer	SanDisk	
Micro ZyRUS	ZyRUS	
NEXTIK	Digiworks Co., Ltd.	

- USB hard disk drives may not be recognized.
- When you use a large capacity USB storage device with multiple logical drives, only files stored on the first drive will be recognized.
- If an application program is loaded on a USB storage device, the corresponding media files may not play.

I iPod mode

Supported devices

Device type	Model	Generation
iPod	iPod nano	1G, 2G, 3G, 4G, 5G, 6G, 7G
	iPod touch	1G (except for iOS 1.1), 2G, 3G, 4G, 5G, 6G
	iPod classic	5G (iPod with video), 6G (iPod classic), 6.5G (iPod classic)
iPad	iPad/iPad mini	Unable to charge, not certified, operation not guaranteed
iPhone		3G (not certified, operation not guaranteed), 3GS, 4, 4S, 5, 5C, 5S, 6, 6+, 6S, 6S+, SE, 7, 7+

Supported OS

Device type	OS version
iPhone/iPod touch/iPod nano/iPod classic/iPad/iPad mini	iOS 9.3.2 or earlier

Common

Item	Specifications
Power supply	DC 14.4 V
Operating power	DC 9 to 16 V
Sleep current	 Average current within 96 hours of ACC off: 10 mA or less Average current after 96 hours of ACC off: 1 mA or less
Operating temperature	-20 to +70 °C (-4 to +158 °F)
Storage temperature	-40 to +85 °C (-40 to +185 °F)
Dimensions (W x H x L)	352 x 171 x 213 mm
Current consumption	2.5 A
Weight	2.26 kg

Display

Item	Specifications
Size (W x H)	8 inch (176.4 x 99.36 mm)
Pixel number	384,000 pixels (resolution: 800 x 480)
Operating method	Thin Film Transistor (TFT) Active Matrix
Viewing angle	Left/Right, Top/Bottom: 89°
Internal lighting	LED

Radio

Item	Specifications
Channels A2	 FM: 87.5 to 107.9 MHz (200 kHz) AM: 530 to 1710 kHz (10 kHz)
Sensitivity	FM: 10 dBuV or lowerAM: 35 dBu EMF or lower
Distortion factor	2 % or less

Bluetooth

Item	Specifications
Frequency range	2400 to 2483.5 MHz
Supported Bluetooth specification	3.0
Supported profile	Handsfree (1.6), A2DP (1.2), AVRCP (1.5), PBAP (1.1)
Bluetooth Power Class 2	-6 to 4 dBm
Antenna power	3 mW (maximum)
Number of channels	79

Modem RF

Item		Specifications
LTE	Reception	 Frequency: 2110 to 2155 MHz (B4), 746 to 756 MHz (B13) Sensitivity: -96.3 dBm or lower @ 10 M (B4), -93.3 dBm or lower @ 10 M (B13) (Throughput ≥ 95 %)
	Transmission	 Frequency: 1710 to 1755 MHz (B4), 777 to 787 MHz (B13) Maximum RF output power: Power Class3 (B4, B13), 20.3 to 25.7 dBm (conducted)
CDMA	Reception	 Frequency: 869 to 894 MHz (BC0), 1930 to 1990 MHz (BC1) Sensitivity: -104 dBm or lower (FER = 0.5 % or lower)
	Transmission	 Frequency: 824 to 849 MHz (BC0), 1850 to 1910 MHz (BC1) Maximum RF output power: Power Class3 (BC0), Power Class2 (BC1), 23.01 to 30 dBm (conducted)

Important information

Before using your system, read and follow all instructions and safety information provided in this user's guide ("User's Manual"). Not following precautions found in this guide can lead to an accident or other serious consequences.

Keep this guide in your vehicle

When kept in the vehicle, this guide will be a ready reference for you and other users unfamiliar with the system. Ensure that before using the system for the first time, all persons have access to this guide and read its instructions and safety information carefully.

Warning

Operating certain parts of this system while driving can distract your attention away from the road, and possibly cause an accident or other serious consequences. Do not change system settings or enter data non-verbally (using your hands) while driving. Stop the vehicle in a safe and legal manner before attempting these operations. This is important since setting up or changing some functions as you drive may distract your attention away from the road and removing your hands from the steering wheel may cause you to lose control of the vehicle.

General operation

Voice command control

Features within the system may be executed using only voice commands. Using voice commands while driving allows you to operate the system without removing your hands from the steering wheel.

Prolonged views of screen

Do not access any function requiring a prolonged view of the screen while you are driving. Pull over in a safe and legal manner before attempting to access a function of the system requiring prolonged attention. Even short views of the screen may be hazardous if your attention has been diverted away from your driving.

Volume setting

Do not raise the volume excessively. Keep the volume at a level where you can still hear outside traffic and emergency signals while driving. Driving while unable to hear these sounds could cause an accident.

Use of speech recognition functions

Speech recognition software is inherently a statistical process which is subject to errors. It is your responsibility to monitor any speech recognition functions included in the system and address any errors.

Index

A	C
advanced options, set 8-7	call history 5-8
Android devices	calls 5-6
Android Auto 2-6	climate control system 1-12
Apple devices Apple CarPlay 2-4 iPod mode 4-6 Buttery warning 1-6 Bluetooth answering a call 5-10 audio 5-5 connection connecting devices 5-4 deleting devices 5-5 disconnecting devices 5-4 pairing devices 5-2 phone call history 5-8 contacts list 5-8 favorites list 5-12 keypad 5-10 making a call 5-7 options during a call 5-11 switching calls 5-11 specifications 10-11	component names and functions control panel custom button 1-3 HOME button 1-3 MEDIA button 1-2 PHONE button 1-3 power button/volume knob 1-2 RADIO button 1-2 SEEK/TRACK button 1-2 SETUP button 1-3 tune knob/file knob 1-3 steering wheel remote control call/answer button 1-4 Call end button 1-4 MODE button 1-4 up/down lever 1-4 voice recognition button 1-4 volume lever/mute button 1-4 contacts list 5-8 control panel 1-2 D data services fuel price via SiriusXM 2-9 movie via SiriusXM 2-11 stock via SiriusXM 2-10 weather via SiriusXM 2-9

F	M
FAQ	media devices, connect 4-2
AV functions 10-6 Bluetooth 10-3 broadcast reception 10-6 self-check on system faults 10-6 favorite numbers, save 5-12 frequently asked questions 10-3	media player iPod mode accessing lists 4-7 connecting devices 4-2 playback 4-6 specifications 10-9 pausing/resuming 4-3 playback 4-3 repeat play 4-4 restarting current playback 4-3 shuffle play 4-4 skipping forward/backward 4-3 USB mode accessing lists 4-6
н	
home screen overview 1-8 setting 8-4	
I iPod mode connecting devices 4-2 notes on connections 4-7 notes on playback 4-8 playback 4-6 specifications 10-9	connecting devices 4-2 device specifications 10-8 music playback 4-4 microphone 6-2 multimedia port (USB) 4-2 music playback Bluetooth audio 5-5 iPod mode 4-6 media player 4-2
K	USB mode 4-4
keyboard, set 8-6	My Menu 1-8
L	P
language, set 8-6	parking guides 1-8 phone projection Android Auto 2-6 Apple CarPlay 2-4 proximity warning 1-9

R	time and date 8-6
radio mode, change 3-2 saving stations 3-4 scanning stations 3-3 searching for stations 3-3 SiriusXM 3-4	touch sound 8-3 UVO 7-4 vehicle environment 8-2 voice recognition 8-5 Siri Eyes Free 6-9 SiriusXM
rear seat climate control system 1-12 quiet mode 2-2	data services 2-8 radio 3-4 sound settings 8-2
rear view parking guides 1-8 proximity warning 1-9 resetting to default screen 8-3 sound 8-3 system 8-7	specifications Bluetooth 10-11 common 10-10 display 10-10 media player 10-7 modem RF 10-12 radio 10-11
•	steering-interactive camera 1-10
S	steering wheel remote control 1-4 surround view monitor
screen saver, set 8-4 screen settings 8-3 settings advanced options 8-7 Bluetooth 8-5 home screen 8-4 keyboard 8-6 language 8-6 phone projection 2-5, 2-7 screen saver 8-4 system information 8-7 system screen 8-3 system sound 8-2	open door/folded mirror alert 1-11 rear top view 1-11 settings 1-12 surround view while backing up 1-11 surround view while driving 1-10 system information 8-7 system layout 1-2 system status icons 10-2 system, turn on/off 1-5

T time and date, set 8-6 touch screen, control 1-6 touch sound, set 8-3 troubleshooting Bluetooth connection 9-5 iPod/iPhone playback 9-4 phone projection 9-6 sound and display 9-2 system operation 9-7 USB playback 9-3 U USB device specifications 10-8 USB mode connecting devices 4-2 device specifications 10-8 file specifications 10-7 music playback 4-4

USB port, connect 4-2

driving information 7-5 menu, access 7-4 roadside assistance 7-6 vehicle diagnosis 7-6

911 call 7-8 activation 7-2 center call 7-7

UVO

vehicle environment, set 8-2 voice memos 2-3 voice recognition call commands 6-6 help 6-4 media commands 6-7 microphone 6-2 notes before starting 6-2 other commands 6-8 radio commands 6-7 Siri Eyes Free 6-9 starting 6-3 UVO commands 6-8 voice volume 6-4

Trademarks

 The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Kia is under license.
 A Bluetooth® Wireless Technology enabled cell phone is required to use Bluetooth® Wireless Technology. Bluetooth® Wireless Technology phone compatibility can be checked by visiting https://www.kia.com.

Bluetooth°

- Google, Android, Android Auto, and Google Play are registered trademarks of Google LLC. Distracted driving can result in a loss of vehicle control. Never use a handheld device or vehicle system that takes your focus away from safe vehicle operation.
- Apple®, Apple CarPlay™, iPad®, iPad mini™, iPhone®, iPod®, iPod classic®, iPod nano®, iPod touch®, iTunes®, and Siri® are trademarks of Apple Inc. Distracted driving can result in a loss of vehicle control. Never use a handheld device or vehicle system that takes your focus away from safe vehicle operation.
- Sirius, XM, SiriusXM and all related marks and logos are trademarks of SiriusXM Radio Inc.
- Other trademarks and trade names are those of their respective owners.

Disclaimers

- Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving.
- Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe personal injury and death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and use of any handheld devices, other equipment or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or that are not permissible by law should never be used during operation of the vehicle.
- SiriusXM®: SiriusXM Satellite Radio. SiriusXM Traffic and SiriusXM Travel Link each require a subscription sold separately, or as a package, by SiriusXM Radio Inc. If you decide to continue your service at the end of your trial subscription, the plan you choose will automatically renew and bill at thencurrent rates until you call 1-866-635-2349 to cancel, See SiriusXM Customer Agreement for complete terms at www. siriusxm.com. Other fees and taxes will apply. All fees and programming are subject to change. Not all vehicles or devices are capable of receiving all services offered by SiriusXM. Data displays and individual product availability vary by vehicle hardware. Current information and features may not be available in all locations, or on all receivers. Weather Forecast, Current Conditions may not be available in all locations. Images above are for representative purposes only and are not real products. For actual features

and images of real products, consult the vehicle manufacturer. SiriusXM is not responsible for any errors or inaccuracies in the data services or their use in the vehicle. Travel Link Stocks displays current price and daily delta of around 7,000 actively reported securities traded on the NYSE®, NASDAQ® and AMEX®. The service is delayed approximately 20 minutes. SiriusXM satellite service is available only to those at least 18 years of age in the 48 contiguous USA, DC, and Puerto Rico (with coverage limitations). SiriusXM Internet Radio service is available throughout our satellite service area and in AK and HI. ©2018 SiriusXM Radio Inc.

 Android Auto: Vehicle user interface is a product of Google and its terms and privacy statements apply. Requires the Android Auto app on Google Play and an Android compatible smartphone running Android™ 5.0 Lollipop or higher. Data plan rates apply.

FCC Certification

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


Caution: Any changes or modifications to this device not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum 20 cm between the radiator and your body. This transmitter must not be collocated or operating in conjunction with any other antenna or transmitter unless authorized to do so by the FCC.











S9MS7-D2000

D27 (영어 | 미국) 디오디오

