



WarningMeasureEventExecutionReport

preconfiguredBrakingModel: uint32

brakePosition: BrakePosition

warningMeasureEvent: \*WarningMeasureEver

operationalPlanIssuedAt: timestamp

executionState: EventExecutionState

issuedAt: timestamp

warning: string[0..1]

failureReason: string[0..1]