
ITEM	QTY.	PART No.	DESCRIPTION
1	4	S017-BG-0004	OSCILLATING BLOCK CHANNEL - UPPER
2	4	S017-BG-0005	OSCILLATING BLOCK CHANNEL - LOWER
3	8	S017-BG-0006D	SHOULDER & BODY SCREEN SLIDE
4	1	S017-AG-0288	SCREEN FRAME SLIDEWAY
5	4	S017-AG-0289A	SCREEN FRAME SLIDEWAY GIB - UPPER REAR
6			
7			
8	8	S007-BG-0006B	OSCILLATING SHOULDER BLOCK
9	8	S007-DG-0011	OSCILLATING LEVER ADJUSTING BLOCK



TOP VIEW TYPICAL SCREEN SLIDEWAY

NOTE: PARTS FOR 4 DECORATING STSTIONS ON A 4 COLOR SLIDEWAY