## / WARNING

THIS DRAWING GIVES THE BASIC INSTRUCTIONS FOR PROVIDING THE SUPPLY SERVICESAND ENVIRONMENT THAT GUARANTEES THE PROPER FUNCTIONNING OF THE PRODUCTS FROM THIS COMPANY. THE PURCHASER, AND THE PURCHARSER'S INSTALLERS SHALL PROVIDE THE SUPPLY LINES NECESSARY FOR EACH PRODUCT IN ACCORDANCE WITH ESTABLISHED APPLICABLE NORMS AND REGULATIONS. THE COMPANY DECLINES ALL RESPONSABILITY FOR FAILURE TO COMPLY WITH SUCH LAWS AND REGULATIONS.

# **№** NOTE

THIS COMPANY RESERVES THE RIGHT TO MODIFY THIS DRAWING ACCORDING TO THE TECHNICAL DEVELOPMENT OF THE EQUIPMENT.

This equipment has been designed for use in accordance with the International EMC(Electromagnetic Compatibility) Standards. In view of different environments, please follow the instructions given below to eliminate interference, if necessary.

- Move the equipment or rotate its direction;
- Enlarge the space between the equipment and other machines;
- Put the plug into other outlets;
- Please consult with the local distributor or qualified electrician.

#### Installation:

- It will require at least two (2) or more people to carry the sterilizer to avoid dropping it off by mistake.
- While installation; please make sure that the bearing capacity of installation table is enough to carry the sterilizer. For the weight information of the sterilizer, please refer to "Specifications".
- 3. Located position the sterilizer on a stable bench or work surface.
- 4. Position the sterilizer on a stable laboratory bench or work surface, ensuring at least 10 cm clearance between the wall or other pieces of equipment and the sides of the unit for free circulation of air.
- 5. Make sure that the door can be opened freely after installation.
- 6. Do not install or operate the sterilizer in areas where flammable items or volatile substances are used or stored. An explosion could occur, causing personal injury. An installation site with good air circulation is required.
- 7. ELECTRIC INTAKE 1 \$\psi\$ /220V/3000W/13A WIRE 4 m LONG. (GENERAL POWER SUPPLY TO THE STERILIZER).

### ENVIRONMENT CONDITIONS IN THE STERILE AREA:


- Indoor use:
- Under 1,000m (altitude);
- Temperature 5°C to 40°C;
- Relative Humidity 80%RH@31°C to Relative Humidity 50%RH@40°C;
- Voltage fluctuation ±10 %;
- Transient overvoltages category II);
- (Pollution degree 2)

## Important Safety Instructions:


- Connect the external water supplier to the water inlet with presure greather than 2 bar.
- 2. Refer to the table for the requirements of water quality.
- Connect the drainage pipe to exhaust the used water according to the local authority's law.
- 4. Do not obstruct the drainage system.
- 5. Consult technicians for the correct connections.


#### ATTENTION:

- CHAMBER DIMENSIONS: Ø300 mmx450 mm.
- DEVICE OUTSIDE DIMENSIONS:584(W)mmx480(h)mmx670(D)mm.
- ALL THE OUTLETS MUST BE INSTALLED ACCORDING TO LOCAL APPLICABLE NORMS.
- THE INSTALLATION UP TO THE MACHINE AS WELL AS THE SUPPLY OF ACCESSIBLE KEY ACCORDING TO THE SPECIFICATIONS INDICATED IN THE DRAWING, ARE CHARGEABLE TO THE PURCHASERS.
- THE MEASUREMENTS OF THIS DRAWING ARE CONSIDERING FINISHED WALLS.
- THE SPACES OF MAINTENANCE MUST BE SUFFICIENTLY ILLUMINATED.



the apparatus.





FRONT VIEW

Table: Suggested maximum limits of contaminants in and specification for water for steam sterilization feed water ≤10 mg/l Evaporate residue ≤ 1 mg/l Silicium oxide .Sio. ≤0.2 mg/l Iron Cadmium ≤0.005 mg/l ≤0.05 mg/l Lead Rest of heavy metals ,excluding iron, ≤0.1 mq/l cadmium.lead Chloride ≤2 mg/l ≤0.5 mg/l Phosphate ≤15 µs/cm Conductivity(at20°C) 5 to 7.5 pH value colourless.clean. Appearance without sediment

/ NOTE


Technician Manual) and adequate information are authorized to install

Installer Qualifications: The install personnel having proper

qualification and holding technical documentation (including

NOTE The use of water for steam generation with contaminants at levels exceeding those given in this Table can greatly shorten the working life of a sterilizer and can invalidate the manufactacure's warranty of guarantee.

≤0.02mmol/l





Sturdy 新駿實業股份有限公司 STURDY INDUSTRIAL CO., LTD.

TOLERANCE未標註	者一般公差表	未標示之	圓角	為R1導角	為C1	DESIGNED 設計:	DRAWN 繪圖:	VERIFIED 校校:	APPROVED 核准:
0~10 ±0.2	51~100±0.6	201~500:	±1	ANGLE	±1°	Mia	Mia	吳雲聖	Robt
11~50 ±0.4	101~200±0.8	501~X	±2	视角		20220714	20220718	202018.	2022 2.14
MATERIAL 材質	SCALE 比例 1:15		UNIT 單位 mm		B 名 PRIME30L INSTALLATION PLAN				
SURFACE FINISHING 表面處理		MODEL NO. 代表機種 PRIME30B				™G.NO. PRIME30L-HE-001-01			