


Button NEW

0 → 17
1 → 0

→ Servo → Brightness sensor.



$$\frac{160}{300}$$

$$y - 0 = \frac{-160}{300} (x - 300)$$

$$y = \frac{-160}{300} (x - 300)$$

$$\text{Angle} = \frac{-16}{30} \times \text{L.V.} + \left(\frac{16}{30} \times 780 \right)$$