

Document Title	Specification of Diagnostic over IP
Document Owner	AUTOSAR
Document Responsibility	AUTOSAR
Document Identification No	418

Document Status	published
Part of AUTOSAR Standard	Classic Platform
Part of Standard Release	R24-11

	Document Change History			
Date	Release	Changed by	Description	
2024-11-27	R24-11	AUTOSAR Release Management	New API: DoIP_AllowNonTlsDoIPConnection Editorial changes	
2023-11-23	R23-11	AUTOSAR Release Management	incorporated DoIP Multiplexed Testers	
2022-11-24	R22-11	AUTOSAR Release Management	No content changes	
2021-11-25	R21-11	AUTOSAR Release Management	 Most APIs reporting development errors no longer return with E_NOT_OK Removed obsolete elements Editorial changes 	
2020-11-30	R20-11	AUTOSAR Release Management	 CONC 649 DoIP Extension fully incorporated Added internal tester support Harmonized IP interface concept with ISO 13400 Duplicate service IDs fixed Harmonized error classification 	





 \triangle

		\triangle	
			Introduced CONC 649 DoIP Extension in draft state
			Updated the functionality of routing activation for security use-cases
2019-11-28	R19-11	AUTOSAR Release Management	Increased multiplicity of DoIP target address so more than 255 DoIP addresses could be used
			Minor corrections / clarifications / editorial changes; for details please refer to the ChangeDocumentation
			Changed Document Status from Final to published
			Updated the functionality to receive vehicle announcements
00404004		AUTOSAR Release Management	Support to add an increased number of DoIP target addresses
2018-10-31	4.4.0		DoIP header file clean-up
			Minor corrections / clarifications / editorial changes; for details please refer to the ChangeDocumentation
	4.3.1	AUTOSAR Release Management	Support for DoIP UDP Connections with limited broadcast IP addresses
2017-12-08			Support for Further Action Code values for vehicle identification and vehicle announcement
			Alignment of routing activation confirmation with ISO 13400
			Editorial changes
			Support for DoIP Activation line switch
2016-11-30	4.3.0	AUTOSAR Release Management	Support for UDP multicast vehicle announcement
2010-11-30	4.3.0		Introduction of reliable TxConfirmation
			Harmonization of identical APIs functions within BSW





 \triangle

2015-07-31	4.2.2	AUTOSAR Release Management	 DET Renaming and Extension Incorporation Support for parallel diagnostic sessions
2014-10-31	4.2.1	AUTOSAR Release Management	 Harmonization of identical APIs within BSW Handling UUDT messages within DoIP Harmonization of callback functions and configuration parameter names Editorial changes
2014-03-31	4.1.3	AUTOSAR Release Management	 Harmonization of identical APIs Multiplicity of some configuration parameters were updated Editorial changes
2013-10-31	4.1.2	AUTOSAR Release Management	 Formalization of Service Interfaces Revised return values of Service Interfaces Editorial changes
2013-03-15	4.1.1	AUTOSAR Release Management	Initial Release



Disclaimer

This work (specification and/or software implementation) and the material contained in it, as released by AUTOSAR, is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the work.

The material contained in this work is protected by copyright and other types of intellectual property rights. The commercial exploitation of the material contained in this work requires a license to such intellectual property rights.

This work may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only. For any other purpose, no part of the work may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The work has been developed for automotive applications only. It has neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.



Contents

1	Introduction and functional overview	9
2	Acronyms and abbreviations	10
3 Related documentation		
	 3.1 Input documents & related standards and norms 3.2 Related standards and norms 3.3 Related specification 	11 11 11
4	Constraints and assumptions	12
	4.1 Applicability to car domains	12
5	Dependencies to other modules	13
	5.1 Socket Adaptor (SoAd) 5.2 Pdu Router (PduR) 5.3 Diagnostic Communication Manager (Dcm) 5.4 Default Error Tracer (Det) 5.5 File structure 5.5.1 Code file structure	14 14 14 14 15
6	Requirements Tracing	16
7	Functional specification	19
	7.1 DoIP usage scenarios 7.1.1 DoIP Internal Tester Functionality Extension (DRAFT) 7.2 Connection establishment 7.3 DoIP Message layout according ISO 13400-2 7.3.1 Generic DoIP header 7.3.2 Payload types 7.3.2.1 Generic acknowledge 7.3.2.2 Vehicle Identification 7.3.2.3 Routing activation 7.3.2.4 Alive check 7.3.2.5 Node information 7.3.2.6 Diagnostic Message 7.4 UDP communication 7.5 TCP communication 7.5.1 Reception of a TCP DoIP message 7.5.2 Transmission of a TCP DoIP message	19 20 21 27 27 30 30 32 40 45 46 49 54 56 56 59
	7.6 Error classification	63 63 63 63



8	API	specification	on Control of the Con	6
	8.1	Imported	I types	. 6
	8.2	Type def	initions	. 6
		8.2.1	DoIP_ConfigType	. 6
	8.3	Function	definitions	. 6
		8.3.1	DoIP_TpTransmit	. 6
		8.3.2	DoIP_TpCancelTransmit	
		8.3.3	DoIP_TpCancelReceive	. 6
		8.3.4	DoIP_IfTransmit	. 7
		8.3.5	DoIP_IfCancelTransmit	. 7
		8.3.6	DoIP_Init	. 7
		8.3.7	DoIP_GetVersionInfo	. 7
		8.3.8	DoIP_ActivationLineSwitch	. 7
		8.3.9	DoIP_TriggerVehicleAnnouncement	
		8.3.10	DoIP_AllowNonTlsDoIPConnection	
	8.4		k notifications	
		8.4.1	DoIP_SoAdTpCopyTxData	
		8.4.2	DoIP_SoAdTpTxConfirmation	
		8.4.3	DoIP_SoAdTpCopyRxData	
		8.4.4	DoIP_SoAdTpStartOfReception	
		8.4.5	DoIP_SoAdTpRxIndication	
		8.4.6	DoIP_SoAdIfRxIndication	
		8.4.7	DoIP_SoAdIfTxConfirmation	
		8.4.8	DoIP_SoConModeChg	
		8.4.9	DoIP_LocallpAddrAssignmentChg	
	8.5	Schedule	ed functions	
		8.5.1	DoIP_MainFunction	
	8.6	Expected	d Interfaces	
		8.6.1	Mandatory Interfaces	
		8.6.2	Optional Interfaces	. 8
		8.6.3	Configurable interfaces	. 8
		8.6.3		
		8.6.3	_ 5	
		8.6.3		
		8.6.3	_ 00 ,	
		8.6.3		
		8.6.3	-	
		8.6.4	DoIP Service Component	. 9
9	Seq	uence diag	rams	ç
	9.1	UDP Dol	IP communication	. (
	9.2		message	
	9.3		message	
	9.4		n Line Handling - Active	
	9.5		n Line Handling - Inactive	
10				
. 0		nfiguration specification 104		



	10.1	How to re	ead this chapter	104
	10.2		ation and configuration parameters	
		10.2.1	Variants	104
		10.2.2	DoIP	104
		10.2.3	DolPGeneral	105
		10.2.4	DoIPGetGidCallback	113
		10.2.5	DoIPPowerModeCallback	114
		10.2.6	DoIPTriggerGidSyncCallback	115
		10.2.7	DoIPConfigSet	116
		10.2.8	DolPInterface	118
		10.2.9	DolPChannel	127
		10.2.10	DoIPPduRRxPdu	128
		10.2.11	DoIPPduRTxPdu	130
		10.2.12	DoIPConnections	131
		10.2.13	DoIPTargetAddress	134
		10.2.14	DoIPTcpConnection	134
		10.2.15	DoIPSoAdTcpRxPdu	136
		10.2.16	DoIPSoAdTcpTxPdu	137
		10.2.17	DoIPUdpConnection	139
		10.2.18	DoIPSoAdUdpRxPdu	140
		10.2.19	DoIPSoAdUdpTxPdu	141
		10.2.20	DoIPUdpVehicleAnnouncementConnection	142
		10.2.21	DoIPSoAdUdpVehicleAnnouncementTxPdu	143
		10.2.22	DoIPFurtherActionByteCallback	144
		10.2.23	DoIPProtocolVersion	145
		10.2.24	DoIPRoutingActivation	147
		10.2.25	DoIPRoutingActivationAuthenticationCallback	150
		10.2.26	DoIPRoutingActivationConfirmationCallback	152
		10.2.27	DolPTester	154
	10.3	Published	d Information	156
1	Chan	ige History		157
	A.1	Traceable	e item history of this document according to AUTOSAR Re-	
		lease R2		157
		A.1.1	Added Specification Items in R22-11	157
		A.1.2	Changed Specification Items in R22-11	157
		A.1.3	Deleted Specification Items in R22-11	158
		A.1.4	Added Constraints in R22-11	158
		A.1.5	Changed Constraints in R22-11	158
		A.1.6	Deleted Constraints in R22-11	159
	A.2		e item history of this document according to AUTOSAR Re-	
		lease R2		159
		A.2.1	Added Specification Items in R23-11	159
		A.2.2	Changed Specification Items in R23-11	159
		A.2.3	Deleted Specification Items in R23-11	160

Specification of Diagnostic over IP AUTOSAR CP R24-11



A.3	Traceable	e item history of this document according to AUTOSAR Re-	
	lease R2	4-11	160
	A.3.1	Added Specification Items in R24-11	160
	A.3.2	Changed Specification Items in R24-11	160
	A.3.3	Deleted Specification Items in R24-11	160



1 Introduction and functional overview

The intent of this document is to specify the functionality, API and the configuration of the AUTOSAR Basic Software module Diagnostic over IP (DoIP).

For detailed introduction and information about DoIP please refer to ISO 13400 documents set.

AUTOSAR as SW standard can provide a standardized solution of the ISO DoIP specification in the already existing Ethernet architecture as depict in Figure 1.1.




Figure 1.1: DoIP in the AUTOSAR ComStack Stack Architecture



2 Acronyms and abbreviations

Abbreviation / Acronym:	Description:
ARP	Address Resolution Protocol
DHCP	Diagnostic Host Configuration Protocol
EID	Entity identifier
GID	Group identifier
ICMP	Internet Control Message Protocol
IP	Internet Protocol
IPv4	Internet Protocol version 4
IPv6	Internet Protocol version 6
TCP	Transmission Control Protocol
TCP/IP	A family of communication protocols used in computer networks
VIN	Vehicle Identification Number
UDP	User Datagram Protocol



3 Related documentation

3.1 Input documents & related standards and norms

- [1] General Specification of Basic Software Modules AUTOSAR_CP_SWS_BSWGeneral
- [2] Specification of Socket Adaptor AUTOSAR_CP_SWS_SocketAdaptor
- [3] Specification of TCP/IP Stack AUTOSAR_CP_SWS_Tcplp
- [4] Specification of PDU Router AUTOSAR_CP_SWS_PDURouter
- [5] Specification of Diagnostic Communication Manager AUTOSAR CP SWS DiagnosticCommunicationManager
- [6] Specification of Default Error Tracer AUTOSAR CP SWS DefaultErrorTracer
- [7] ISO 13400-2:2019 Road vehicles Diagnostic communication over Internet Protocol (DoIP) Part 2: Network and transport layer requirements and services (Release 2019-12) https://www.iso.org/standard/74785.html
- [8] Specification of RTE Software AUTOSAR_CP_SWS_RTE

3.2 Related standards and norms

3.3 Related specification

AUTOSAR provides a General Specification on Basic Software modules [1] (SWS BSW General), which is also valid for the DoIP module.

Thus, the specification SWS BSW General [1] shall be considered as additional and required specification for the DoIP module.



4 Constraints and assumptions

4.1 Applicability to car domains

The DoIP basic software module may be used for all car domains.



5 Dependencies to other modules

This section describes the relations and dependencies between the DoIP module and other AUTOSAR Basic Software modules. It describes briefly the services and interfaces required from other modules and how they call the DoIP module and how they are called by the DoIP module.




Figure 5.1: DoIPBSWInterfaces



5.1 Socket Adaptor (SoAd)

The Socket Adaptor [2] is the lower layer module of the DoIP module. It provides:

- Interfaces and callbacks for Socket connection establishment and notification
- Transmission of Data via multiple socket connection
- Reception of Data via multiple socket connection
- Notification on Socket status changes
- Notification on IP Address status changes

The Socket Adaptor is the interfacing module for the TCP/IP Stack [3] that supports IP, TCP, UDP,IPv4, IPv6 and address assignment mechanisms like AutoIP and DHCP.

5.2 Pdu Router (PduR)

The Pdu Router [4] is the module used by the DoIP module to connect to the rest of the communication stack. It provides:

- Forward diagnostic messages from the DoIP module to other modules (i.e. internal Dcm or other TP module)
- Forward diagnostic messages from Dcm or other TP modules to the DoIP mod-

The PduR is the module to route the diagnostic message from the DoIP module to their according destination and back.

5.3 Diagnostic Communication Manager (Dcm)

The Diagnostic Communication Manager [5] is the module providing the VIN to the DoIP module. Additionally the Dcm will execute the ECU local diagnostic routed via PduR.

5.4 Default Error Tracer (Det)

If the configuration parameter DoIPDevelopmentErrorDetect is set to true and a DoIP API is called with incorrect parameters, the Default Error Tracer [6] is called with an error ID.



5.5 File structure

5.5.1 Code file structure

For details refer to chapter 5.1.6 "Code file structure" in SWS_BSWGeneral [1].



6 Requirements Tracing

Requirement	Description	Satisfied by
[RS_Diag_00024]	DoIP messages shall be bi-directionally routed	[SWS_DoIP_00022] [SWS_DoIP_00023] [SWS_DoIP_00024] [SWS_DoIP_00026] [SWS_DoIP_00031] [SWS_DoIP_00032] [SWS_DoIP_00033] [SWS_DoIP_00037] [SWS_DoIP_00038] [SWS_DoIP_00197] [SWS_DoIP_00198] [SWS_DoIP_00200] [SWS_DoIP_00207] [SWS_DoIP_00208] [SWS_DoIP_00209] [SWS_DoIP_00210] [SWS_DoIP_00209] [SWS_DoIP_00214] [SWS_DoIP_00212] [SWS_DoIP_00217] [SWS_DoIP_00218] [SWS_DoIP_00217] [SWS_DoIP_00218] [SWS_DoIP_00219] [SWS_DoIP_00220] [SWS_DoIP_00221] [SWS_DoIP_00223] [SWS_DoIP_00224] [SWS_DoIP_00225] [SWS_DoIP_00226] [SWS_DoIP_00228] [SWS_DOIP_00229] [SWS_DoIP_00230] [SWS_DOIP_002231] [SWS_DoIP_00230] [SWS_DOIP_00233] [SWS_DoIP_00231] [SWS_DOIP_00245] [SWS_DoIP_002257] [SWS_DoIP_00254] [SWS_DoIP_002260] [SWS_DoIP_00259] [SWS_DoIP_002260] [SWS_DOIP_00277] [SWS_DOIP_002284] [SWS_DOIP_00279] [SWS_DOIP_002284] [SWS_DOIP_00279] [SWS_DOIP_002284] [SWS_DOIP_00279]
[RS_Diag_00025]	Valid DoIP messages shall be recognized	[SWS_DoIP_00004] [SWS_DoIP_00005] [SWS_DoIP_00006] [SWS_DoIP_00007] [SWS_DoIP_00008] [SWS_DoIP_00009] [SWS_DoIP_00010] [SWS_DoIP_00012] [SWS_DoIP_00013] [SWS_DoIP_00014] [SWS_DoIP_00016] [SWS_DoIP_00017] [SWS_DoIP_00018] [SWS_DoIP_00019] [SWS_DoIP_00292] [SWS_DoIP_00293] [SWS_DoIP_00321] [SWS_DoIP_00322]
[RS_Diag_00026]	DoIP Vehicle Identification shall be provided	[SWS_DoIP_00015] [SWS_DoIP_00050] [SWS_DoIP_00051] [SWS_DoIP_00056] [SWS_DoIP_00057] [SWS_DoIP_00059] [SWS_DoIP_00060] [SWS_DoIP_00061] [SWS_DoIP_00062] [SWS_DoIP_00063] [SWS_DoIP_00064] [SWS_DoIP_00065] [SWS_DoIP_00066] [SWS_DoIP_00067] [SWS_DoIP_00068] [SWS_DoIP_00069] [SWS_DoIP_00070] [SWS_DoIP_00071] [SWS_DoIP_00072] [SWS_DoIP_00073] [SWS_DoIP_00074] [SWS_DoIP_00075] [SWS_DoIP_00076] [SWS_DoIP_00077] [SWS_DoIP_00076] [SWS_DoIP_00077] [SWS_DoIP_00080] [SWS_DoIP_00081] [SWS_DoIP_00080] [SWS_DoIP_00081] [SWS_DoIP_00081] [SWS_DoIP_00088] [SWS_DoIP_00087] [SWS_DoIP_00088] [SWS_DoIP_00087] [SWS_DoIP_00088] [SWS_DoIP_00087] [SWS_DoIP_00088] [SWS_DoIP_00089] [SWS_DoIP_00205] [SWS_DoIP_00287] [SWS_DoIP_00288] [SWS_DoIP_00289] [SWS_DoIP_00290] [SWS_DoIP_00289] [SWS_DoIP_00290]



\triangle

Requirement	Description	Satisfied by
[RS_Diag_00027]	DoIP diagnostic message shall have a format	[SWS_DoIP_00121] [SWS_DoIP_00122] [SWS_DoIP_00123] [SWS_DoIP_00124] [SWS_DoIP_00125] [SWS_DoIP_00126] [SWS_DoIP_00127] [SWS_DoIP_00128] [SWS_DoIP_00129] [SWS_DoIP_00130] [SWS_DoIP_00131] [SWS_DoIP_00132] [SWS_DoIP_00133] [SWS_DoIP_00134] [SWS_DoIP_00135] [SWS_DoIP_00136] [SWS_DoIP_00137] [SWS_DoIP_00138] [SWS_DoIP_00173]
[RS_Diag_00028]	Multiple DoIP sockets shall be allowed on a single port	[SWS_DoIP_00002] [SWS_DoIP_00039] [SWS_DoIP_00040] [SWS_DoIP_00058] [SWS_DoIP_00085] [SWS_DoIP_00115] [SWS_DoIP_00201] [SWS_DoIP_00202] [SWS_DoIP_00204] [SWS_DoIP_00234] [SWS_DoIP_00235] [SWS_DoIP_00241] [SWS_DoIP_00243] [SWS_DoIP_00296] [SWS_DoIP_00297] [SWS_DoIP_00298] [SWS_DoIP_00306] [SWS_DoIP_00358]
[RS_Diag_00047]	DoIP shall be able to access the DHCP host name option.	[SWS_DoIP_00154] [SWS_DoIP_00155] [SWS_DoIP_00156]
[RS_Diag_00080]	DoIP shall implement a mechanism to retrieve diagnostic power mode	[SWS_DoIP_00047] [SWS_DoIP_00054] [SWS_DoIP_00090] [SWS_DoIP_00091] [SWS_DoIP_00092] [SWS_DoIP_00093] [SWS_DoIP_00261]
[RS_Diag_00081]	DoIP shall be able to dynamically maintain connection to different testers	[SWS_DoIP_00001] [SWS_DoIP_00002] [SWS_DoIP_00039] [SWS_DoIP_00040] [SWS_DoIP_00058] [SWS_DoIP_00085] [SWS_DoIP_00115] [SWS_DoIP_00201] [SWS_DoIP_00202] [SWS_DoIP_00204] [SWS_DoIP_00234] [SWS_DoIP_00235] [SWS_DoIP_00241] [SWS_DoIP_00243] [SWS_DoIP_00296] [SWS_DoIP_00297] [SWS_DoIP_00298] [SWS_DoIP_00306] [SWS_DoIP_00358]
[RS_Diag_00082]	DoIP shall implement a mechanism to retrieve Entity Status	[SWS_DoIP_00094] [SWS_DoIP_00095] [SWS_DoIP_00096] [SWS_DoIP_00097] [SWS_DoIP_00098] [SWS_DoIP_00099] [SWS_DoIP_00100]
[RS_Diag_00083]	DoIP shall implement a mechanism to check if diagnostic testers are alive	[SWS_DoIP_00058] [SWS_DoIP_00105] [SWS_DoIP_00107] [SWS_DoIP_00115] [SWS_DoIP_00139] [SWS_DoIP_00140] [SWS_DoIP_00141] [SWS_DoIP_00142] [SWS_DoIP_00143] [SWS_DoIP_00144] [SWS_DoIP_00145] [SWS_DoIP_00146] [SWS_DoIP_00159] [SWS_DoIP_00358]
[RS_Diag_00084]	DoIP shall implement routing activation mechanism	[SWS_DoIP_00048] [SWS_DoIP_00049] [SWS_DoIP_00055] [SWS_DoIP_00101] [SWS_DoIP_00102] [SWS_DoIP_00103] [SWS_DoIP_00104] [SWS_DoIP_00105] [SWS_DoIP_00106] [SWS_DoIP_00107] [SWS_DoIP_00108] [SWS_DoIP_00109] [SWS_DoIP_00110] [SWS_DoIP_00111] [SWS_DoIP_00112] [SWS_DoIP_00113] [SWS_DoIP_00114] [SWS_DoIP_00116] [SWS_DoIP_00117] [SWS_DoIP_00118] [SWS_DoIP_00119] [SWS_DoIP_00120] [SWS_DoIP_00160] [SWS_DoIP_00161] [SWS_DoIP_00262] [SWS_DoIP_00295]





 \triangle

Requirement	Description	Satisfied by
[SRS_BSW_00407]	Each BSW module shall provide a function to read out the version information of a dedicated module implementation	[SWS_DoIP_00027]
[SRS_BSW_00411]	All AUTOSAR Basic Software Modules shall apply a naming rule for enabling/disabling the existence of the API	[SWS_DoIP_00027]

Table 6.1: Requirements Tracing



7 Functional specification

This specification provides the AUTOSAR representation of ISO 13400-2 as specified in the following chapters.

7.1 DoIP usage scenarios

This chapter gives only a brief overview of some use cases. For detailed information about DoIP usage scenarios please refer to ISO 13400-1.

The use cases for usage of DoIP differ from the single connection of external test equipment (see Figure 7.1) to a brought interconnectivity of the car or single ECUs with the environment (see Figure 7.2).




Figure 7.1: Connection of an external test equipment directly to the car (see ISO 13400-1 [7])



The DoIP is using for this interaction a protocol that executes several services within the single DoIP entities to fulfil the service related requirements of the DoIP ISO 13400 [7]:

Some of the DoIP services are exemplarily:

- Vehicle identification and announcement: Is necessary to detect who is participating in the DoIP communication
- Routing Activation: Allows that single Diagnostic Message pathes are activated or not to treat different protocols different (like UDS and OBD) and to also treat single testers different
- Node information: Provides general information of the single DoIP entity. Usually used by the testers to get the current DoIP protocol relevant information from the single DoIPEntities
- Alive mechanism: Is used to maintain different tester connections




Figure 7.2: Highly interconnected system of several Cars via the DoIP protocol (see ISO 13400-1 [7])

7.1.1 DolP Internal Tester Functionality Extension (DRAFT)

Note: Related to CONC_649 DoIP Extension. Everything that is implemented in this section is in DRAFT state.

This usecase covers the possibility of in vehicle DoIP communication. The tester(s) can also reside within the vehicle network.

The requirement to be able to communicate with EXTERNAL and INTERNAL test equipment via DoIP can be generalized as:



An ECU/DoIP node might be "multi-homed". I.e. it can have multiple logical IP interfaces (maybe sharing the same physical Ethernet interface/MAC address).

In this case, the ECU shall be able to "communicate" on each of its IP interfaces via DoIP independently. I.e. DoIP functionalities on each IP interface have to be isolated from each other. That f.i. means that:

- An "Activation-Line-Low" trigger is something restricted to a certain IP interface. So not ALL DoIP connections on ALL interfaces are closed down then, but just the one aggregated to the IP interface for which an "Activation-Line-Low" happened. (so each interface has its own logical activation line)
- During the routing activation, checks for a SA that has already been registered/activated shall also be restricted to that interface! So, it would be possible, that a tester with SA X can have a valid routing activation on two different interfaces (but not on two different connections of the same interface)

DoIP communication on the vehicle internal IP interface typically differs from the one on the external interface:

- Internal IP interface is typically always active/enabled through the lifecycle of the ECU
- Internal IP interface has typically a static IP address assigned.
- Internal IP interface therefore typically has no assigned "Activation-Line" semantics. I.e. on an abstract level for internal IP interface, the "Activation-Line" is always "high".

To break this down to the more general notion of "multi-homed" ECUs/DoIP nodes, this means:

There shall be the possibility for a DoIP module (CP or AP) to

- Configure on which interfaces it shall "work"
- Per interface configure
- o Whether Activation Line functionality plays a role/is needed
- o Whether dynamic IP assignment shall take place
- o Whether Vehicle announcement shall be done or not (and when it shall be done)

7.2 Connection establishment

This chapter describes the maintenance of the socket connections of the DoIP module

[SWS DoIP 00201]

Upstream requirements: RS_Diag_00081, RS_Diag_00028

The DoIP module shall determine the DoIP Activation Line status by the calls to DoIP ActivationLineSwitch (uint8 InterfaceId, boolean *Active) based on the value of



the boolean parameter Active per DolPInterface with a given Interfaceld. The Activation Line status is considered "active", if the boolean value in the call is set to TRUE. The Activation Line status is considered "inactive", if the boolean value in the call is set to FALSE.

[SWS DoIP 00202]

Upstream requirements: RS_Diag_00081, RS_Diag_00028

[If data is received from SoAd or PduR (i.e. communication related interfaces are called) via Pdulds related to a certain DolPInterface configured with DolPInterface-ActLineCtrl = TRUE, where the status of the Activation Line of this DolPInterface is currently inactive, the DolP module shall ignore all these requests and return a negative return value as return value.

Note: The return value depends on the API that is called. If it is Std_ReturnType it shall return E NOT OK, if it is BufReq ReturnType it shall return BUFREQ NOT OK.

[SWS DoIP 00204]

Upstream requirements: RS Diag 00081, RS Diag 00028

[For activation line controlled DoIP Interfaces with DoIPInterfaceActLineCtrl = TRUE, DoIP shall establish the corresponding connections for these interfaces according to [SWS_DoIP_00306] if corresponding Activation Line Status switches to "active". (SRS_Eth_00081, SRS_Eth_00028, SRS_Eth_00026).

[SWS DoIP 00296]

Upstream requirements: RS Diag 00081, RS Diag 00028

[For non activation line controlled DoIP Interfaces with DoIPInterfaceActLineCtrl = FALSE, DoIP shall establish the corresponding connections for these interfaces according to [SWS_DoIP_00306] in context of first call to DoIP_MainFunction(). (SRS_Eth_00081, SRS_Eth_00028, SRS_Eth_00026).]

[SWS DoIP 00234]

Upstream requirements: RS_Diag_00081, RS_Diag_00028

[If the Activation Line status of a DoIPInterface switches to "inactive", the DoIP module shall shall loop over all DoIPTcpConnection, DoIPUdpConnection, and DoIPUdpVehicleAnnouncementConnections. For each of these DoIPConnections the DoIP module shall retrieve the corresponding SoConId via call to the SoAd_GetSoConId and close all the connection by a call to SoAd_CloseSoCon with the retrieved SoConId.



[SWS DoIP 00235]

Upstream requirements: RS_Diag_00081, RS_Diag_00028

[In addition to [SWS_DoIP_00234], the DoIP module shall release the corresponding IP Address assignment via the call to SoAd_ReleaseIpAddrAssignment for those connections, which belong to the DoIPInterface for which the Activation Line status switched to "inactive", that have DoIPRequestAddressAssignment set to true.

[SWS DoIP 00306]

Upstream requirements: RS_Diag_00081, RS_Diag_00028

To open the socket connections (triggered by SWS_DoIP_00204 or SWS_DoIP_00296) of an DoIP interface the DoIP module shall loop over all its associated DoIPTcpConnection, DoIPUdpConnection and DoIPUdpVehicleAnnouncementConnections. For each DoIP connections belonging to respective DoIP Interfaces which has a DoIPRequestAddressAssignment set to true the DoIP module shall retrieve the corresponding SoConId via call to the SoAd_GetSoConId() and trigger the IP Address assignment via subsequent calls to SoAd_RequestIpAddrAssignment() with the retrieved SoConId, LocalIpAddrPtr and DefaultRouterPtr set to NULL_PTR, Netmask set to 0, and Type set to TCPIP_IPADDR_ASSIGNMENT_ALL. For each of these DoIP connections (irrespective of the value of DoIPRequestAddressAssignment) the DoIP module shall open the respective connection by an according call to SoAd_OpenSoCon(). (SRS_Eth_00081, SRS_Eth_00028, SRS_Eth_00026).]

[SWS_DoIP_00001]

Upstream requirements: RS Diag 00081

The DoIP module shall maintain the following information of the configured DoIPUd-pConnection (for UDP communication):

(a) State of the SocketConnection

[SWS DoIP 00002]

Upstream requirements: RS Diag 00081, RS Diag 00028

The DoIP module shall be able to maintain DoIPMaxTesterConnections configured connections with the following information:

- (a) DoIPSoAdTcpRxPduId, describes the connection to the SocketConnection
- (b) Source Address (SA) as soon as the information is available for the DoIP module
- (c) All Routing activation status of this socket connection
- (d) Status of the SocketConnection
- (f) Time since last TCP communication (Rx or Tx)
- (g) Information if the connection is active or not



[SWS DoIP 00241]

Upstream requirements: RS_Diag_00081, RS_Diag_00028

[If the DoIP module is called with DoIP_SoConModeChg and the Mode set to SOAD_SOCON_ONLINE the state of the socket connection shall be considered as online and the DoIP module shall behave as described in [SWS_DoIP_00143].

[SWS DoIP 00243]

Upstream requirements: RS_Diag_00081, RS_Diag_00028

[If the DoIP module is called with DoIP_SoConModeChg and the Mode set to something else than SOAD_SOCON_ONLINE the state of the socket connection shall be considered as offline and the DoIP module shall behave as described in [SWS_DoIP_00115].

[SWS_DoIP_00205]

Upstream requirements: RS_Diag_00026

[If the function DoIP_SoConModeChg is called with Mode set to SOAD_SOCON_ONLINE for a UDP vehicle announcement connection, the DoIP module shall send the vehicle announcement message via the corresponding Tx PDU configured in the DoIPUdpVehicleAnnouncementConnection and belonging to the reported socket connection.

[SWS DoIP 00058]

Upstream requirements: RS Diag 00081, RS Diag 00028, RS Diag 00083

[If a connection needs to be closed based on DoIP specific behavior, the DoIP module shall call the function SoAd_CloseSoCon with the parameter abort set to FALSE and the SoConId determined by a call to the function SoAd_GetSoConId for the corresponding DoIPSoAdTcpTxPdu. Additionally, the inactivity timer shall be stopped.

[SWS DoIP 00358]

Upstream requirements: RS_Diag_00081, RS_Diag_00028, RS_Diag_00083

[If a connection needs to be reset based on DoIP specific behavior, the DoIP module shall call the function SoAd_CloseSoCon with the parameter abort set to TRUE and the SoConId determined by a call to the function SoAd_GetSoConId for the corresponding DoIPSoAdTcpTxPdu. Additionally, the inactivity timer shall be stopped.]

[SWS DoIP 00076]

Upstream requirements: RS_Diag_00026

[If the parameter DoIPVinGidMaster is set to true and the Container DoIP-TriggerGIDSynchronization is configured, the DoIP module shall call the <User>_DoIPTriggerGIDSynchronization function (after successful IP Address assignment, see [SWS_DoIP_00306]) and repeat this call within the DoIP_MainFunction



until its return value equals to E_OK or until the complete connection is closed for any other reason.

[SWS DoIP 00085]

Upstream requirements: RS Diag 00028, RS Diag 00081

Γlf change in the IΡ address assignment indicated by DoIP LocallpAddrAssignmentChg with TCP lpAddrStateType another then TCPIP IPADDR STATE ASSIGNED, the function to start GID synchronisation as described in [SWS DoIP 00076] shall not be called any longer independent from the before return value.

[SWS_DoIP_00115]

Upstream requirements: RS_Diag_00028, RS_Diag_00081, RS_Diag_00083

[If a TCP socket connection gets closed (after the DoIP_SoConModeChg was called with different mode value than SOAD_SOCON_ONLINE or any other reason described by [SWS_DoIP_00058] or [SWS_DoIP_00358]) the DoIP module shall

- unregister and release the socket connection to the related Tester,
- discard the ongoing diagnostic message processing and
- reset the inactivity timer of the given socket connection.

Note: This includes cleaning up all the buffers/internal variables and scheduled asynchronous or pending function calls as well as reducing the amount of tester connected by 1.

[SWS DoIP 00142]

Upstream requirements: RS_Diag_00083

The DoIP module shall maintain an inactivity timer for each registered TCP connection.

[SWS_DoIP_00143]

Upstream requirements: RS_Diag_00083

[After a successful TCP socket connection (i.e. DoIP_SoConModeChg) the DoIP module shall start the inactivity timer.]

[SWS DoIP 00144]

Upstream requirements: RS_Diag_00083

[If no Routing Activation request was received on a new opened socket within the configured DolPInitialInactivityTime, the DolP module shall reset the socket connection as described in [SWS_DolP_00358].]



[SWS DoIP 00159]

Upstream requirements: RS Diag 00083

[If a Routing Activation request was received on a new opened socket before the inactivity timer elapsed (i.e. the configured DoIPInitialInactivityTime did not pass) the DoIP module shall reset the inactivity timer to 0.

[SWS_DoIP_00145]

Upstream requirements: RS_Diag_00083

[After a routing activation has been performed (see [SWS_DoIP_00159]), the DoIP module shall reset the inactivity timer to 0 always when data communication is performed on the socket (send or receive).

[SWS DoIP 00146]

Upstream requirements: RS_Diag_00083

[If the inactivity timer reaches the time configured in DoIPGeneralInactivityTime, the corresponding socket connection shall be reset as described in [SWS_DoIP_00358].

[SWS_DoIP_00154]

Upstream requirements: RS_Diag_00047

[If the API DoIP_LocalIpAddrAssignmentChg is called with the State set to TCPIP_IPADDR_STATE_ASSIGNED, the DoIP module shall call the function SoAd_ReadDhcpHostNameOption with the received SoConId to get the currently set host name option. The returned Byte buffer shall be considered as ASCII buffer and shall start with "DoIP-".|

[SWS_DoIP_00155]

Upstream requirements: RS_Diag_00047

[If the ASCII buffer returned in [SWS_DoIP_00154] does not start with "DoIP-" and the configuration parameter DoIPDhcpOptionVinUse is set to FALSE the DoIP module shall call the SoAd_WriteDhcpHostNameOption with a pointer to the string "DoIP-" in order to set the hostname.

[SWS_DoIP_00156]

Upstream requirements: RS_Diag_00047

[If the ASCII buffer returned in [SWS_DoIP_00154] does not start with "DoIP-" and the configuration parameter DoIPDhcpOptionVinUse is set to TRUE the DoIP module shall call the SoAd_WriteDhcpHostNameOption with a pointer to to the ASCII buffer "DoIP-VIN
vinnumberinascii>" with <vinnumberinascii> representing the ASCII representation of the VIN that is retrieved via Dcm_GetVin. If no valid VIN could be retrieved the DoIP shall use the configured DoIPVinInvalidityPattern in ASCII representation.]



[SWS DoIP 00294]

Upstream requirements: RS_Diag_00084

[When receiving a routing activation request on a TCP connection where DoIPTcp-Connection/DoIPTcpConnectionSecurityRequired is not set or set to FALSE, the DoIP module shall search for a DoIPTester with an assigned container that matches DoIPTesterSA. If such a DoIPTester container was found and the matching DoIPRoutingActivation container (refer to [SWS_DoIP_00108]) has the attribute DoIPRoutingActivationSecurityRequired not set or set to FALSE, the connection will be established.

If such a DoIPTester container was found and the matching DoIPRoutingActivation container (refer to [SWS_DoIP_00108]) has the attribute DoIPRoutingActivationSecurityRequired is set to TRUE, the connection shall be rejected with the response code "0x07".|

[SWS DoIP 00295]

Upstream requirements: RS Diag 00084

[When receiving a routing activation request on a TCP connection where DoIPTcp-Connection/DoIPTcpConnectionSecurityRequired set to TRUE, the DoIP module shall search for a DoIPTester with an assigned container that matches DoIPTesterSA.

If such a DoIPTester container was found, the connection will be established.

Rationale: A secure TCP connection can be established with a DoIPTester that requests a secure or unsecured connection.

7.3 DoIP Message layout according ISO 13400-2

A DoIP message can be identified by its generic DoIP header structure, which is described in the chapter 7.3.1.

7.3.1 Generic DoIP header

All Pdus received or sent via the SoAd shall support the the DoIP header structure as defined in the ISO 13400-2 [7] table 11. The DoIP header is described in this chapter.

[SWS_DoIP_00004]

Upstream requirements: RS Diag 00025

The first 8 Bytes of a DoIP message shall contain the DoIP Header followed by the actual payload data.

1



Item	Position (Byte)	Length (Byte)	
Generic DoIP header synchronization pattern			
Protocol version	0	1	
Inverse protocol version	1	1	
Generic DoIP payload type and payload length			
Payload type	2	2	
Payload length	4	4	
Payload type specific message content	8		

Table 7.1: DoIP message Generic header Layout

[SWS DoIP 00005]

Upstream requirements: RS_Diag_00025

[Byte 0 of the DoIP header shall contain the protocol version e.g. 0x02.]

[SWS_DoIP_00333] Used DoIP protocol version [The DoIP module shall use the configured DoIPProtocolVersion [ECUC_DoIP_00102] as DoIP protocol version in all generic headers of send DoIP messages.

[SWS_DoIP_00006]

Upstream requirements: RS Diag 00025

[The Byte 1 of the DoIP header shall contain the inverse protocol version e.g. 0xFD value shall be added if the protocol version is 0x02.]

[SWS_DoIP_00321]

Upstream requirements: RS_Diag_00025

[If config parameter DoIP_ISO13400_2_2012 is enabled, the DoIP entity shall accept received frames with protocol version 0x02.]

[SWS_DoIP_00322]

Upstream requirements: RS Diag 00025

[If config parameter DoIP_ISO13400_2_2019 is enabled, the DoIP entity shall accept received frames with protocol version 0x03.]

[SWS_DoIP_00323] [If a routing activation request with protocol version 0x02 was received on an unsecured connection to activate a secured route, then the DoIP entity shall send back the routing activation response 0x06 and close this socket connection according to [SWS_DoIP_00058].]



[SWS_DoIP_00324] [The DoIP entity shall use the protocol version configured in DoIPAnnouncedProtocolVersion as advertised protocol version in vehicle announcements.]

[SWS_DoIP_00325] [If a vehicle identification request was received with protocol version 0xFF, the DoIP entity shall use the protocol version configured in DoIPAnnounced-ProtocolVersion as protocol version in the vehicle identification response.]

[SWS_DoIP_00326] For transmission of DoIP responses over Tcp, the DoIP entity shall use the same protocol version as received and extracted from the first request of this tester.

[SWS_DoIP_00327] For transmission of DoIP responses over UDP, the DoIP entity shall use the same protocol version as received and extracted from the request.

[SWS DoIP 00007]

Upstream requirements: RS_Diag_00025

[Byte 2 and Byte 3 shall contain the PayloadType.]

[SWS_DoIP_00008]

Upstream requirements: RS_Diag_00025

The following PayloadTypes shall be supported for reception of DoIP messages:

Payload Type value	Payload type name	Chapter in DoIP SWS	Connection Kind
0x0000	Generic DoIP header negative acknowledge	7.3.2.1	UDP/TCP
0x0001	Vehicle Identification request message	7.3.2.2.1	UDP
0x0002	Vehicle identification request message with EID	7.3.2.2.2	UDP
0x0003	Vehicle identification request message with VIN	7.3.2.2.3	UDP
0x0004	Vehicle announcement message/vehicle identification response message	7.3.2.2.1	UDP
0x0005	Routing activation request	7.3.2.3.1	TCP
0x0008	Alive Check response	7.3.2.4.2	TCP
0x4001	DoIP entity status request	7.3.2.5.3	UDP
0x4003	Diagnostic power mode information request	7.3.2.5.1	UDP
0x8001	Diagnostic message	7.3.2.6.1	TCP

Table 7.2: DoIP payload types received by a DoIP entity, chapter reference and the connection type they are received on



[SWS DoIP 00009]

Upstream requirements: RS_Diag_00025

The following PayloadTypes shall be supported for sending of DoIP messages:

|

Payload Type value	Payload type name	Chapter in DoIP SWS	Connection Kind
0x0000	Generic DoIP header negative acknowledge	7.3.2.1	UDP/TCP
0x0004	Vehicle announcement message/vehicle identification response	7.3.2.2.4	UDP
0x0006	Routing activation response	7.3.2.3.2	TCP
0x0007	Alive Check request	7.3.2.4.1	TCP
0x4002	DoIP entity status response	7.3.2.5.4	UDP
0x4004	Diagnostic power mode information response	7.3.2.5.2	UDP
0x8002	Diagnostic message positive acknowledgement	7.3.2.6.2	TCP
0x8003	Diagnostic message negative acknowledgement	7.3.2.6.3	TCP

Table 7.3: DoIP payload types transmitted by a DoIP entity, chapter reference and the connection type they are transmitted on

[SWS_DoIP_00010]

Upstream requirements: RS Diag 00025

[Bytes 4 to 7 shall contain the payload length in Bytes not including the length of the DoIP header information (i.e. if a DoIP message is received with Payload length set to 2 it means that 10 Bytes in total were received).

7.3.2 Payload types

This chapter describes the different Payload types in detail.

7.3.2.1 Generic acknowledge

This chapter contains the check of the DoIP header with the according negative acknowledge messages with payload type 0x0000 for an invalid DoIP header.



[SWS DoIP 00012]

Upstream requirements: RS_Diag_00025

[If an invalid DoIP header was received, a DoIP message with payload type 0x0000 shall be transmitted with the payload described in [SWS_DoIP_00013] on the TxPdu which is related to the RxPdu the message was received on, if the according Socket-Connection status has not changed since the reception of the DoIP message

[SWS DoIP 00013]

Upstream requirements: RS_Diag_00025

[The payload of the generic DoIP header shall contain the corresponding NACK code (1 Byte) as specified from [SWS DoIP 00014] to [SWS DoIP 00019].

[SWS DoIP 00014]

Upstream requirements: RS_Diag_00025

[SWS_DoIP_00006], [SWS_DoIP_00321], [SWS_DoIP_00322], and [SWS_DoIP_00015] for valid information) the NACK code 0x00 shall be sent and the according socket shall be closed (see [SWS_DoIP_00058]).

[SWS DoIP 00016]

Upstream requirements: RS Diag 00025

[If a payload type is not supported (see [SWS_DoIP_00008] for valid payload types) the DoIP module shall send the NACK code 0x01 to indicate that an unknown payload type was requested. The message shall be discarded for further processing. For TCP_DATA socket connections, this NACK shall only be sent as response in the ISO 13400 connection state "Registered [Routing Active]".

[SWS DoIP 00017]

Upstream requirements: RS Diag 00025

[If the payload length exceeds the value configured by DoIPMaxRequestBytes, the DoIP module shall send the NACK code 0x02 to indicate that the message is too large. The message shall be discarded for further processing. For TCP_DATA socket connections, this NACK shall only be sent as response in the ISO 13400 connection state "Registered [Routing Active]".]

[SWS_DoIP_00018]

Upstream requirements: RS_Diag_00025

[If the DoIP module is called with DoIP_SoAdTpStartOfReception() and the indicated payload length exceeds the currently available buffer size, the function must return with BUFREQ_E_OVFL value (No buffer of the required length can be provided) and trigger a Negative Response (NACK) with value 0x03.



The currently available buffer size calculation shall be based on Payload Type. If the DoIP message is processed internally (see [SWS_DoIP_00008]) the locally available buffer, other case the upper layer (PduR_DoIPTpStartOfReception) provided buffer size shall be the base for the response. For TCP_DATA socket connections, this NACK shall only be sent as response in the ISO 13400 connection, state "Registered [Routing Active]".|

[SWS DoIP 00019]

Upstream requirements: RS_Diag_00025

[If the DoIP module is called with a payload length that is not valid for the specific payload type, the NACK code 0x04 shall be sent and the corresponding connection shall be closed (see [SWS_DoIP_00058]). For TCP_DATA socket connections, this NACK shall be sent as response for payload type "Routing Activation Request" in any ISO 13400 connection state and for payload type "Alive Check Response" in any ISO 13400 connection state "Registered".

All other DoIP messages received on the TCP_DATA socket connections shall only be responded in the ISO 13400 connection state "Registered [Routing Active]".

Note: The single valid payload length ranges for the single payload types are described in the single subchapters of the payloads (see [SWS_DoIP_00008] for the list of all receive payload types and the according chapter references).

[SWS DoIP 00292]

Upstream requirements: RS Diag 00025

[If a DoIP message with payload Type 0x0000 is received on a configured DoIPUdp-Connection or DoIPTcpConnection, the message shall be discarded.]

7.3.2.2 Vehicle Identification

[SWS_DoIP_00015]

Upstream requirements: RS_Diag_00026

[On a vehicle identification request the Protocol Type 0xFF and the inverse Protocol Type 0x00 shall be supported as default values, additionally to the ProtocolType described in [SWS_DoIP_00005] and [SWS_DoIP_00006].



7.3.2.2.1 Vehicle Identification request (payload type 0x0001)

[SWS DoIP 00061]

Upstream requirements: RS_Diag_00026

[When the module receives a DoIP message with payload type 0x0001 on a connection different than a configured DoIPUdpConnection, the module shall discard the DoIP message.]

Note: This also means that it is not allowed to receive this payload type on a TCP connection.

[SWS DoIP 00059]

Upstream requirements: RS_Diag_00026

The expected payload length (see [SWS_DoIP_00019]) for vehicle identification request message with payload type 0x0001 shall be exactly 0.

[SWS DoIP 00060]

Upstream requirements: RS_Diag_00026

[If a DoIP message with payload Type 0x0001 is received on the configured DoIPUd-pConnection, the DoIP module shall respond with a vehicle identification response/vehicle announcement message after the configured DoIPInitialVehicleAnnouncement-Time with payload type 0x0004.]

7.3.2.2.2 Vehicle Identification request with EID (payload type 0x0002)

The payload data structure of a vehicle identification request message with EID shall be supported as described in Table 7.4:

Item	Position (Byte)	Length (Byte)	
Payload type vehicle identification request message with EID			
EID	0	6	

Table 7.4: Vehicle identification request with EID payload data

[SWS_DoIP_00062]

Upstream requirements: RS Diag 00026

[When the module receives a DoIP message with payload Type 0x0002 on a connection different than a configured DoIPUdpConnection, the module shall discard the DoIP message.]



Note: This also means that it is not allowed to receive this payload type on a TCP connection.

[SWS DoIP 00063]

Upstream requirements: RS Diag 00026

The expected payload length (see [SWS_DoIP_00019]) for vehicle identification request message with payload type 0x0002 shall be exactly 6.

[SWS_DoIP_00064]

Upstream requirements: RS_Diag_00026

[If a DoIP message with payload Type 0x0002 is received on the configured DoIPUd-pConnection, the DoIP module shall further process the message.]

[SWS DoIP 00065]

Upstream requirements: RS_Diag_00026

[If the Parameter DoIPUseMacAddressForIdentification is set to true the received "EID" 6 payload data bytes shall be compared to the MacAddress received via SoAd_GetPhysAddr. If they match the DoIP module shall respond with a vehicle identification response/vehicle announcement message with payload type 0x0004.]

[SWS DoIP 00066]

Upstream requirements: RS Diag 00026

[If the Parameter DoIPUseMacAddressForIdentification is set to false the received "EID" 6 payload data bytes shall be compared to the configured DoIPEid. If they match the DoIP module shall respond with a vehicle identification response/vehicle announcement message with payload type 0x0004.

7.3.2.2.3 Vehicle Identification request with VIN (payload type 0x003)

The payload data structure of a vehicle identification request message with VIN shall be supported as described in Table 7.5:

Item	Position (Byte)	Length (Byte)	
Payload type vehicle identification request message with VIN			
VIN	0	17	

Table 7.5: Vehicle identification request with VIN payload data



[SWS DoIP 00067]

Upstream requirements: RS_Diag_00026

[When the module receives a DoIP message with payload Type 0x0003 on a connection different than a configured DoIPUdpConnection, the module shall discard the DoIP message.]

Note: This also means that it is not allowed to receive this payload type on a TCP connection.

[SWS DoIP 00068]

Upstream requirements: RS_Diag_00026

[The expected payload length (see [SWS_DoIP_00019]) for vehicle identification request message with payload type 0x0003, shall be exactly 17.

[SWS DoIP 00069]

Upstream requirements: RS_Diag_00026

[If a DoIP message with payload Type 0x0003 is received on the configured DoIPUd-pConnection the DoIP module shall further process the message.]

[SWS_DoIP_00070]

Upstream requirements: RS_Diag_00026

The DoIP 17 payload data bytes shall be compared to the data retrieved by the function Dcm_GetVin. If the function returns E_OK, the VIN pointer is considered to contain valid information. If the function returns E_NOT_OK or the returned VIN do not match the requested VIN, the DoIP message with payload Type 0x0003 shall be ignored. If the requested VIN matches the derived VIN, the DoIP module shall respond with a vehicle identification response/vehicle announcement message with payload type 0x0004.

7.3.2.2.4 Vehicle Identification response/vehicle announcement (payload type 0x0004)

[SWS_DoIP_00297]

Upstream requirements: RS_Diag_00081, RS_Diag_00028

[For a DoIP Interface with DoIPInterfaceAnnouncementStart = DOIP_AUTOMATIC_ANNOUNCE, the DoIP module shall start Vehicle announcement according to [SWS_DoIP_00205].



[SWS DoIP 00298]

Upstream requirements: RS_Diag_00081, RS_Diag_00028

[For a DoIP Interface with DoIPInterfaceAnnouncementStart = DOIP_ONTRIGGER_ANNOUNCE, the sending of vehicle announcement only starts if DoIP_TriggerVehicleAnnouncement () has been called for that Interface.]

[SWS_DoIP_00299] [If DoIP_TriggerVehicleAnnouncement() is called, but the corresponding socket is not yet ONLINE then the request shall be remembered and vehicle announcement shall be sent as soon as the socket goes ONLINE.|

[SWS DoIP 00071]

Upstream requirements: RS Diag 00026

[SWS_DoIP_00205] and [SWS_DoIP_00298]), it shall send the vehicle announcement message (see [SWS_DoIP_00205] and [SWS_DoIP_00298]), it shall send the vehicle announcement message via the configured DoIPUdpVehicleAnnouncementConnection after DoIPInitialVehicleAnnouncementTime. This message shall be sent DoIPVehicleAnnouncementCount times with a delay of DoIPVehicleAnnouncementInterval between each message. The last "VIN/GID Status" byte of the Vehicle identification response message is optional as defined in the ISO 13400-2 standard. It shall exist only if the "DoIPUseVehicleIdentificationSyncStatus" configuration parameter is set to True. (See [SWS_DoIP_00086]).]

The payload data structure of a vehicle identification response/vehicle announcement message shall be supported as described in Table 7.6.

Item	Position (Byte)	Length (Byte)	
Vehicle identification number			
VIN	0	17	
DoIP entity logical address information			
Logical Address	17	2	
Entity identification			
EID	19	6	
Group identification			
GID	25	6	
Further action byte	31	1	
VIN/GID Status	32	1	

Table 7.6: Vehicle identification response/vehicle announcement message payload data

[SWS DoIP 00072]

Upstream requirements: RS Diag 00026

[The "VIN" of a vehicle identification response/vehicle announcement message shall be derived by calling Dcm_GetVin. If Dcm_GetVin returns E_OK, the 17 Bytes in the pointer shall be used, if the callback returns E_NOT_OK the 17 Bytes shall be filled with



the configured DoIPVinInvalidityPattern with "Further Action Required" field set to 0x00 and VIN/GID sync. Status field set to 0x10 if (DoIPUseVehicleIdentificationSyncStatus) is set to true.

[SWS DoIP 00073]

Upstream requirements: RS_Diag_00026

The "LA" of a vehicle identification response/vehicle announcement message shall contain the configured DoIPLogicalAddress.

[SWS DoIP 00074]

Upstream requirements: RS_Diag_00026

[The "EID" of a vehicle identification response/vehicle announcement message of a DolPInterface shall contain the MAC address derived by SoAd_GetPhysAddr() if the corresponding configuration parameter DolPUseMacAddressForIdentification is set to true.

[SWS DoIP 00075]

Upstream requirements: RS_Diag_00026

[The "EID" of a vehicle identification response/vehicle announcement message of a DoIPInterface shall contain the configured <code>DoIPEid</code> if the corresponding configuration parameter <code>DoIPUseMacAddressForIdentification</code> is set to false.

[SWS DoIP 00077]

Upstream requirements: RS Diag 00026

[The "GID" of a vehicle identification response/vehicle announcement message shall contain the same value as the EID used in the interface referenced by DoIPUseEidAs-GidRef.]

[SWS DoIP 00078]

Upstream requirements: RS Diag 00026

[The "GID" of a vehicle identification response/vehicle announcement message shall contain the configured DoIPGID value, if the configuration parameter DoIPVinGidMaster is set to true, the configuration reference DoIPUseEidAsGidRef is disabled.

[SWS DoIP 00079]

Upstream requirements: RS_Diag_00026

[The "GID" of a vehicle identification response/vehicle announcement message shall contain the value retrieved by the configured DoIPGetGidCallback function(for the signature see <User>_DoIPGetGidcallback, [SWS_DoIP_00051]), if the configuration parameter DoIPVinGidMaster is set to true, the configuration parameter DoIPUseEIDas-GID is set to false and the parameter DoIPGID is not configured. If the function does



not return E_OK the GID shall consist of 6 Bytes according to the configured DoIPGID-InvalidityPattern.

[SWS DoIP 00080]

Upstream requirements: RS Diag 00026

[The "GID" of a vehicle identification response/vehicle announcement message shall contain the configured DoIPGID value, if the configuration parameter DoIPVinGidMaster is set to false and the parameter DoIPGID is configured.

[SWS DoIP 00081]

Upstream requirements: RS_Diag_00026

[The "GID" of a vehicle identification response/vehicle announcement message shall contain the value retrieved by the configured DoIPGetGID function, if the configuration parameter DoIPVinGidMaster is set to false and the parameter DoIPGID is not configured. If the function does not return E_OK, the GID shall consist of 6 Bytes according to the configured DoIPGIDInvalidityPattern.

[SWS_DoIP_00082]

Upstream requirements: RS Diag 00026

[The "Further action" byte of a vehicle identification response/vehicle announcement message shall contain the value 0x10 if any DoIPRoutingActivation with DoIPRoutingActivationNumber equal to 0xE0 is configured and the according RoutingActivation was not yet successfully performed.]

[SWS DoIP 00083]

Upstream requirements: RS_Diag_00026

The "Further action" byte of a vehicle identification response/vehicle announcement message shall contain the value 0x00, if no DoIPRoutingActivation with DoIPRoutingActivationNumber equal to 0xE0 is configured.

[SWS DoIP 00084]

Upstream requirements: RS_Diag_00026

[The "Further action" byte of a vehicle identification response/vehicle announcement message shall contain the value 0x00, if any DoIPRoutingActivation with DoIPRoutingActivationNumber equal to 0xE0 is configured and the according RoutingActivation was successfully performed.



[SWS DoIP 00086]

Upstream requirements: RS Diag 00026

[If the configuration parameter DoIPUseVehicleIdentificationSyncStatus is set to true, the "VIN/GID status" byte shall be additionally added to the vehicle identification response/vehicle announcement message.

[SWS DoIP 00087]

Upstream requirements: RS_Diag_00026

[If a valid VIN could be requested in [SWS_DoIP_00072], the value of the "VIN/GID status" byte shall be 0x00.

[SWS_DoIP_00088]

Upstream requirements: RS Diag 00026

[If no valid VIN could be requested in [SWS_DoIP_00072] and the vehicle GID synchronization was not yet successful as described in [SWS_DoIP_00076], the value of the "VIN/GID status" byte shall be 0x10.

[SWS_DoIP_00089]

Upstream requirements: RS_Diag_00026

[If no valid VIN could be requested in [SWS_DoIP_00072] and the vehicle GID synchronization was already successful as described in [SWS_DoIP_00076], the value of the "VIN/GID status" byte shall be 0x00.

[SWS DoIP 00291]

Upstream requirements: RS_Diag_00026

[The "Further action" byte of a vehicle identification response/vehicle announcement message shall contain the 1 Byte value retrieved by a call to the configured DoIPFurtherActionByteCallback (if configured, for the signature see <User>_DoIPGetFurtherActionByteCallback, [SWS_DoIP_00288]). If the function returns E_OK, the "Further action" byte shall be set to the retrieved value of Further-ActionByte. If the function returns E_NOT_OK, the "Further action" byte shall be set according to [SWS_DoIP_00082], [SWS_DoIP_00083] or [SWS_DoIP_00084].]

[SWS DoIP 00293]

Upstream requirements: RS Diag 00025

[If a DoIP message with payload Type 0x0004 is received on a configured DoIPUdp-Connection, the message shall be discarded.]



7.3.2.3 Routing activation

7.3.2.3.1 Routing activation request (payload type 0x0005)

The payload data structure of a routing activation request message shall be supported as described in Table 7.7:

Item	Position (Byte)	Length (Byte)	
External test equipment address inform	External test equipment address information		
Source address	0	2	
Activation Type	2	1	
Reserved and OEM specific data			
Reserved by the ISO (0x00000000)	3	4	
OEM specific	7	4	

Table 7.7: Routing activation request message payload data

[SWS DoIP 00101]

Upstream requirements: RS Diag 00084

[When the module receives a DoIP message with payload Type 0x0005 on a connection different than a configured DoIPTcpConnection, the module shall discard the DoIP message.]

Note: That means that it is also not allowed to receive this payload type on a UDP connection,

[SWS DoIP 00117]

Upstream requirements: RS_Diag_00084

[The expected payload length (see [SWS_DoIP_00019]) for Routing Activation Request Message with payload type 0x0005 shall be either exactly 7 or 11.|

[SWS_DoIP_00102]

Upstream requirements: RS_Diag_00084

[If a routing activation request message is received with a valid DoIP header, the DoIP module shall process further to [SWS_DoIP_00103], if the field "Source address" matches a configured DoIPTesterSA.

[SWS_DoIP_00106]

Upstream requirements: RS Diag 00084

[If a routing activation request message is received with a valid "Source address" but the connection this Routing activation was received on is already Registered [Routing Active] to another source address, the DoIP module shall send a routing activation response message on the same connection the request was received on, with the



routing activation response code set to 0x02. Additionally, the socket connection shall be closed as defined in [SWS_DoIP_00058].

[SWS DoIP 00104]

Upstream requirements: RS_Diag_00084

[If a routing activation request message is received with a "Source address" that does not match a configured DoIPTesterSA, the routing activation response message shall be sent on the same connection as the received request with the routing activation response code 0x00. Additionally the socket connection shall be closed as defined in [SWS_DoIP_00058].]

[SWS DoIP 00103]

Upstream requirements: RS_Diag_00084

[The DoIP module shall always continue with processing as defined in [SWS_DoIP_00105], either if the received "Source Address" is already registered to a connection as described in [SWS_DoIP_00002] and it is the same socket connection this routing activation request was received on, or if the received "Source Address" is not registered to a connection yet.

[SWS_DoIP_00105]

Upstream requirements: RS_Diag_00084, RS_Diag_00083

[If the received "Source Address" is already registered to another connection, belonging to the same DolPInterface, an alive check request to this connection shall be triggered as described in [SWS_DolP_00139] and [SWS_DolP_00140] and it shall be waiting for the alive check response message or until the time configured in parameter DolPAliveCheckResponseTimeout expired. If the alive check response was received within the configured time, the DolP module shall send a routing activation response message with the activation response code set to 0x03. Additionally the socket connection shall be closed as defined in [SWS_DolP_00058]. If the "Source Address" is not already registered or the DolPAliveCheckResponseTimeout expired without receiving an alive check response message the DolP module shall continue with [SWS_DolP_00107].]

[SWS DoIP 00107]

Upstream requirements: RS_Diag_00084, RS_Diag_00083

[If the amount of registered connections is smaller than the configured DolPMax-TesterConnections, the DolP module shall proceed with the message as described in [SWS_DolP_00108] otherwise an alive check request shall be sent to all registered connections as described in [SWS_DolP_00139] and [SWS_DolP_00140]. If none of the alive checks times out (i.e. all tester respond with a valid alive check response within the configured DolPAliveCheckResponseTimeout) the DolP module shall send a routing activation response message with the activation response code set to 0x01.



Additionally the socket connection shall be closed as defined in [SWS_DoIP_00058]. If at least one of them times out the DoIP module shall close the socket connection and continue as described in [SWS_DoIP_00108].

[SWS DoIP 00108]

Upstream requirements: RS Diag 00084

[If the "Activation type" bytes matches the DoIPRoutingActivationNumber of one of the DoIPRoutingActivationRef of the "Source Address" (i.e. DoIPTester has a DoIPRoutingActivationRef configured which has the DoIPRoutingActivationNumber equal to "Activation type") the DoIP module shall proceed with [SWS DoIP 00109].

[SWS DoIP 00160]

Upstream requirements: RS_Diag_00084

[If the "Activation type" bytes do not fulfill the [SWS_DoIP_00108] requirement, the DoIP module shall send a routing activation response message with the activation response code set to 0x06. In this case the socket connection shall be closed as defined in [SWS_DoIP_00058].

[SWS_DoIP_00109]

Upstream requirements: RS_Diag_00084

[If an DoIPRoutingActivationAuthenticationCallback is configured for the referenced DoIPRoutingActivation, the DoIP module shall call this callback (for the signature see <User>_DoIPRoutingActivationAuthentication, [SWS_DoIP_00049]). If the DoIPRoutingActivationAuthenticationReqLength is not configured to 0, the DoIP module shall handle additionally the first DoIPRoutingActivationAuthenticationReqLength bytes of the optional field "OEM specific".]

[SWS DoIP 00161]

Upstream requirements: RS_Diag 00084

[If the DolPRoutingActivationAuthenticationCallback returns with E_OK the routing activation authentication shall be considered as successful. If the DolPRoutingActivationAuthenticationResLength is not set to 0 the first DolPRoutingActivationAuthenticationResLength byte shall be attached in routing activation response message in the field "OEM specific" as described in [SWS_DolP_00120].

[SWS DoIP 00110]

Upstream requirements: RS Diag 00084

[If the DoIPRoutingActivationAuthenticationCallback returns DOIP_E_PENDING, the DoIP module shall trigger the callback at next DoIP_MainFunction calls again until



something else than DOIP_E_PENDING is returned. Additionally, the socket connection shall be considered as registered to this DoIPTesterSA without activating the routing. In this case, the connection is in ISO 13400 connection state "Registered[Pending for Authentication]".

[SWS DoIP 00111]

Upstream requirements: RS Diag 00084

[If the DoIPRoutingActivationAuthenticationCallback returns something else (e.g. E_NOT_OK) the DoIP module shall send a routing activation response message with the activation response code set to 0x04 and the socket connection shall be considered as registered to this DoIPTesterSA without activating the routing.]

[SWS_DoIP_00112]

Upstream requirements: RS_Diag_00084

[If a DoIPRoutingActivationConfirmationCallback is configured for the referenced DoIPRoutingActivation, the DoIP module shall call this callback (for the signature see <User>_DoIPRoutingActivationConfirmation, [SWS_DoIP_00048]). If the DoIPRoutingActivationConfirmationReqLength is not configured to 0, the DoIP module shall handle additionally the last DoIPRoutingActivationConfirmationReqLength bytes of the optional field "OEM specific". If the Callback returns with E_OK the routing activation confirmation shall be considered as successful and if the DoIPRoutingActivationConfirmationResLengthis not set to 0, the last DoIPRoutingActivationConfirmationResLength bytes shall be attached in routing activation response message in the field "OEM specific" as described in [SWS_DoIP_00120].

[SWS DoIP 00114]

Upstream requirements: RS Diag 00084

[If the DoIPRoutingActivationConfirmationCallback returns DOIP_E_PENDING, the DoIP module shall send a routing activation response message once with the routing activation response code set to 0x11. In this case, the connection is in ISO 13400 connection state "Registered [Pending for Confirmation]".|

[SWS DoIP 00274]

Upstream requirements: RS Diag 00084

[If the DoIPRoutingActivationConfirmationCallback returns E_NOT_OK, the DoIP module shall send a routing activation response message with the activation response code set to 0x05 and the socket connection shall be closed as defined in [SWS_DoIP_00058].]



[SWS DoIP 00113]

Upstream requirements: RS Diag 00084

[If no response was sent because of the before mentioned checks, this DoIPRoutingActivation is confirmed, authorized and valid. A routing activation response message shall be sent with the activation response code set to 0x10 and the socket connection shall be considered as Registered [Routing Active] to this DoIPTesterSA and enable the routing for this routing activation.

Note: From now on the routing to the configured DoIPTargetAdressRef are activated and valid so the diagnostic request messages related to the specified DoIPTargetAdress received via this socket connection are routed to the respective target address.

[SWS_DoIP_00330] [The DoIP module shall silently discard any message other than routing activation request message or messages required for authentication or confirmation received on a socket connection in any ISO 13400 connection state other than "Registered [Routing Active]".

Exceptions are:

- The protocol version or inverse protocol version check. If this check fails it shall always be responded and handled according to [SWS_DoIP_00014].
- Alive check response is valid in any ISO 13400 connection state "Registered".
 Generic header checks for this payload type shall be responded.

╛

7.3.2.3.2 Routing activation response (payload type 0x0006)

The payload data structure of a routing activation response message shall be supported as described in Table 7.8:

Item	Position (Byte)	Length (Byte)		
External test equipment address information	External test equipment address information			
Logical Address Tester	0	2		
Routing activation status information				
Logical address of DoIP entity	2	2		
Routing activation response code	4	1		
Reserved by ISO (0x00000000)	5	4		
OEM specific	9	4		

Table 7.8: Routing activation response message payload data



[SWS DoIP 00116]

Upstream requirements: RS_Diag_00084

The "Logical Address Tester" field shall be set to the Tester SA the according routing activation request message was received from.

[SWS_DoIP_00118]

Upstream requirements: RS_Diag_00084

The "Logical Address DoIP entity" shall be set to the configured parameter DoIPLogicalAddress.

[SWS DoIP 00119]

Upstream requirements: RS_Diag_00084

[The "Routing activation response code shall be set according to the response conditions specified in [SWS_DoIP_00106], [SWS_DoIP_00104], [SWS_DoIP_00105], [SWS_DoIP_00107], [SWS_DoIP_00160], [SWS_DoIP_00111], [SWS_DoIP_00114], [SWS_DoIP_00274] and [SWS_DoIP_00113].]

[SWS_DoIP_00120]

Upstream requirements: RS_Diag_00084

[If the DoIPRoutingActivationAuthenticationResLength and/or DoIPRoutingActivation-ConfirmationResLength are used (different from zero), the "OEM specific" field shall be filled with the specified length data.

Note: see details of the RoutingActivation request and response structures in 7.3.2.3.

7.3.2.4 Alive check

7.3.2.4.1 Alive check request (payload type 0x0007)

[SWS DoIP 00139]

Upstream requirements: RS_Diag_00083

[If the DoIP module needs to send a alive check request, it shall have no payload data but only the generic DoIP header and the payload type set 0x0007.]

[SWS DoIP 00140]

Upstream requirements: RS Diag 00083

[After sending an alive check request the DoIP module shall wait the configured time DoIPAliveCheckResponseTimeout to receive a valid alive check response and



[SWS_DoIP_00141]. If it does not receive an alive check response, the socket connection on which the alive check request was sent shall be reset as described in [SWS_DoIP_00358].]

7.3.2.4.2 Alive check response (payload type 0x0008)

The payload data structure of a alive check response message shall be supported as described in Table 7.9:

Item	Position (Byte)	Length (Byte)	
External test equipment address information			
Source address 0 2			

Table 7.9: Alive check response message payload data

[SWS DoIP 00141]

Upstream requirements: RS Diag 00083

[If an Alive check response is received on a socket connection which is in any ISO 13400 connection state "Registered" and the field "SourceAddress" matches the registered Source Address of this socket connection, then the DoIP module shall reset the general inactivity timer.

Note: The alive check response can always be sent (not only after an according request): With this method the test equipment can reset the inactivity time.

[SWS_DoIP_00332] [If an Alive check response is received on a socket connection which is in any ISO 13400 connection state "Registered" and the field "SourceAddress" does not match the registered Source Address of this socket connection, then the socket connection shall be closed as described in [SWS_DoIP_00058].

7.3.2.5 Node information

7.3.2.5.1 Diagnostic power mode information request (payload type 0x4003)

[SWS DoIP 00090]

Upstream requirements: RS Diag 00080

[When the module receives a DoIP message with payload Type 0x4003 on a connection different than a configured DoIPUdpConnection, the module shall discard the DoIP message.]



Note: This means also that it is not allowed to receive this payload type on a TCP connection.

[SWS DoIP 00091]

Upstream requirements: RS Diag 00080

[The expected payload length (see [SWS_DoIP_00019]) for diagnostic power mode information request message with payload type 0x4003 shall be exactly 0.

[SWS DoIP 00092]

Upstream requirements: RS_Diag_00080

[After a valid Diagnostic power mode request message, the DoIP module shall send a Diagnostic Power mode information response message ([SWS_DoIP_00093]) on the configured DoIPUdpConnection.]

7.3.2.5.2 Diagnostic power mode information response (payload type 0x4004)

The payload data structure of a diagnostic power mode information response shall be supported as described in Table 7.10:

Item	tem Position (Byte)	
Diagnostic Power Mode		
Diagnostic power mode	0	1

Table 7.10: Diagnostic power mode information response message payload data

[SWS DoIP 00093]

Upstream requirements: RS Diag 00080

[The "Diagnostic Power Mode" byte of diagnostic power mode information response message contains the 1 Byte value retrieved by a call to the configured DoIPPowerModeCallback (for the signature see <User>DoIPGetPowerModeStatus, [SWS_DoIP_00047]). If the function returns E_OK, the "Diagnostic Power Mode" shall be set to the retrieved value of PowerStateReady, otherwise it shall be set to 0x00 to indicate that the power mode is not ready.



7.3.2.5.3 Diagnostic entity status request (payload type 0x4001)

[SWS DoIP 00094]

Upstream requirements: RS_Diag_00082

[When the module receives a DoIP message with payload Type 0x4001 on a connection different than a configured DoIPUdpConnection, the module shall discard the DoIP message.]

Note: This means also that it is not allowed to receive this payload type on a TCP connection.

[SWS DoIP 00095]

Upstream requirements: RS_Diag_00082

[The expected payload length (see [SWS_DoIP_00019]) for diagnostic entity status request message with payload type 0x4001 shall be exactly 0. |

[SWS DoIP 00096]

Upstream requirements: RS_Diag_00082

[After a valid Diagnostic entity status request message, the DoIP module shall send a Diagnostic entity status response message on the configured DoIPUdpConnection.]

7.3.2.5.4 Diagnostic entity status response (payload type 0x4002)

The payload data structure of a diagnostic entity status response message shall be supported as described in Table 7.11:

Item	Position (Byte)	Length (Byte)
DoIP Entity Status Response		
Node Type	0	1
Max open sockets	1	1
Currently open socket	2	1
Max. data size	3	4

Table 7.11: Diagnostic entity status response message payload data

[SWS DoIP 00097]

Upstream requirements: RS_Diag_00082

[The "Node Type" byte of a diagnostic entity status response message shall contain the configured DoIPNodeType, whereas DOIP_GATEWAY shall be represented by 0x00 and DOIP_NODE shall be represented by 0x01.]



[SWS DoIP 00098]

Upstream requirements: RS_Diag_00082

[The "Max open sockets" byte of a diagnostic entity status response message shall contain the configured DoIPMaxTesterConnections. This parameter represents the maximum number of concurrent TCP_DATA sockets allowed with this DoIP entity, excluding the reserve socket required for socket handling as defined in the ISO 13400-2 standard.

[SWS DoIP 00099]

Upstream requirements: RS_Diag_00082

[The "Currently open sockets" byte of a diagnostic entity status response message shall contain the currently active connections, based on the information described in [SWS_DoIP_00002].

[SWS DoIP 00100]

Upstream requirements: RS_Diag_00082

[The "Max data size" bytes are only supported if the configuration parameter DoIPEntityStatusMaxByteFieldUse is set to TRUE. In this case, the diagnostic entity status response message shall contain the configured DoIPMaxRequestBytes in the "Max data size" field.

7.3.2.6 Diagnostic Message

For enhanced diagnostic as well as for emissions related diagnostic communication, the DoIP module uses the same diagnostic message structure and payload types. Additionally it provides an acknowledge mechanism to provide early feedback to the tester wether the diagnostic message was received and successfully received for the internal ECU or sent out to the target network.

7.3.2.6.1 Diagnostic message (for request and response) (payload type 0x8001)

The payload data structure of a diagnostic message shall be supported as described in Table 7.12:

Item	Position (Byte)	Length (Byte)
Logical address information		
Source address	0	2
Target address	2	2
Diagnostic message data		
User data	4	

Table 7.12: Diagnostic message payload data



[SWS DoIP 00121]

Upstream requirements: RS_Diag_00027

[When the module receives a DoIP message with payload Type 0x8001 on a connection different than a configured DoIPTcpConnection, the module shall discard the DoIP message.]

Note: This means also that it is not allowed to receive this payload type on a UDP connection.

[SWS DoIP 00122]

Upstream requirements: RS_Diag_00027

[The expected payload length (see [SWS_DoIP_00019]) for diagnostic messages with payload type 0x8001 shall be at least 5 byte.]

[SWS DoIP 00123]

Upstream requirements: RS_Diag_00027

[If a diagnostic message on a socket connection arrived, which is in the state Registered [Routing Active], and the "Source Address" does not match, a negative acknowledge set to 0x02 shall be sent. Additionally, the socket connection shall be closed as described in [SWS_DoIP_00058].]

Note: see details of the negative acknowledge message in 7.3.2.6.3.

[SWS DoIP 00124]

Upstream requirements: RS_Diag_00027

[If the DoIP module receives a diagnostic message with a "Target Addess" (equals DoIPTargetAddressValue) which is not connected via DoIPRoutingActivationRef and DoIPTargetddressRef to the received valid DoIPTesterSA, than the DoIP module shall send a diagnostic message negative acknowledge message with the diagnostic message negative acknowledge code set to 0x03. Additionally the message shall be discarded.

[SWS DoIP 00125]

Upstream requirements: RS_Diag_00027

[If the DoIP module receives a diagnostic message with the payload data length in the DoIP header is set to a value bigger than DoIPMaxRequestBytes-4, than the DoIP module shall send a diagnostic message negative acknowledge message with the diagnostic message negative acknowledge code set to 0x04. Additionally the message shall be discarded.]



[SWS DoIP 00126]

Upstream requirements: RS_Diag_00027

[If the DoIP module receives a diagnostic message and [SWS_DoIP_00125] does not apply but the current buffer size is not sufficient to receive the message, than the DoIP module shall send a diagnostic message negative acknowledge message with the diagnostic message negative acknowledge code set to 0x05. Additionally the message shall be discarded.

Note: This means that the PduR DoIPTpStartOfReception is not accepting the buffer.

[SWS DoIP 00127]

Upstream requirements: RS Diag 00027

[If the DoIP module receives a diagnostic message and the according "TargetAddress" was not activated by routing activation as described in [SWS_DoIP_00113], the DoIP module shall send a diagnostic message negative acknowledge message with the diagnostic message negative acknowledge code set to 0x06. Additionally the message shall be discarded.

[SWS_DoIP_00331] [Diagnostic messages shall only be evaluated in the ISO 13400 connection state "Registered [Routing Active]". If a DoIP message of payload type "Diagnostic Message" is received on a TCP_DATA socket connection which is not in the ISO 13400 connection state "Registered [Routing Active]", the DoIP message shall be silently discarded as soon as the payload type is evaluated. No further checks shall be performed on followed messages fields. Only the payload length shall be used to identify the start of the next frame.]

[SWS DoIP 00128]

Upstream requirements: RS Diag 00027

[If no negative acknowledge was sent the DoIP module shall evaluate the message and forward the content (i.e. all UDS Data, not the TargetAddress and SourceAddress) to the DoIPPduRRxPdu connected to the received TargetAddress/SourceAddress combination as configured in DoIPChannel|

Note: For how to proceed with the communication please refer to the TCP communication described in chapter 7.5.1

[SWS_DoIP_00129]

Upstream requirements: RS Diag 00027

[If the PduR accepted all Data, the DoIP module shall send a diagnostic acknowledge message.]



[SWS DoIP 00130]

Upstream requirements: RS Diag 00027

The DoIP module will get a diagnostic response message (i.e DoIP_TpTransmit or DoIP_IfTransmit is called with DoIPPduRTxPdu which matches to the DoIPPduRRx-Pdu that handled the data to the PduR) via the upper layer connection to the PduR, so it has to monitor whether the socket connection the request was received on is still established. If the socket connection has been closed, the response shall be discarded and the DoIP shall return with E_NOT_OK in the return value.

[SWS DoIP 00131]

Upstream requirements: RS_Diag_00027

[If the DoIP module is called with DoIPPduRTxPdu in the DoIP_TpTransmit or DoIP_IfTransmit as described in [SWS_DoIP_00130] and the according socket connection has not been closed since the reception of the according diagnostic message, the DoIP module shall prepare a diagnostic message via the according socket connection with the "SourceAddress" set to the DoIPTargetAddressValue of the request and the "TargetAddress" set to the DoIPTesterSA.

[SWS DoIP 00173]

Upstream requirements: RS_Diag_00027

[The field "User data" of the [SWS_DoIP_00131] message contains the actual diagnostic payload data which shall not be modified by DoIP.

Note: The reception and transmission of diagnostic payload data is described more in detail in chapter 7.5, the diagnostic communication related part of this specification

Note: Because of enhanced diagnostic and emissions related diagnostic communication behavior, several responses to the tester could be sent out before the final response is sent. The DoIP module is not evaluating the content or the amount of responses or requests to the target address. It is just routing the diagnostic data from SoAd to PduR and back.

7.3.2.6.2 Diagnostic acknowledge message (payload type 0x8002)

The payload data structure of a diagnostic acknowledge message shall be supported as described in Table 7.13:

Item Position (Byte)		Length (Byte)	
Logical address information			
Source address 0 2			
Target address	2	2	





Δ

Diagnostic message acknowledge information			
ACK code (0x00) 4 1			
Previous diagnostic message 5			

Table 7.13: Diagnostic acknowledge message payload data

[SWS DoIP 00132]

Upstream requirements: RS_Diag_00027

[If the DoIP module needs to send a diagnostic acknowledge message the "Source Address" shall be set to the according "TargetAddress" of the received message.

[SWS DoIP 00133]

Upstream requirements: RS_Diag_00027

[If the DoIP module needs to send a diagnostic acknowledge message the "Target Address" shall be set to the according "SourceAddress" of the received message.

[SWS_DoIP_00134]

Upstream requirements: RS_Diag_00027

[If the DoIP module needs to send a diagnostic acknowledge message the field "previous diag message" shall be filled with the number of bytes of the original request message as configured in the parameter DoIPNumByteDiagAckNack for the DoIPTester the request was received on.]

7.3.2.6.3 Diagnostic negative acknowledge message (payload type 0x8003)

The payload data structure of a diagnostic negative acknowledge message shall be supported as described in Table 7.14:

Item	Position (Byte)	Length (Byte)
Logical address information		
Source address	0	2
Target address	2	2
Diagnostic message acknowledge information		
Diagnostic message negative acknowledge code	4	1
Previous diagnostic message	5	

Table 7.14: Diagnostic negative acknowledge payload data



[SWS DoIP 00135]

Upstream requirements: RS_Diag_00027

[If the DoIP module needs to send a diagnostic negative acknowledge message the "Source Address" shall be set to the according "TargetAddress" of the received message.

[SWS DoIP 00136]

Upstream requirements: RS_Diag_00027

[If the DoIP module needs to send a diagnostic negative acknowledge message the "Target Address" shall be set to the according "SourceAddress" of the received message.

[SWS DoIP 00137]

Upstream requirements: RS_Diag_00027

[If the DoIP module needs to send a diagnostic negative acknowledge message, the "Diagnostic message negative acknowledge code" shall be set to the value specified by the specification item that is triggering the diagnostic negative acknowledge message.

[SWS DoIP 00138]

Upstream requirements: RS Diag 00027

[If the DoIP module needs to send a diagnostic negative acknowledge message the field "previous diag message" shall be filled with the configured number of the original request message as configured in the parameter DoIPNumByteDiagAckNack for the DoIPTester the request was received on.]

7.4 UDP communication

DoIP messages that are communicated via UDP connection are communicated on the SoAd Interface APIs. So all messages which are received via UDP as described in Table 7.2 and sent via UDP as described in Table 7.3 shall be treated as described in this chapter.

[SWS_DoIP_00197]

Upstream requirements: RS_Diag_00024

[If the SoAd calls the DoIP module via the Interface DoIP_SoAdIfRxIndication, the DoIP module shall copy the message into the internal UDP buffer for further processing.]



Note: Further processing depends on the header information and on the payload type. For details refer to chapter 7.3.2. Which messages are expected to be received on UDP connection is described in Table 7.2.

[SWS DoIP 00198]

Upstream requirements: RS_Diag_00024

[If the DoIP module shall send a DoIP message via UDP it shall call the SoAd_IfTransmit with the TxPduId set to the SoAd internal TxPduId that is retrieved via the according configured DoIPSoAdUdpTxPduRef, the PduInfoPtr shall contain the length of the message and the pointer to the to be transmitted message buffer and additionally the buffer shall be locked.]

Note: The events that lead to the sending of UDP DoIP messages are described in the rest of the specification. Which DoIP message shall use UDP connection is described in Table 7.3.

[SWS_DoIP_00199] If the SoAd calls the DoIP module via the Interface DoIP_SoAdIfTxConfirmation, the DoIP module shall release the buffer which is related to the received TxPduId.

[SWS_DoIP_00286] [DoIP module shall consider the announcement successful and process DoIPVehicleAnnouncementCount if the SoAd calls the DoIP module via the interface DoIP_SoAdIfTxConfirmation with Result set to E_OK for the announcement related SoAd_IfTransmit() call i.e. if E_NOT_OK is returned for the last announcement message, it will not be considered an announcement.

[SWS_DoIP_00276] [If DoIP receives more UDP requests on a connection than the configured amount of DoIPMaxUDPRequestPerConnection, only DoIPMaxUDPRequestPerConnection requests (including the request that has just been accepted) shall be processed and responded. DoIP shall silently discard the request messages that cannot be processed.

Note: Tester will detect discarded UDP requests via timeout handling.

[SWS_DoIP_00310] [If a UDP message contains more than one DoIP requests, DoIP shall process and respond to the first DoIP request and discard the remaining requests.]

Note: Tester will detect discarded UDP requests via timeout handling.



7.5 TCP communication

DoIP messages that are communicated via TCP connection are communicated on the SoAd Tp APIs. So all messages which are received via TCP as described in Table 7.2 and sent via TCP as described in Table 7.3 shall be treated as described in this chapter.

7.5.1 Reception of a TCP DoIP message

[SWS DoIP 00207]

Upstream requirements: RS_Diag_00024

[If the function DoIP_SoAdTpStartOfReception is called with TpSduLength set to 0, the DoIP module shall fill in the bufferSizePtr the available buffer size in the DoIP for the reception of the TCP message, lock the according buffer for other TCP connections and return BUFREQ_OK.]

Note: The API will be called from SoAd only once per TCP connection, directly when the socket is connected. All the data will be transferred to DoIP via the API DoIP SoAdTpCopyRxData.

[SWS DoIP 00208]

Upstream requirements: RS_Diag_00024

[If the function DoIP_SoAdTpCopyRxData is called at the start of a new DoIP message (e.g. directly after DoIPSoAdTpStartOfReception succeeded or previous DoIP message processed completely) with info.SduLength set to 0 the DoIP module shall return in the parameter bufferSizePtr the length to the maximum necessary bytes to evaluate the DoIP relevant data for routing of diagnostic data.]

Note: The DoIP module knows internal when a new DoIP message is started because of the DoIP protocol payload length information (see chapter Generic DoIP header 7.3.1).

[SWS_DoIP_00209]

Upstream requirements: RS_Diag_00024

[If the function DoIP_SoAdTpCopyRxData is called at the start of a new DoIP message (e.g. directly after DoIPSoAdTpStartOfReception succeeded or previous DoIP message processed completely) with info.SduLength is not set to 0 and the DoIP TCP buffer is big enough to copy all the data, the DoIP module shall copy the received data to the internal TCP buffer, return the parameter bufferSizePtr set to the available buffer after copying and return BUFREQ_OK.]



[SWS DoIP 00210]

Upstream requirements: RS_Diag_00024

[If the function DoIP_SoAdTpCopyRxData is called at the start of a new DoIP message (e.g. directly after DoIPSoAdTpStartOfReception succeeded or previous DoIP message processed completely) with info.SduLength is not set to 0 and the DoIP TCP buffer is not big enough to copy all the data, the DoIP module shall return BUFREQ_E_NOT_OK.|

[SWS DoIP 00214]

Upstream requirements: RS_Diag_00024

[If the DoIP module has received sufficient data to evaluate the DoIP header and the payload type is not diagnostic message the DoIP shall copy all data of this DoIP message to the internal DoIP TCP buffer, lock the according buffer for other TCP connections and process the DoIP message as described in [SWS_DoIP_00219].

Note: The length of the DoIP message is encoded in the DoIP header. It has to be considered that after the first DoIP message, there can be more in one single TCP stream.

[SWS_DoIP_00212]

Upstream requirements: RS_Diag_00024

[If the DoIP module has received sufficient data to evaluate the DoIP header, the payload type is diagnostic message and the Routing was already activated for the SourceAddress/TargetAddress combination on this DoIPInterface, the DoIP module shall call the PduR_DoIPTpStartOfReception with the according id set to the DoIP-PduRRxPduId matching the SourceAddress/TargetAddress combination of the diagnostic message on this DoIPInterface, set the info.SduLength to the already received diagnostic data, set the info->SduDataPtr to the buffer containing the received diagnostic data and set the TpSduLength to the total size of the diagnostic message extracted from DoIP Header.]

Note: For the SourceAddress/TargetAddress combinations refer to configuration container DoIPChannel.

[SWS_DoIP_00260]

Upstream requirements: RS_Diag_00024

[If PduR_DoIPTpStartOfReception returns BUFREQ_OK the reception was accepted and the DoIP module shall forward already received data of the diagnostic message to the upper layer by subsequent calls to PduR_DoIPTpCopyRxData.]



[SWS DoIP 00218]

Upstream requirements: RS Diag 00024

[If PduR_DoIPTpStartOfReception returns BUFREQ_OK the reception was accepted and the DoIP shall forward all subsequent calls to DoIP_SoAdTpCopyRxData directly to PduR_DoIPTpCopyRxData until all diagnostic data was handed to the PduR.|

[SWS_DoIP_00259]

Upstream requirements: RS_Diag_00024

[At the end of the copy procedure via PduR_DoIPTpCopyRxData to PduR, the DoIP module has to modify the available buffer size pointer returned to SoAd in order to stop before the next DoIP header.]

[SWS DoIP 00253]

Upstream requirements: RS_Diag_00024

[If the buffer size reported by PduR_DoIPTpStartOfReception does not suffice for already received data, DoIP shall abort the reception and call PduR_DoIPTpRxIndication with E_NOT_OK.]

[SWS DoIP 00216]

Upstream requirements: RS Diag 00024

[If PduR_DoIPTpStartOfReception returns BUFREQ_E_NOT_OK, the DoIP module shall send a diagnostic negative acknowledge message with the diagnostic message negative acknowledge code set to 0x08 and discard all the TCP data until the next DoIP message.]

Note: PduR_DoIPTpRxIndication() will not be called when PduR_DoIPStartOfReception() does not return BUFREQ_OK.

[SWS DoIP 00311]

Upstream requirements: RS_Diag_00024

[If PduR_DoIPTpStartOfReception returns BUFREQ_E_OVFL, the DoIP module shall send a diagnostic negative acknowledge message with the diagnostic message negative acknowledge code set to 0x05 and discard all the TCP data until the next DoIP message.]

[SWS DoIP 00217]

Upstream requirements: RS_Diag_00024

[If PduR_DoIPTpCopyRxData returns BUFREQ_E_NOT_OK, the DoIP module shall discard all the TCP data until the next DoIP message and call the PduR_DoIPTpRxIndication with the according PduId and the result set to E NOT OK.]



[SWS DoIP 00221]

Upstream requirements: RS Diag 00024

[If all diagnostic data was successfully forwarded to the PduR (see [SWS_DoIP_00216]) the DoIP module shall call the PduR_DoIPTpRxIndication with the according PduId and the result set to E_OK.|

[SWS_DoIP_00219]

Upstream requirements: RS_Diag_00024

[If the DoIP module has received with the DoIP_SoAdTpCopyRxData operations enough data to evaluate the DoIP header and the payload type is not diagnostic message (see [SWS_DoIP_00214]), the DoIP module shall receive via subsequent calls to DoIP_SoAdTpCopyRxData all data for the DoIP message and process it.]

Note: The possible DoIP messages on TCP are described in Table 7.2 and in the according chapters in this specification.

[SWS DoIP 00200]

Upstream requirements: RS_Diag_00024

[If the function DoIP_SoAdTpRxIndication is called the DoIP module shall release all data connected to the reception and forward the result to PduR_DoIPTpRxIndication if a reception for diagnostic message is currently ongoing.]

Note: The function DoIP_SoAdTpRxIndication is only called once when the socket is closed.

[SWS_DoIP_00258] [If the DoIP module is called with DoIP_TpCancelReceive, the DoIP module shall call the SoAd_TpCancelReceive function with the RxPduld that is retrieved via the according configured DoIPSoAdTcpRxPduRef.|

7.5.2 Transmission of a TCP DoIP message

[SWS DoIP 00220]

Upstream requirements: RS_Diag_00024

[If the DoIP module needs to send a DoIP message that is not a diagnostic message on the TCP connection, the DoIP shall call the SoAd_TpTransmit with the TxPduId containing the Id of the according socket, the PduInfoPtr.SduLength set to the size of the data to be transmitted and lock the buffer to send.



Note: If the call to SoAd_TpTransmit returns E_OK the DoIP module shall consider that the data will be transmitted by subsequent calls to the DoIP_SoAdTpCopyTxData.

[SWS DoIP 00223]

Upstream requirements: RS Diag 00024

[If the call to SoAd_TpTransmit returns E_NOT_OK the DoIP module shall discard the DoIP message.]

[SWS DoIP 00224]

Upstream requirements: RS_Diag_00024

[If the function DoIP_SoAdCopyTxData is called after a sucessfull call to SoAd_TpTransmit, with a valid id and the info.SduLength is set to 0 the DoIP shall return BUFREQ_OK and set the parameter availableDataPtr to the total available data size of the current DoIP message to be transmitted.

[SWS DoIP 00225]

Upstream requirements: RS_Diag_00024

[If the function DoIP_SoAdCopyTxData is called after a sucessfull call to SoAd_TpTransmit, with a valid id and the info.SduLength is not set to 0, the DoIP module shall copy the bytes specified in the info.SduLength to the info->SduDataPtr, return BUFREQ_OK and set the parameter availableDataPtr to the total available data size of the current DoIP message after the copy process.

[SWS DoIP 00229]

Upstream requirements: RS_Diag_00024

[If the function DoIP_SoAdTpTxConfirmation is called the DoIP module shall release the buffer related to the id. |

[SWS DoIP 00230]

Upstream requirements: RS Diag 00024

[If the function DoIP_TpTransmit or DoIP_IfTransmit is called and the data package is allowed to be sent according to the current DoIP protocol related information, the DoIP module shall return E OK.

- 1.) If the connection to the SoAd is idle, the DoIP shall call the SoAd_TpTransmit function according to [SWS_DoIP_00284].
- 2.) If the connection to the SoAd is not idle, the DoIP shall store the transmission request and call SoAd_TpTransmit according to [SWS_DoIP_00284] as soon as the connection is idle again.



[SWS DoIP 00284]

Upstream requirements: RS_Diag_00024

To transmit a DoIP diagnostic message the DoIP shall assemble the DoIP header considering the information of the handed PduInfoPtr.SduLength and call SoAd_TpTransmit with the TxPduId set to the according PduId of the socket connection and the PduInfoPtr.SduLength set to the sum of the following lengths: DoIP header (8 Byte), the DoIP diagnostic message specific data (4 Byte) and received length of the call to DoIP_TpTransmit or DoIP_IfTransmit (PduInfoPtr.SduLength).

[SWS DoIP 00226]

Upstream requirements: RS_Diag_00024

[If the function DoIP_TpTransmit or DoIP_IfTransmit is called and the data package is not allowed according to the current DoIP protocol related information, the DoIP module shall return E_NOT_OK.]

[SWS DoIP 00279]

Upstream requirements: RS_Diag_00024

[If the DoIPPduType of a DoIPPduRTxPdu is DOIP_IFPDU, the content of the PDU provided by DoIP_IfTransmit shall be stored completely in the DoIP internal buffer. If the buffer is too small, E_NOT_OK shall be returned immediately.]

Note: If the function SoAd_TpTransmit returns for the use case "diagnostic message" E_OK, the DoIP module shall consider that the data will be transmitted by subsequent calls to the DoIP SoAdTpCopyTxData.

[SWS DoIP 00228]

Upstream requirements: RS_Diag_00024

[If the call to SoAd_TpTransmit returns for the use case "diagnostic message" E_NOT_OK the DoIP module shall discard the DoIP message and, in case the DoIPPduType of the corresponding DoIPPduRTxPdu is DOIP_TPPDU, call the PduR_DoIPTpTxConfirmation with result set to E_NOT_OK.|

[SWS DoIP 00231]

Upstream requirements: RS Diag 00024

[If the function DoIP_SoAdCopyTxData is called after a sucessfull call to SoAd_TpTransmit for the use case "diagnostic message", with a valid id and the info.SduLength is set to 0 the DoIP shall return BUFREQ_OK and set the parameter availableDataPtr to the total available data size of the current buffered DoIP message to be transmitted.



Note: This means that only the length for the created DoIP header and the diagnostic SourceAddress/TargetAddress is returned and not the total data length.

[SWS DoIP 00232]

Upstream requirements: RS Diag 00024

[If the function DoIP_SoAdCopyTxData is called after a sucessfull call to SoAd_TpTransmit for the use case "diagnostic message" with a valid id and the info.SduLength is not set to 0, the DoIP module shall copy the bytes specified in the info.SduLength to the info->SduDataPtr. If the requested bytes are more than in the DoIP internal buffer, the DoIP shall call the PduR_DoIPTpCopyTxData with the info.SduLength set to the remaining requested data bytes and the info-> SduDataPtr set to the position where the PduR shall continue to copy the data.

[SWS DoIP 00254]

Upstream requirements: RS_Diag_00024

[If the call to PduR_DoIPTpCopyTxData returns BUFREQ_OK or all the requested data was part of the DoIP internal buffer, the DoIP module shall return BUFREQ_OK and set the parameter availableDataPtr to the remaining data size of the DoIP header and diagnostic SourceAddress/TargetAddress if they have not been copied completely or to the remaining data size returned from PduR_DoIPTpCopyTxData.|

[SWS DoIP 00233]

Upstream requirements: RS Diag 00024

[If the DoIP module has copied via subsequent calls to DoIP_SoAdTpCopyTxData for the use case "diagnostic message" all information stored in the DoIP internal buffer, the DoIP module shall forward all subsequent calls to DoIP_SoAdTpCopyTxData/DoIP_SoAdTpTxConfirmation for this transmission directly to the PduR using PduR_DoIPTpCopyTxData/PduR_DoIPTpTxConfirmation in case the DoIPPduRTxPdu is DOIP_TPPDU and PduR_DoIPIfTxConfirmation otherwise, and release the internal buffer for this transmission.

[SWS_DoIP_00257]

Upstream requirements: RS_Diag_00024

[If the DoIP module is called with DoIP_TpCancelTransmit or DoIP_IfCancelTransmit, the DoIP module shall call the SoAd_TpCancelTransmit function of the according SoAdTxPduId.]

)



7.6 Error classification

7.6.1 Development Errors

[SWS_DoIP_00148] Definiton of development errors in module DoIP [

Type of error	Related error code	Error value
API service call without module initialization	DOIP_E_UNINIT	0x01
NULL-Pointer on any API call	DOIP_E_PARAM_POINTER	0x02
Wrong Lower Layer (SoAd) or Upper Layer (Pdu Router) Id received	DOIP_E_INVALID_PDU_SDU_ID	0x03
API call with invalid Parameter	DOIP_E_INVALID_PARAMETER	0x04
DoIP Init service call failure	DOIP_E_INIT_FAILED	0x05

7.6.2 Runtime Errors

There are no runtime errors.

7.6.3 Production Errors

There are no production errors.

7.6.4 Extended Production Errors

There are no extended production errors.



8 API specification

8.1 Imported types

The follwing types shall be imported by the DoIP module from the modules given:

[SWS_DoIP_00020] Definition of imported datatypes of module DoIP [

Module	Header File	Imported Type
Comtype	ComStack_Types.h	BufReq_ReturnType
	ComStack_Types.h	PduldType
	ComStack_Types.h	PduInfoType
	ComStack_Types.h	PduLengthType
	ComStack_Types.h	RetryInfoType
	ComStack_Types.h	TpDataStateType
SoAd	SoAd.h	SoAd_SoConIdType
	SoAd.h	SoAd_SoConModeType
Std	Std_Types.h	Std_ReturnType
	Std_Types.h	Std_VersionInfoType
Tcplp	Tcplp.h	Tcplp_DomainType
	Tcplp.h	Tcplp_lpAddrAssignmentType
	Tcplp.h	Tcplp_lpAddrStateType
	Tcplp.h	Tcplp_SockAddrType

The following types are contained in the Rte_DoIP_Type.h header file, which is generated by the RTE generator:

[SWS_DoIP_00266] Definition of ImplementationDataType DoIP_PowerStateType

Name	DoIP_PowerStateType		
Kind	Туре		
Derived from	uint8		
Range	DOIP_NOT_READY 0x00 DoIP Power Mode "not ready"		
	DOIP_READY 0x01 DoIP Power Mode "ready"		
	DOIP_NOT_SUPPORTED 0x02 DoIP Power Mode "not supported"		
	0x03-0xFF		
Description	Used for handling of the PowerMode in DoIP entity status requests		
Variation	-		
Available via	Rte_DoIP_Type.h		

1



[SWS_DoIP_00267] Definition of ImplementationDataType AuthenticationReq DataType_{Name} \lceil

Name	AuthenticationReqDataType_{Name}		
Kind	Array Element type uint8		uint8
Size	{ecuc(DoIP/DoIPConfigSet/DoIPInterface/DoIPRoutingActivation/DoIPRoutingActivation AuthenticationCallback.DoIPRoutingActivationAuthenticationReqLength)} Elements		
Description	_		
Variation	Name = {ecuc(DoIP/DoIPConfigSet/DoIPInterface/DoIPRoutingActivation.SHORT-NAME)}		
Available via	Rte_DoIP_Type.h		

[SWS_DoIP_00268] Definition of ImplementationDataType AuthenticationRes DataType_{Name}

Name	AuthenticationResDataType_{Name}		
Kind	Array Element type uint8		uint8
Size	{ecuc(DoIP/DoIPConfigSet/DoIPRoutingActivation/DoIPRoutingActivationAuthentication Callback.DoIPRoutingActivationAuthenticationResLength)} Elements		
Description	_		
Variation	Name = {ecuc(DoIP/DoIPConfigSet/DoIPRoutingActivation.SHORT-NAME)}		
Available via	Rte_DoIP_Type.h		

1

[SWS_DoIP_00269] Definition of ImplementationDataType ConfirmationReqData Type_{Name}

Name	ConfirmationReqDataType_{Name}		
Kind	Array Element type uint8		uint8
Size	{ecuc(DoIP/DoIPConfigSet/DoIPRoutingActivation/DoIPRoutingActivationConfirmationCallback.DoIPRoutingActivationConfirmationReqLength)} Elements		
Description			
Variation	Name = {ecuc(DoIP/DoIPConfigSet/DoIPRoutingActivation.SHORT-NAME)}		
Available via	Rte_DoIP_Type.h		

I

[SWS_DoIP_00270] Definition of ImplementationDataType ConfirmationResData Type_{Name} \lceil

Name	ConfirmationResDataType_{Name}		
Kind	Array	Array Element type uint8	
Size	{ecuc(DoIP/DoIPConfigSet/DoIPRoutingActivation/DoIPRoutingActivationConfirmationCallback.Do IPRoutingActivationConfirmationResLength)} Elements		





 \triangle

Description	-
Variation	Name = {ecuc(DoIP/DoIPConfigSet/DoIPRoutingActivation.SHORT-NAME)}
Available via	Rte_DoIP_Type.h

١

[SWS_DoIP_00287] Definition of ImplementationDataType DoIP_FurtherAction ByteType

Upstream requirements: RS_Diag_00026

Γ

Name	DoIP_FurtherActionByteType		
Kind	Туре		
Derived from	uint8		
Range	0x110xFF	_	Available for additional OEM-specific use
Description	Used to get the OEM specific Further Action Byte for the DoIP vehicle identification response/ vehicle announcement.		
Variation	-		
Available via	Rte_DoIP_Type.h		

1

8.2 Type definitions

[SWS_DoIP_00272] [The value of DOIP_E_PENDING shall be 0x10.|

The following Data Types shall be used for the functions defined in this specification.

8.2.1 DoIP_ConfigType

[SWS_DoIP_00025] Definition of datatype DoIP_ConfigType [

Name	DoIP_ConfigType	
Kind	Structure	
Elements	Implementation specific	
	Type –	
	Comment	The content of the configuration data structure is implementation specific





 \triangle

Description	Configuration data structure of the DoIP module	
Available via	DoIP.h	

8.3 Function definitions

This chapter contains a list of functions provided to upper layer modules.

8.3.1 DoIP_TpTransmit

[SWS_DoIP_00022] Definition of API function DoIP_TpTransmit

Upstream requirements: RS_Diag_00024

Γ

Service Name	DoIP_TpTransmit		
Syntax	Std_ReturnType DoIP_TpTransmit (PduIdType TxPduId, const PduInfoType* PduInfoPtr)		
Service ID [hex]	0x53		
Sync/Async	Synchronous		
Reentrancy	Reentrant for different Pdul	Reentrant for different Pdulds. Non reentrant for the same Pduld.	
Parameters (in)	TxPduld Identifier of the PDU to be transmitted		
	PduInfoPtr	Length of and pointer to the PDU data and pointer to MetaData.	
Parameters (inout)	None		
Parameters (out)	None		
Return value	Std_ReturnType	E_OK: Transmit request has been accepted. E_NOT_OK: Transmit request has not been accepted.	
Description	Requests transmission of a PDU.		
Available via	DoIP.h		

[SWS_DoIP_00162] [If development error detection is enabled: The function shall check that the service DoIP_Init was previously called. If the check fails, the function shall raise the development error DOIP_E_UNINIT.]

[SWS_DoIP_00163] [If development error detection is enabled: The function shall check if the TxPduld matches a configured DoIPPduRTxPduld. If the check fails the function shall raise the development error DOIP_E_INVALID_PDU_SDU_ID.]



[SWS_DoIP_00164] [If development error detection is enabled: The function shall check if the PduInfoPtr is not a NULL_PTR. If the check fails the function shall raise the development error DOIP_E_PARAM_POINTER.|

8.3.2 DoIP_TpCancelTransmit

[SWS_DoIP_00023] Definition of API function DoIP_TpCancelTransmit

Upstream requirements: RS Diag 00024

Γ

Service Name	DoIP_TpCancelTransmit		
Syntax	Std_ReturnType DoIP_TpCancelTransmit (PduIdType TxPduId)		
Service ID [hex]	0x54		
Sync/Async	Synchronous		
Reentrancy	Reentrant for different Pdulds. Non reentrant for the same Pduld.		
Parameters (in)	TxPduld –		
Parameters (inout)	None		
Parameters (out)	None		
Return value	Std_ReturnType E_OK: Cancellation was executed successfully by the destination module. E_NOT_OK: Cancellation was rejected by the destination module.		
Description	Requests cancellation of an ongoing transmission of a PDU in a lower layer communication module. The call of this API to cancel an ongoing transmission will close the used TCP connection.		
Available via	DoIP.h		

1

[SWS_DoIP_00166] [If development error detection is enabled: The function shall check that the service DoIP_Init was previously called. If the check fails, the function shall raise the development error DOIP_E_UNINIT.]

[SWS_DoIP_00167] [If development error detection is enabled: The function shall check if the TxPduId matches a configured DoIPPduRTxPduId. If the check fails the function shall raise the development error DOIP_E_INVALID_PDU_SDU_ID.|



8.3.3 DoIP_TpCancelReceive

[SWS_DoIP_00024] Definition of API function DoIP_TpCancelReceive

Upstream requirements: RS_Diag_00024

Γ

Service Name	DoIP_TpCancelReceive	DoIP_TpCancelReceive	
Syntax	Std_ReturnType DoIP_ PduIdType RxPduId)	Std_ReturnType DoIP_TpCancelReceive (PduIdType RxPduId)	
Service ID [hex]	0x4c		
Sync/Async	Synchronous		
Reentrancy	Non Reentrant		
Parameters (in)	RxPduld	RxPduld Identification of the PDU to be cancelled.	
Parameters (inout)	None		
Parameters (out)	None		
Return value	Std_ReturnType E_OK: Cancellation was executed successfully by the destination module. E_NOT_OK: Cancellation was rejected by the destination module.		
Description		Requests cancellation of an ongoing reception of a PDU in a lower layer transport protocol module. The call of this API to cancel an ongoing reception will close the used TCP connection.	
Available via	DolP.h		

1

[SWS_DoIP_00169] [If development error detection is enabled: The function shall check that the service DoIP_Init was previously called. If the check fails, the function shall raise the development error DOIP_E_UNINIT.]

[SWS_DoIP_00170] [If development error detection is enabled: The function shall check if the RxPduld matches a configured DoIPPduRRxPduld. If the check fails the function shall raise the development error DOIP E INVALID PDU SDU ID.]



8.3.4 DoIP_IfTransmit

[SWS_DoIP_00277] Definition of API function DoIP_IfTransmit

Upstream requirements: RS_Diag_00024

Γ

Service Name	DoIP_IfTransmit	
Syntax	Std_ReturnType DoIP_IfTransmit (PduIdType TxPduId, const PduInfoType* PduInfoPtr)	
Service ID [hex]	0x49	
Sync/Async	Synchronous	
Reentrancy	Reentrant for different Pdulds. Non reentrant for the same Pduld.	
Parameters (in)	TxPduld Identifier of the PDU to be transmitted	
	PduInfoPtr	Length of and pointer to the PDU data and pointer to MetaData.
Parameters (inout)	None	
Parameters (out)	None	
Return value	Std_ReturnType	E_OK: Transmit request has been accepted. E_NOT_OK: Transmit request has not been accepted.
Description	Requests transmission of a PDU.	
Available via	DoIP.h	

8.3.5 DoIP_IfCancelTransmit

[SWS_DoIP_00278] Definition of API function DoIP_IfCancelTransmit

Upstream requirements: RS_Diag_00024

Γ

Service Name	DoIP_IfCancelTransmit	
Syntax	Std_ReturnType DoIP_IfCancelTransmit (PduIdType TxPduId)	
Service ID [hex]	0x4a	
Sync/Async	Synchronous	
Reentrancy	Reentrant for different Pdulds. Non reentrant for the same Pduld.	
Parameters (in)	TxPduld	Identification of the PDU to be cancelled.
Parameters (inout)	None	
Parameters (out)	None	
Return value	Std_ReturnType	E_OK: Cancellation was executed successfully by the destination module. E_NOT_OK: Cancellation was rejected by the destination module.





 \triangle

Description	Requests cancellation of an ongoing transmission of a PDU in a lower layer communication module.
Available via	DoIP.h

1

8.3.6 DoIP_Init

[SWS_DoIP_00026] Definition of API function DoIP_Init

Upstream requirements: RS_Diag_00024

Γ

Service Name	DoIP_Init		
Syntax	<pre>void DoIP_Init (const DoIP_ConfigType* DoIPConfigPtr)</pre>		
Service ID [hex]	0x01		
Sync/Async	Synchronous		
Reentrancy	Non Reentrant		
Parameters (in)	DoIPConfigPtr	Pointer to the configuration data of the DoIP module	
Parameters (inout)	None	None	
Parameters (out)	None		
Return value	None		
Description	This service initializes all global variables of the DoIP module. After return of this service the Do IP module is operational.		
Available via	DolP.h		

Ī

8.3.7 DoIP_GetVersionInfo

[SWS_DoIP_00027] Definition of API function DoIP_GetVersionInfo

Upstream requirements: SRS_BSW_00407, SRS_BSW_00411

Γ

Service Name	DoIP_GetVersionInfo
Syntax	<pre>void DoIP_GetVersionInfo (Std_VersionInfoType* versioninfo)</pre>
Service ID [hex]	0x00





	۸	
/	7	١

Sync/Async	Synchronous		
Reentrancy	Reentrant	Reentrant	
Parameters (in)	None		
Parameters (inout)	None		
Parameters (out)	versioninfo	Pointer to where to store the version information of this module.	
Return value	None		
Description	Returns the version information of this module.		
Available via	DoIP.h		

1

[SWS_DoIP_00172] [If development error detection is enabled: The function shall check if the versioninfo is not a NULL_PTR. If the check fails the function shall raise the development error DOIP_E_PARAM_POINTER.]

((SRS_BSW_00323, SRS_BSW_00386)

[SWS_DoIP_00030] [If source code for caller and callee of DoIP_GetVersionInfo is available, the DoIP module should realize DoIP_GetVersionInfo as a macro, defined in the module's header file.]

8.3.8 DoIP_ActivationLineSwitch

[SWS_DoIP_91000] Definition of API function DoIP_ActivationLineSwitch [

Service Name	DoIP_ActivationLineSwitch	
Syntax	<pre>void DoIP_ActivationLineSwitch (uint8 InterfaceId , boolean* Active)</pre>	
Service ID [hex]	0x0e	
Sync/Async	Synchronous	
Reentrancy	Non Reentrant	
Parameters (in)	InterfaceId	Indentifier of the DoIP interface for which DoIP_ActivationLine Switch function is called.
Parameters (inout)	Active	Boolean value acting as input parameter to request active/ inactive status of the given DoIP Interface and acts as an output parameter indicating the activation line status.
Parameters (out)	None	
Return value	None	
Description	This function is to be used by integrators to inform the DoIP implementation about the status of the activation line of a DoIP interface with given InterfaceId.	
Available via	DolP.h	

1



[SWS_DoIP_00285] [If development error detection is enabled: The function shall check that the service DoIP_Init was previously called. If the check fails, the function shall raise the development error DOIP_E_UNINIT.|

[SWS_DoIP_00302] [If development error detection is enabled DoIP_ Activation-LineSwitch (InterfaceId,*Active) shall check if interface identified by InterfaceId actually exists and DoIPInterfaceActLineCtrl is set to TRUE. If the check fails, the function shall raise the development error DOIP E INVALID PARAMETER.]

[SWS_DoIP_00303] [If development error detection is enabled call to DoIP_ActivationLineSwitch shall check if the interface identified by InterfaceId actually exists. If the check fails, the function shall raise the development error DOIP_E_INVALID_PARAMETER.|

8.3.9 DoIP_TriggerVehicleAnnouncement

[SWS_DoIP_91002] Definition of API function DoIP_TriggerVehicleAnnouncement \lceil

Service Name	DoIP_TriggerVehicleAnnour	ncement	
Syntax	<pre>void DoIP_TriggerVeh: uint8 InterfaceId)</pre>	void DoIP_TriggerVehicleAnnouncement (uint8 InterfaceId)	
Service ID [hex]	0x0d		
Sync/Async	Asynchronous	Asynchronous	
Reentrancy	Non Reentrant		
Parameters (in)	InterfaceId Indentifier of the DoIP interface for which DoIP_TriggerVehicle Announcement is called.		
Parameters (inout)	None		
Parameters (out)	None		
Return value	None		
Description	This function is used to notify the DoIP module to start vehicle announcement for DoIP interfaces with given Interfaceld. This function is just a trigger to start the DoIPInitialVehicle AnnouncementTime timeout.		
Available via	DoIP.h		

1

[SWS_DoIP_00304] [If development error detection is enabled DoIP_TriggerVehicleAnnouncement shall check if the interface identified by InterfaceId is configured with DoIPInterfaceActLineCtrl set to FALSE. If the check fails the function shall raise the development error DOIP E INVALID PARAMETER.]



[SWS_DoIP_00305] [If development error detection is enabled call to DoIP_TriggerVehicleAnnouncement shall check if the interface identified by InterfaceId actually exists. If the check fails, the function shall raise the development error DOIP_E_INVALID_PARAMETER.|

8.3.10 DoIP_AllowNonTIsDoIPConnection

[SWS_DoIP_91003] Definition of API function DoIP_AllowNonTIsDoIPConnection

Service Name	DoIP_AllowNonTlsDoIP(DoIP_AllowNonTlsDoIPConnection	
Syntax		void DoIP_AllowNonTlsDoIPConnection (boolean NonTlsAllowed)	
Service ID [hex]	0x55		
Sync/Async	Synchronous	Synchronous	
Reentrancy	Non Reentrant	Non Reentrant	
Parameters (in)	NonTlsAllowed	NonTlsAllowed NonTlsAllowed: Requested behavior of DoIP	
Parameters (inout)	None	None	
Parameters (out)	None	None	
Return value	None	None	
Description	establishments. If called	Call with argument NonTlsAllowed==TRUE to allow unsecured DoIP connection establishments. If called with NonTlsAllowed==FALSE, DoIP will close the unsecured connection with NRC 0x07 and require the tester to use TLS.	
Available via	DoIP.h		

8.4 Call-back notifications

In AUTOSAR, the functions a module provides to layers which are placed below the module in the AUTOSAR software layer model, are called 'call-back functions'. Generally, a software entity A (DoIP), which, in order to be informed about some event C in software entity B (SoAd), is registered as interested in event C at software entity B by calling a register mechanism B provides, and is called by entity B if event C occurs.

This chapter contains a list of Call-Back functions which are called by the lower layer SoAd module.



8.4.1 DoIP_SoAdTpCopyTxData

[SWS_DoIP_00031] Definition of callback function DoIP_SoAdTpCopyTxData

Upstream requirements: RS_Diag_00024

Service Name	DoIP_SoAdTpCopyTxData	
Syntax	BufReq_ReturnType DoIP_SoAdTpCopyTxData (PduIdType id, const PduInfoType* info, const RetryInfoType* retry, PduLengthType* availableDataPtr)	
Service ID [hex]	0x43	
Sync/Async	Synchronous	
Reentrancy	Reentrant	
Parameters (in)	id	Identification of the transmitted I-PDU.
	info	Provides the destination buffer (SduDataPtr) and the number of bytes to be copied (SduLength). If not enough transmit data is available, no data is copied by the upper layer module and BUFREQ_E_BUSY is returned. The lower layer module may retry the call. An SduLength of 0 can be used to indicate state changes in the retry parameter or to query the current amount of available data in the upper layer module. In this case, the Sdu DataPtr may be a NULL_PTR.
	retry	This parameter is used to acknowledge transmitted data or to retransmit data after transmission problems.
		If the retry parameter is a NULL_PTR, it indicates that the transmit data can be removed from the buffer immediately after it has been copied. Otherwise, the retry parameter must point to a valid RetryInfoType element.
		If TpDataState indicates Tp_CONFPENDING, the previously copied data must remain in the TP buffer to be available for error recovery. TP_DATACONF indicates that all data that has been copied before this call is confirmed and can be removed from the TP buffer. Data copied by this API call is excluded and will be confirmed later. TP_DATARETRY indicates that this API call shall copy previously copied data in order to recover from an error. In this case TxTpDataCnt specifies the offset in bytes from the current data copy position.
Parameters (inout)	None	
Parameters (out)	availableDataPtr	Indicates the remaining number of bytes that are available in the upper layer module's Tx buffer. availableDataPtr can be used by TP modules that support dynamic payload lengths (e.g. FrIsoTp) to determine the size of the following CFs.
Return value	BufReq_ReturnType	BUFREQ_OK: Data has been copied to the transmit buffer completely as requested. BUFREQ_E_BUSY: Request could not be fulfilled, because the required amount of Tx data is not available. The lower layer module may retry this call later on. No data has been copied. BUFREQ_E_NOT_OK: Data has not been copied. Request failed.





Δ

Description	This function is called to acquire the transmit data of an I-PDU segment (N-PDU). Each call to this function provides the next part of the I-PDU data unless retry->TpDataState is TP_ DATARETRY. In this case the function restarts to copy the data beginning at the offset from the current position indicated by retry->TxTpDataCnt. The size of the remaining data is written to the position indicated by availableDataPtr.
Available via	DoIP.h

[SWS DoIP 00175] [If development error detection is enabled: The function shall check that the service DoIP Init was previously called. If the check fails, the function shall raise the development error DOIP E UNINIT.

[SWS_DoIP_00176] [If development error detection is enabled: The function shall check if the id matches a configured DoIPSoAdTcpTxPduld. If the check fails the function shall raise the development error DOIP E INVALID PDU SDU ID.

[SWS DoIP 00177] [If development error detection is enabled: The function shall check that neither the info nor the availableDataPtr are a NULL PTR. If the check fails the function shall raise the development error DOIP E PARAM POINTER.

[SWS DoIP 00178] [If development error detection is enabled: The function shall check if the retry is a NULL PTR. If the check fails the function shall raise the development error DOIP E INVALID PARAMETER.

8.4.2 DoIP SoAdTpTxConfirmation

[SWS_DoIP_00032] Definition of callback function DoIP_SoAdTpTxConfirmation

Upstream requirements: RS Diag 00024

76 of 160

Service Name	DoIP_SoAdTpTxConfirmation	
Syntax	<pre>void DoIP_SoAdTpTxConfirmation (PduIdType id, Std_ReturnType result)</pre>	
Service ID [hex]	0x48	
Sync/Async	Synchronous	
Reentrancy	Reentrant	
Parameters (in)	id	Identification of the transmitted I-PDU.
	result	E_OK: The PDU was transmitted. E_NOT_OK: Transmission of the PDU failed.





 \triangle

Parameters (inout)	None
Parameters (out)	None
Return value	None
Description	This function is called after the I-PDU has been transmitted on its network, the result indicates whether the transmission was successful or not.
Available via	DolP.h

١

[SWS_DoIP_00180] [If development error detection is enabled: The function shall check that the service DoIP_Init was previously called. If the check fails, the function shall raise the development error DOIP_E_UNINIT.|

[SWS_DoIP_00181] [If development error detection is enabled: The function shall check if the id matches a configured DoIPSoAdTcpTxPduId. If the check fails the function shall raise the development error DOIP_E_INVALID_PDU_SDU_ID.]

[SWS_DoIP_00182] [If development error detection is enabled: The function shall check if the result is valid. If the check fails the function shall raise the development error DOIP_E_INVALID_PARAMETER.|

8.4.3 DoIP_SoAdTpCopyRxData

[SWS_DoIP_00033] Definition of callback function DoIP_SoAdTpCopyRxData

Upstream requirements: RS Diag 00024

Γ

Service Name	DoIP_SoAdTpCopyRxData	
Syntax	BufReq_ReturnType DoIP_SoAdTpCopyRxData (PduIdType id, const PduInfoType* info, PduLengthType* bufferSizePtr)	
Service ID [hex]	0x44	
Sync/Async	Synchronous	
Reentrancy	Reentrant	
Parameters (in)	id Identification of the received I-PDU.	
	info	Provides the source buffer (SduDataPtr) and the number of bytes to be copied (SduLength). An SduLength of 0 can be used to query the current amount of available buffer in the upper layer module. In this case, the SduDataPtr may be a NULL_PTR.
Parameters (inout)	None	
Parameters (out)	bufferSizePtr	Available receive buffer after data has been copied.





/\		١.
	_/	1
	_	_\

Return value	BufReq_ReturnType	BUFREQ_OK: Data copied successfully BUFREQ_E_NOT_OK: Data was not copied because an error occurred.
Description	This function is called to provide the received data of an I-PDU segment (N-PDU) to the upper layer. Each call to this function provides the next part of the I-PDU data. The size of the remaining buffer is written to the position indicated by bufferSizePtr.	
Available via	DoIP.h	

[SWS_DoIP_00183] [If development error detection is enabled: The function shall check that the service DoIP_Init was previously called. If the check fails, the function shall raise the development error DOIP E UNINIT.]

[SWS_DoIP_00036] [If development error detection is enabled: The function shall check if the id matches a configured DoIPSoAdTcpRxPduId. If the check fails the function shall raise the development error DOIP_E_INVALID_PDU_SDU_ID.]

[SWS_DoIP_00184] [If development error detection is enabled: The function shall check that neither the info nor the bufferSizePtr are a NULL_PTR. If the check fails, the function shall raise the development error DOIP_E_PARAM_POINTER.|

8.4.4 DoIP_SoAdTpStartOfReception

[SWS_DoIP_00037] Definition of callback function DoIP_SoAdTpStartOfReception

Upstream requirements: RS_Diag_00024

Γ

Service Name	DoIP_SoAdTpStartOfRecep	otion
Syntax	BufReq_ReturnType DoIP_SoAdTpStartOfReception (PduIdType id, const PduInfoType* info, PduLengthType TpSduLength, PduLengthType* bufferSizePtr)	
Service ID [hex]	0x46	
Sync/Async	Synchronous	
Reentrancy	Reentrant	
Parameters (in)	id	Identification of the I-PDU.





\triangle

	info	Pointer to a PduInfoType structure containing the payload data (without protocol information) and payload length of the first frame or single frame of a transport protocol I-PDU reception, and the MetaData related to this PDU. If neither first/single frame data nor MetaData are available, this parameter is set to NULL_PTR.
	TpSduLength	Total length of the N-SDU to be received.
Parameters (inout)	None	
Parameters (out)	bufferSizePtr	Available receive buffer in the receiving module. This parameter will be used to compute the Block Size (BS) in the transport protocol module.
Return value	BufReq_ReturnType BUFREQ_OK: Connection has been accepted. bufferSizePtr indicates the available receive buffer; reception is continued. If no buffer of the requested size is available, a receive buffer size of 0 shall be indicated by bufferSizePtr. BUFREQ_E_NOT_OK: Connection has been rejected; reception is aborted. bufferSizePtr remains unchanged. BUFREQ_E_OVFL: No buffer of the required length can be provided; reception is aborted. bufferSizePtr remains unchanged.	
Description	This function is called at the start of receiving an N-SDU. The N-SDU might be fragmented into multiple N-PDUs (FF with one or more following CFs) or might consist of a single N-PDU (SF). The service shall provide the currently available maximum buffer size when invoked with TpSdu Length equal to 0.	
Available via	DolP.h	

1

[SWS_DoIP_00186] [If development error detection is enabled: The function shall check that the service DoIP_Init was previously called. If the check fails, the function shall raise the development error DOIP_E_UNINIT.]

[SWS_DoIP_00187] [If development error detection is enabled: The function shall check if the id matches a configured DoIPSoAdTcpRxPduId. If the check fails the function shall raise the development error DOIP_E_INVALID_PDU_SDU_ID.]

[SWS_DoIP_00188] [If development error detection is enabled: The function shall check if the bufferSizePtr is not a NULL_PTR. If the check fails the function shall raise the development error DOIP_E_PARAM_POINTER.]

[SWS_DoIP_00189] [If development error detection is enabled: The function shall check if the TpSduLength is not 0. If TpSduLength is not 0 the function shall raise the development error DOIP_E_INVALID_PARAMETER.]

Note: This is because SoAd will call the DoIP module only once with the TpSduLength set to 0 after the TCP connection has been established.



8.4.5 DoIP SoAdTpRxIndication

[SWS_DoIP_00038] Definition of callback function DoIP_SoAdTpRxIndication

Upstream requirements: RS_Diag_00024

Γ

Service Name	DoIP_SoAdTpRxIndication	DoIP_SoAdTpRxIndication	
Syntax	void DoIP_SoAdTpRxIndication (PduIdType id, Std_ReturnType result)		
Service ID [hex]	0x45		
Sync/Async	Synchronous		
Reentrancy	Reentrant		
Parameters (in)	id Identification of the received I-PDU.		
	result	E_OK: The PDU was received. E_NOT_OK: Reception of the PDU failed.	
Parameters (inout)	None		
Parameters (out)	None		
Return value	None		
Description	Called after an I-PDU has been received via the TP API, the result indicates whether the transmission was successful or not.		
Available via	DoIP.h		

[SWS_DoIP_00190] [If development error detection is enabled: The function shall check that the service DoIP_Init was previously called. If the check fails, the function shall raise the development error DOIP_E_UNINIT.|

[SWS_DoIP_00191] [If development error detection is enabled: The function shall check if the id matches a configured DoIPSoAdTcpRxPduId. If the check fails the function shall raise the development error DOIP E INVALID PDU SDU ID.]

[SWS_DoIP_00192] [If development error detection is enabled: The function shall check if the result is valid. If the check fails the function shall raise the development error DOIP_E_INVALID_PARAMETER.]



8.4.6 DoIP SoAdlfRxIndication

[SWS_DoIP_00244] Definition of callback function DoIP_SoAdlfRxIndication

Upstream requirements: RS_Diag_00024

Γ

Service Name	DoIP_SoAdIfRxIndication	DoIP_SoAdIfRxIndication	
Syntax	<pre>void DoIP_SoAdIfRxIndication (PduIdType RxPduId, const PduInfoType* PduInfoPtr)</pre>		
Service ID [hex]	0x42		
Sync/Async	Synchronous	Synchronous	
Reentrancy	Reentrant for different Pdulds. Non reentrant for the same Pduld.		
Parameters (in)	RxPduld	RxPduId ID of the received PDU.	
	PduInfoPtr	Contains the length (SduLength) of the received PDU, a pointer to a buffer (SduDataPtr) containing the PDU, and the MetaData related to this PDU.	
Parameters (inout)	None	None	
Parameters (out)	None		
Return value	None		
Description	Indication of a received PDU from a lower layer communication interface module.		
Available via	DoIP.h		

[SWS_DoIP_00246] [If development error detection is enabled: The function shall check that the service DoIP_Init was previously called. If the check fails, the function shall raise the development error DOIP E UNINIT.]

[SWS_DoIP_00247] [If development error detection is enabled: The function shall check if the RxPduld matches a configured DoIPSoAdUdpRxPduld. If the check fails the function shall raise the development error DOIP_E_INVALID_PDU_SDU_ID.]

[SWS_DoIP_00248] [If development error detection is enabled: The function shall check the validity of the PduInfoPtr and call the DET with DOIP_E_PARAM_POINTER error id if it is a NULL_PTR.]



8.4.7 DoIP SoAdIfTxConfirmation

[SWS_DoIP_00245] Definition of callback function DoIP_SoAdIfTxConfirmation

Upstream requirements: RS_Diag_00024

Γ

Service Name	DoIP_SoAdlfTxConfirmation	1
Syntax	<pre>void DoIP_SoAdIfTxConfirmation (PduIdType TxPduId, Std_ReturnType result)</pre>	
Service ID [hex]	0x40	
Sync/Async	Synchronous	
Reentrancy	Reentrant for different Pdulds. Non reentrant for the same Pduld.	
Parameters (in)	TxPduld ID of the PDU that has been transmitted.	
	result E_OK: The PDU was transmitted. E_NOT_OK: Transmission of the PDU failed.	
Parameters (inout)	None	
Parameters (out)	None	
Return value	None	
Description	The lower layer communication interface module confirms the transmission of a PDU, or the failure to transmit a PDU.	
Available via	DoIP.h	

[SWS_DoIP_00249] [If development error detection is enabled: The function shall check that the service DoIP_Init was previously called. If the check fails, the function shall raise the development error DOIP_E_UNINIT.]

[SWS_DoIP_00250] [If development error detection is enabled: The function shall check if the TxPduId matches a configured DoIPSoAdUdpTxPduId. If the check fails the function shall raise the development error DOIP_E_INVALID_PDU_SDU_ID.|



8.4.8 DoIP_SoConModeChg

[SWS_DoIP_00039] Definition of callback function DoIP_SoConModeChg

Upstream requirements: RS_Diag_00081, RS_Diag_00028

Γ

Service Name	DoIP_SoConModeChg	
Syntax	void DoIP_SoConModeChg (SoAd_SoConIdType SoConId, SoAd_SoConModeType Mode)	
Service ID [hex]	0x0b	
Sync/Async	Synchronous	
Reentrancy	Reentrant for different SoConlds. Non reentrant for the same SoConld.	
Parameters (in)	SoConId socket connection index specifying the socket connection with the mode change.	
	Mode new mode	
Parameters (inout)	None	
Parameters (out)	None	
Return value	None	
Description	Notification about a SoAd socket connection state change, e.g. socket connection gets online	
Available via	DoIP.h	

[SWS_DoIP_00193] [If development error detection is enabled: The function shall check that the service DoIP_Init was previously called. If the check fails, the function shall raise the development error DOIP_E_UNINIT.|

[SWS_DoIP_00194] [If development error detection is enabled: The function shall check if the SoConId and Mode are valid. If the check fails the function shall raise the development error DOIP_E_INVALID_PARAMETER.|



8.4.9 DoIP_LocallpAddrAssignmentChg

[SWS_DoIP_00040] Definition of callback function DoIP_LocallpAddrAssignment Chg

Upstream requirements: RS_Diag_00081, RS_Diag_00028

Γ

Service Name	DoIP_LocallpAddrAssignm	DoIP_LocallpAddrAssignmentChg		
Syntax	SoAd_SoConIdType S	<pre>void DoIP_LocalIpAddrAssignmentChg (SoAd_SoConIdType SoConId, TcpIp_IpAddrStateType State)</pre>		
Service ID [hex]	0x0c			
Sync/Async	Synchronous	Synchronous		
Reentrancy	Reentrant for different SoC	Reentrant for different SoConlds. Non reentrant for the same SoConld.		
Parameters (in)	SoConId socket connection index specifying the socket connection when the IP address assignment has changed			
	State	State state of IP address assignment		
Parameters (inout)	None	None		
Parameters (out)	None	None		
Return value	None			
Description	This function gets called by the SoAd if an IP address assignment related to a socket connection changes (i.e. new address assigned or assigned address becomes invalid).			
Available via	DolP.h			

1

[SWS_DoIP_00195] [If development error detection is enabled: The function shall check that the service DoIP_Init was previously called. If the check fails, the function shall raise the development error DOIP_E_UNINIT.|

[SWS_DoIP_00196] [If development error detection is enabled: The function shall check if the SoConId and State are valid. If the check fails the function shall raise the development error DOIP_E_INVALID_PARAMETER.]

8.5 Scheduled functions

The Basic Software Scheduler within the Rte [8] directly calls these functions. The following functions shall have no return value and no parameter. All functions shall be non reentrant.



8.5.1 DoIP MainFunction

[SWS_DoIP_00041] Definition of scheduled function DoIP_MainFunction [

Service Name	DoIP_MainFunction
Syntax	<pre>void DoIP_MainFunction (void)</pre>
Service ID [hex]	0x02
Description	Schedules the Diagnostic over IP module. (Entry point for scheduling)
Available via	SchM_DoIP.h

[SWS_DoIP_00042] [The main function for scheduling the DoIP module (Entry point for scheduling) shall be called by the Schedule Manager according to the configured call period.]

[SWS_DoIP_00043] [The call period of the DoIP_MainFunction() is determined by the configuration parameter DoIPMainFunctionPeriod.

8.6 Expected Interfaces

In this chapter all interfaces required from other modules are listed.

8.6.1 Mandatory Interfaces

This chapter defines all interfaces which are required to fulfill the core functionality of the module.

[SWS_DoIP_00044] Definition of mandatory interfaces required by module DoIP

API Function	Header File	Description
Dcm_GetVin	Dcm.h	Function to get the VIN (as defined in SAE J1979-DA)
PduR_DoIPTpCopyRxData	PduR_DoIPTp.h	This function is called to provide the received data of an I-PDU segment (N-PDU) to the upper layer. Each call to this function provides the next part of the I-PDU data. The size of the remaining buffer is written to the position indicated by bufferSizePtr.





 \triangle

API Function	Header File	Description
PduR DoIPTpCopyTxData	PduR DolPTp.h	This function is called to acquire the transmit data of
Tour_boil Tpoopy Inbala		an I-PDU segment (N-PDU). Each call to this function provides the next part of the I-PDU data unless retry->TpDataState is TP_DATARETRY. In this case the function restarts to copy the data beginning at the offset from the current position indicated by retry->TxTpDataCnt. The size of the remaining data is written to the position indicated by availableDataPtr.
PduR_DoIPTpRxIndication	PduR_DoIPTp.h	Called after an I-PDU has been received via the TP API, the result indicates whether the transmission was successful or not.
PduR_DoIPTpStartOfReception	PduR_DolPTp.h	This function is called at the start of receiving an N-SDU. The N-SDU might be fragmented into multiple N-PDUs (FF with one or more following CFs) or might consist of a single N-PDU (SF). The service shall provide the currently available maximum buffer size when invoked with TpSdu Length equal to 0.
PduR_DoIPTpTxConfirmation	PduR_DolPTp.h	This function is called after the I-PDU has been transmitted on its network, the result indicates whether the transmission was successful or not.
SoAd_CloseSoCon	SoAd.h	This service closes the socket connection specified by SoConId.
SoAd_GetPhysAddr	SoAd.h	Retrieves the physical source address of the EthIf controller used by the SoAd socket connection specified by SoConId.
SoAd_GetSoConId	SoAd.h	Returns socket connection index related to the specified TxPduld.
SoAd_lfTransmit	SoAd.h	Requests transmission of a PDU.
SoAd_OpenSoCon	SoAd.h	This service opens the socket connection specified by SoConId.
SoAd_ReadDhcpHostNameOption	SoAd.h	By this API service an upper layer of the SoAd can read the currently configured hostname, i.e. FQDN option in the DHCP submodule of the TCP/IP stack.
SoAd_ReleaselpAddrAssignment	SoAd.h	By this API service the local IP address assignment used for the socket connection specified by SoConId is released.
SoAd_RequestlpAddrAssignment	SoAd.h	By this API service the local IP address assignment which shall be used for the socket connection specified by SoConld is initiated.
SoAd_TpTransmit	SoAd.h	Requests transmission of a PDU.
SoAd_WriteDhcpHostNameOption	SoAd.h	By this API service an upper layer of the SoAd can set the hostname, i.e. FQDN option in the DHCP submodule of the TCP/IP stack.

١

8.6.2 Optional Interfaces

This chapter defines all interfaces which are required by the DoIP module to fulfill an optional functionality of the DoIP module.



[SWS_DoIP_00045] Definition of optional interfaces requested by module DoIP [

API Function	Header File	Description
Det_ReportError	Det.h	Service to report development errors.
PduR_DoIPIfTxConfirmation	PduR_DoIPIf.h	The lower layer communication interface module confirms the transmission of a PDU, or the failure to transmit a PDU.

Note: The PduR_DoIPIfTxConfirmation optional interface is needed only if the DoIPP-duType is set to DOIP_IFPDU for at least one Tx PDU, which is the case when UUDT frames are sent via Ethernet

8.6.3 Configurable interfaces

In this chapter all interfaces are listed where the target function could be configured. The target function is usually a call-back function. The names of these kind of interfaces is not fixed because they are configurable.

8.6.3.1 < User>_DoIPGetPowerModeCallback

[SWS_DoIP_00047] Definition of configurable interface <User>_DoIPGetPower ModeCallback

Upstream requirements: RS Diag 00080

Γ

Service Name	<user>_DoIPGetPowerModeCallback</user>	
Syntax	Std_ReturnType <user>_DoIPGetPowerModeCallback (DoIP_PowerStateType* PowerStateReady)</user>	
Sync/Async	Synchronous	
Reentrancy	Don't care	
Parameters (in)	None	
Parameters (inout)	None	
Parameters (out)	PowerStateReady Pointer containing the information of the PowerModeStatus. Only valid if the return value equals E_OK.	
Return value	Std_ReturnType	
Description	Callback function to check if the PowerMode of the DoIP entity is ready or not.	
	The <user> part of the function name is configurable via parameter DoIPPowerModeDirect ([ECUC_DoIP_00027]).</user>	
Available via	DoIP_Externals.h	



8.6.3.2 < User>_DolPRoutingActivationConfirmation

[SWS_DoIP_00048] Definition of configurable interface <User>_DoIPRoutingActivationConfirmation

Upstream requirements: RS_Diag_00084

Γ

Service Name	<use><user>_DoIPRoutingActiv</user></use>	<user>_DoIPRoutingActivationConfirmation</user>	
Syntax	boolean* Confirmed	<pre>Std_ReturnType <user>_DoIPRoutingActivationConfirmation (boolean* Confirmed, const uint8* ConfirmationReqData, uint8* ConfirmationResData)</user></pre>	
Sync/Async	Synchronous		
Reentrancy	Don't care		
Parameters (in)	ConfirmationReqData	Pointer to OEM specific bytes for Routing activation request. Only needed if DoIPRoutingActivationConfirmationReqLength is not 0.	
Parameters (inout)	None	None	
Parameters (out)	Confirmed	Pointer containing the information if Confirmation was successful (TRUE) or not (FALSE). Only valid if the return value equals E_OK.	
	ConfirmationResData	Pointer to OEM specific bytes for Response on Routing activation. Only needed if DoIPRoutingActivationConfirmationRes Length if not 0. Contains valid data if function return with E_OK.	
Return value	Std_ReturnType	E_OK: Confirmed and ConfirmationResData contain valid Data. DOIP_E_PENDING: Confirmation still running. Call next DoIP_ MainFunction cycle again. E_NOT_OK: Confirmed and/or ConfirmationResData do not contain valid information.	
Description	Callback function to get the	Callback function to get the confirmation for the Routing Activation.	
Available via	DoIP_Externals.h		



8.6.3.3 < User>_DolPRoutingActivationAuthentication

[SWS_DoIP_00049] Definition of configurable interface <User>_DoIPRoutingActivationAuthentication

Upstream requirements: RS_Diag_00084

Γ

Service Name	<user>_DoIPRoutingActivationAuthentication</user>		
Syntax	<pre>Std_ReturnType <user>_DoIPRoutingActivationAuthentication (boolean* Authentified, const uint8* AuthenticationReqData, uint8* AuthenticationResData)</user></pre>		
Sync/Async	Synchronous		
Reentrancy	Don't care		
Parameters (in)	AuthenticationReqData	Pointer to OEM specific bytes for Routing activation request. Only needed if DoIPRoutingActivationAuthenticationReqLength is not 0.	
Parameters (inout)	None		
Parameters (out)	Authentified	Pointer containing the information if Confirmation was successful (TRUE) or not (FALSE). Only valid if the return value equals E_OK.	
	AuthenticationResData	Pointer to OEM specific bytes for Response on Routing activation. Only needed if DoIPRoutingActivationAuthenticationResLength if not 0. Contains valid data if function return with E_OK.	
Return value	Std_ReturnType	E_OK: Authentified and AuthenticationResData contain valid Data. DOIP_E_PENDING: Authentication still running. Call next DoIP_ MainFunction cycle again. E_NOT_OK: Authentified and/or AuthenticationResData do not contain valid information.	
Description	Callback function to get the	Callback function to get the confirmation for the Routing Activation.	
Available via	DoIP_Externals.h		

8.6.3.4 < User>_DolPTriggerGidSyncCallback

[SWS_DoIP_00050] Definition of configurable interface <User>_DoIPTriggerGid SyncCallback

Upstream requirements: RS_Diag_00026

Γ

Service Name	<user>_DoIPTriggerGidSyncCallback</user>	
Syntax	Std_ReturnType <user>_DoIPTriggerGidSyncCallback (void)</user>	





 \triangle

Sync/Async	Synchronous		
Reentrancy	Don't care		
Parameters (in)	None		
Parameters (inout)	None		
Parameters (out)	None		
Return value	Std_ReturnType E_OK: GroupIdentifier Synchronization was triggered E_NOT_OK: GroupIdentifier Synchronization could not be triggered so try again next MainFunction		
Description	Function is used in the case that DoIPVinGIDMaster is set to true and a container DoIPTrigger GidSyncCallback is configured to trigger the synchronization process of the GroupIdentifier.		
	The <user> part of the function name is configurable via parameter DoIPTriggerGidSyncDirect ([ECUC_DoIP_00029]).</user>		
Available via	DoIP_Externals.h		

8.6.3.5 < User>_DolPGetGidCallback

[SWS_DoIP_00051] Definition of configurable interface <User>_DoIPGetGidCallback

Upstream requirements: RS_Diag_00026

Γ

Service Name	<user>_DoIPGetGidCallbac</user>	k		
Syntax	<pre>Std_ReturnType <user>_DoIPGetGidCallback (uint8* GroupId)</user></pre>			
Sync/Async	Synchronous			
Reentrancy	Don't care			
Parameters (in)	None			
Parameters (inout)	None	None		
Parameters (out)	Groupld	Pointer to GroupIdentifier		
Return value	Std_ReturnType E_OK: GroupId contains a valid value E_NOT_OK: GroupId does not contain a valid value			
Description	Function is used in the case that DoIPVinGIDMaster is set to false and DoIPGetGidCallback is configured to get on a vehicle identification the GID. If the return value is not E_OK the DoIP shall use the default GID.			
	The <user> part of the function name is configurable via parameter DoIPGetGidDirect ([ECUC_DoIP_00028]).</user>			
Available via	DoIP_Externals.h			



8.6.3.6 < User>_DolPGetFurtherActionByteCallback

[SWS_DoIP_00288] Definition of configurable interface <User>_DoIPGetFurther ActionByteCallback

Upstream requirements: RS_Diag_00026

Γ

Service Name	<user>_DoIPGetFurtherAc</user>	<user>_DoIPGetFurtherActionByteCallback</user>		
Syntax		<pre>Std_ReturnType <user>_DoIPGetFurtherActionByteCallback (DoIP_FurtherActionByteType* FurtherActionByte)</user></pre>		
Sync/Async	Synchronous			
Reentrancy	Don't care			
Parameters (in)	None	None		
Parameters (inout)	None	None		
Parameters (out)	FurtherActionByte	FurtherActionByte Pointer containing the information of the FurtherActionByte. Only valid if the return value equals E_OK.		
Return value	Std_ReturnType			
Description	Callback function to get the OEM specific Further Action Byte for the DoIP vehicle identification response/vehicle announcement.			
Available via	DoIP_Externals.h			

8.6.4 DolP Service Component

The following section describes the DoIP service representation and the condition for which configuration Services have to be requested and provided by the DoIP module.

[SWS_DoIP_00052] [A DoIP Service Component with the ShortName DoIP shall be provided based on the configuration of the DoIP module.]

The DoIP Service Component shall provide the interface CallbackGetPowerMode as described below to request the value of the Power mode for DoIP diagnostic power mode handling.

[SWS_DoIP_00054] Definition of ClientServerInterface CallbackGetPowerMode

Upstream requirements: RS Diag 00080

Γ



Name	CallbackGetPowerMode			
Comment	_	-		
IsService	true	true		
Variation	{ecuc(DoIP/DoIPGeneral/DoIPPowerModeCallback/DoIPPowerModeDirect)} == NULL			
Possible Errors	0	0 E_OK Operation successful		
	1	1 E_NOT_OK Operation failed		

Operation	GetPowerMode	e		
Comment	_			
Mapped to API	_			
Variation	_	-		
Parameters	PowerStateReady			
	Туре	DoIP_PowerStateType		
	Direction	OUT		
	Comment	_		
	Variation	-		
Possible Errors	E_OK E_NOT_OK			

1

The DoIP Service Component shall be equipped with a service port as described below to request the value of the Power mode for DoIP diagnostic power mode handling.

[SWS_DoIP_00261] Definition of Port CBGetPowerMode required by module Do IP

Upstream requirements: RS_Diag_00080

Γ

Name	CBGetPowerMode		
Kind	RequiredPort Interface CallbackGetPowerMode		
Description	-		
Variation	{ecuc(DoIP/DoIPGeneral/DoIPPowerModeCallback/DoIPPowerModeDirect)} == NULL		

١

The DoIP Service Component shall provide the service port interface <NameOfRoutingActivation>_RoutingActivation as described below for each DoIPRoutingActivation that has at least DoIPRoutingActivationConfirmationCallback or DoIPRoutingActivationAuthenticationCallback configured without direct Callback functions.

[SWS_DoIP_00055] Definition of ClientServerInterface {Name}_RoutingActivation

Upstream requirements: RS_Diag_00084

Γ



Name	{Name}_RoutingActivation			
Comment	_			
IsService	true			
Variation	(({ecuc(DoIP/DoIPConfigSet/DoIPInterface/DoIPRoutingActivation/DoIPRoutingActivation AuthenticationCallback)} != null) && ({ecuc(DoIP/DoIPConfigSet/DoIPInterface/DoIPRouting Activation/DoIPRoutingActivationAuthentication Callback/DoIPRoutingActivationAuthentication Func)} == "")) (({ecuc(DoIP/DoIPConfigSet/DoIPInterface/DoIPRoutingActivation/DoIPRoutingActivationConfirmationCallback)} != null) && ({ecuc(DoIP/DoIPConfigSet/DoIPInterface/DoIPRoutingActivationConfirmationCallback/DoIPRoutingActivationConfirmationCallback/DoIPRoutingActivationConfirmationFunc)} == "")) Name = {ecuc(DoIP/DoIPConfigSet/DoIPInterface/DoIPRoutingActivation.SHORT-NAME)}			
Possible Errors	0 E_OK Operation successful			
	1	1 E_NOT_OK Operation failed		
	16	DOIP_E_PENDING	RoutingActivation still pending.	

Operation	RoutingActiva	RoutingActivationAuthentication			
Comment	-	-			
Mapped to API	-	-			
Variation	Authentication Activation/Dol Func)} ==NUl	(({ecuc(DoIP/DoIPConfigSet/DoIPInterface/DoIPRoutingActivation/DoIPRoutingActivation AuthenticationCallback)} != NULL) && ({ecuc(DoIP/DoIPConfigSet/DoIPInterface/DoIPRouting Activation/DoIPRoutingActivationAuthenticationCallback/DoIPRoutingActivationAuthentication Func)} == NULL))			
Parameters	Authentified				
rarameters	Туре	boolean			
	Direction	OUT			
	Comment	-			
	Variation	-			
	Authentication	AuthenticationReqData			
	Туре	AuthenticationReqDataType_{Name}			
	Direction	IN			
	Comment	-			
	Variation	{ecuc(DoIP/DoIPConfigSet/DoIPInterface/DoIPRoutingActivation/DoIPRouting ActivationAuthenticationCallback.DoIPRoutingActivationAuthenticationReq Length)} > 0 Name = {ecuc(DoIP/DoIPConfigSet/DoIPInterface/DoIPRouting Activation.SHORT-NAME)}			
	Authentication	ResData			
	Туре	AuthenticationResDataType_{Name}			
	Direction	OUT			
	Comment	-			
	Variation	{ecuc(DoIP/DoIPConfigSet/DoIPInterface/DoIPRoutingActivation/DoIPRouting ActivationAuthenticationCallback.DoIPRoutingActivationAuthenticationRes Length)} > 0 Name = {ecuc(DoIP/DoIPConfigSet/DoIPInterface/DoIPRouting Activation.SHORT-NAME)}			
Possible Errors	E_OK E_NOT_OK DOIP_E_PEN	IDING			

Operation	RoutingActivationConfirmation		
Comment	-		
Mapped to API	-		





 \triangle

Variation	(({ecuc(DoIP/DoIPConfigSet/DoIPInterface/DoIPRoutingActivation/DoIPRoutingActivation ConfirmationCallback)} != NULL) && ({ecuc(DoIP/DoIPConfigSet/DoIPInterface/DoIPRouting Activation/DoIPRoutingActivationConfirmationCallback/DoIPRoutingActivationConfirmation Func)} == NULL))		
Parameters	Confirmed		
raiailieleis	Туре	boolean	
	Direction	OUT	
	Comment	-	
	Variation	_	
	ConfirmedReq	Data	
	Туре	ConfirmationReqDataType_{Name}	
	Direction	IN	
	Comment	-	
	Variation {		
	ConfirmedResData		
	Type ConfirmationResDataType_{Name}		
	Direction	OUT	
	Comment	_	
	Variation	{ecuc(DoIP/DoIPConfigSet/DoIPInterface/DoIPRoutingActivation/DoIPRouting ActivationConfirmationCallback.DoIPRoutingActivationConfirmationRes Length)} > 0 Name = {ecuc(DoIP/DoIPConfigSet/DoIPInterface/DoIPRouting Activation.SHORT-NAME)}	
Possible Errors	E_OK E_NOT_OK DOIP_E_PENI	DING	

1

The DoIP Service Component shall be equipped with a service port as described below for each DoIPRoutingActivation that has at least DoIPRoutingActivationConfirmationCallback or DoIPRoutingActivationAuthenticationCallback configured without direct Callback functions.

[SWS_DoIP_00262] Definition of Port CB{Name}RoutingActivation required by module DoIP

Upstream requirements: RS_Diag_00084

Γ

Name	CB{Name}RoutingActivation		
Kind	RequiredPort Interface {Name}_RoutingActivation		
Description	-		
Variation	Name = {ecuc(DoIP/DoIPConfigSet/DoIPInterface/DoIPRoutingActivation.SHORT-NAME)}		



The DoIP Service Component shall provide the service port interface CallbackTriggerGIDSyncronization as described below if the container DoIPTriggerGIDSyncCallback is configured without direct Callback function.

[SWS_DoIP_00056] Definition of ClientServerInterface CallbackTriggerGIDSynchronization

Upstream requirements: RS_Diag_00026

Γ

Name	CallbackTriggerGIDSynchronization		
Comment	_		
IsService	true		
Variation	({ecuc(DoIP/DoIPGeneral/DoIPTriggerGidSyncCallback)} != NULL) && ({ecuc(DoIP/DoIPGeneral/DoIPTriggerGidSyncDirect)} == NULL) && ({ecuc(DoIP/DoIPGeneral/DoIPVinGidMaster)} == TRUE)		
Possible Errors	0 E_OK Operation successful		Operation successful
	1	E_NOT_OK	Operation failed

Operation	TriggerGIDSynchronization
Comment	-
Mapped to API	-
Variation	-
Possible Errors	E_OK E_NOT_OK

The DoIP Service Component shall be equipped with a service port as described below if the container DoIPTriggerGIDSyncCallback is configured without direct Callback function.

[SWS_DoIP_00263] Definition of Port CBTriggerGIDSynchronization required by module DoIP

Upstream requirements: RS_Diag_00026

Γ

Name	CBTriggerGIDSynchronization		
Kind	RequiredPort Interface CallbackTriggerGIDSynchronization		
Description	_		
Variation	({ecuc(DoIP/DoIPGeneral/DoIPTriggerGidSyncCallback)} != NULL) && ({ecuc(DoIP/DoIPGeneral/DoIPTriggerGidSyncCallback/DoIPTriggerGidSyncDirect)} == NULL) && ({ecuc(DoIP/DoIPGeneral/DoIPVinGidMaster)} == TRUE)		



The DoIP Service Component shall provide the service port interface CallbackGetGID as described below to request the GID if the container DoIPGetGidCallback is configured without direct Callback function.

[SWS DoIP 00057] Definition of ClientServerInterface CallbackGetGID

Upstream requirements: RS_Diag_00026

Name	CallbackGetGID		
Comment	_		
IsService	true		
Variation	({ecuc(DoIP/DoIPGeneral/DoIPGetGidCallback)} != NULL) && ({ecuc(DoIP/DoIPGeneral/DoIPGetGidCallback/DoIPGetGidDirect)} == NULL)		
Possible Errors	0 E_OK Operation successful		
	1 E_NOT_OK Operation failed		Operation failed

Operation	GetGID		
Comment	_		
Mapped to API	_		
Variation	-		
Parameters	Data		
	Туре	uint8	
	Direction	OUT	
	Comment	-	
	Variation	_	
Possible Errors	E_OK E_NOT_OK		

1

The DoIP Service Component shall provide the service port as described below to request the GID if the container DoIPGetGidCallback is configured without direct Callback function

[SWS_DoIP_00264] Definition of Port CBGetGID required by module DoIP

Upstream requirements: RS_Diag_00026

Γ

Name	CBGetGID		
Kind	RequiredPort Interface CallbackGetGID		
Description	_		
Variation	({ecuc(DoIP/DoIPGeneral/DoIPGetGidCallback)} != NULL) && ({ecuc(DoIP/DoIPGeneral/DoIPGetGidCallback/DoIPGetGidDirect)} == NULL)		



The DoIP Service Component shall provide the interface DoIPActivationLineStatus as described below to be informed on the transition of the ActivationLine for DoIP.

The DoIP Service Component shall provide the interface CallbackGetFurtherAction-Byte as described below to request the value of the OEM specific Further Action Byte for the DoIP vehicle identification response/vehicle announcement.

[SWS_DoIP_00290] Definition of ClientServerInterface CallbackGetFurtherAction Byte

Upstream requirements: RS_Diag_00026

Γ

Name	CallbackGetFurtherActionByte		
Comment	_		
IsService	true		
Variation	{ecuc(DoIP/DoIPConfigSet/DoIPInterface/DoIPFurtherActionByteCallback/DoIPFurtherActionByteDirect)} == NULL		
Possible Errors	0 E_OK Operation successful		
	1 E_NOT_OK Operation failed		

Operation	GetFurtherActionByte			
Comment	_			
Mapped to API	<user>_DoIPC</user>	GetFurtherActionByteCallback		
Variation	_			
Parameters	FurtherActionE	FurtherActionByte		
	Туре	Type DoIP_FurtherActionByteType		
	Direction OUT			
	Comment –			
	Variation –			
Possible Errors	E_OK E_NOT_OK			

The DoIP Service Component shall be equipped with a service port per DoIPInterface as described below to request the value of the Further Action Byte for DoIP diagnostic vehicle identification response/vehicle announcement.



[SWS_DoIP_00289] Definition of Port CBGetfurtherActionByte*_{DoIPInterface_short_name}* required by module DoIP

Upstream requirements: RS_Diag_00026

Γ

Name	CBGetfurtherActionByte*_{DoIPInterface_short_name}*		
Kind	RequiredPort Interface CallbackGetFurtherActionByte		
Description	-		
Variation	{ecuc(DoIP/DoIPConfigSet/DoIPInterface/DoIPFurtherActionByteCallback/DoIPFurtherActionByte Direct)} == NULL		



9 Sequence diagrams

9.1 UDP DoIP communication




Figure 9.1: DoIP UDP communication



9.2 Rx TCP message




Figure 9.2: DoIP TCP message reception



Note that more than one CopyRxData could provide the data of one request, but to reduce complexity this detail was omitted.

9.3 Tx TCP message




Figure 9.3: DoIP TCP message transmission



9.4 Activation Line Handling - Active




Figure 9.4: Activation Line Handling - Active



9.5 Activation Line Handling - Inactive




Figure 9.5: Activation Line Handling - Inactive



10 Configuration specification

Chapter 10.2 specifies the structure (containers) and the parameters of the module DoIP. Chapter 10.3 specifies additionally published information of the module DoIP.

10.1 How to read this chapter

For details refer to the chapter 10.1 "Introduction to configuration specification" in SWS_BSWGeneral [1].

10.2 Configuration and configuration parameters

The following chapters summarize all configuration parameters. For a detailed description of parameters please refer to chapter 7 and chapter 8.

10.2.1 Variants

For details refer to the chapter 10.1.2 "Variants" in SWS_BSWGeneral [1].

10.2.2 DoIP

[ECUC_DoIP_00001] Definition of EcucModuleDef DoIP [

Module Name	DoIP
Description	Configuration of the DoIP (Diagnostic over IP) module.
Post-Build Variant Support	true
Supported Config Variants	VARIANT-LINK-TIME, VARIANT-POST-BUILD, VARIANT-PRE-COMPILE

Included Containers			
Container Name	Multiplicity	Scope / Dependency	
DoIPConfigSet	1	This container contains the configuration parameters and sub containers of the AUTOSAR DoIP module.	
DolPGeneral	1	This container specifies the general configuration parameters of the DoIP module.	






Figure 10.1: DoIP

10.2.3 DolPGeneral

[ECUC_DoIP_00002] Definition of EcucParamConfContainerDef DoIPGeneral \lceil

Container Name	DolPGeneral
Parent Container	DoIP
Description	This container specifies the general configuration parameters of the DoIP module.
Configuration Parameters	

Included Parameters				
Parameter Name	Multiplicity	ECUC ID		
DoIPDevelopmentErrorDetect	1	[ECUC_DoIP_00004]		
DoIPDhcpOptionVinUse	1	[ECUC_DoIP_00067]		
DoIPEntityStatusMaxByteFieldUse	1	[ECUC_DoIP_00064]		
DoIPGIDInvalidityPattern	1	[ECUC_DoIP_00065]		
DoIPHostNameSizeMax	1	[ECUC_DoIP_00073]		
DoIPMainFunctionPeriod	1	[ECUC_DoIP_00006]		
DoIPMaxRequestBytes	1	[ECUC_DoIP_00019]		
DoIPMaxUDPRequestPerConnection	1	[ECUC_DoIP_00074]		
DoIPNodeType	1	[ECUC_DoIP_00021]		
DoIPVersionInfoApi	1	[ECUC_DoIP_00005]		
DoIPVinGidMaster	1	[ECUC_DoIP_00017]		
DoIPVinInvalidityPattern	1	[ECUC_DoIP_00066]		
DolPUseEidAsGidRef	01	[ECUC_DoIP_00106]		



Included Containers				
Container Name	Multiplicity	Scope / Dependency		
DolPGetGidCallback	01	This container describes the usage of a callback function to get the GID. (If this container is not present no callback function shall be used by DoIP module to retrive the GID.)		
DoIPPowerModeCallback	1	This container describes the usage of a callback function to retrieve the current power mode. This container shall always be present.		
DolPTriggerGidSyncCallback	01	This container describes the usage of a callback function to trigger the GID synchronization. (If this container does not exist no callback function shall be used by DoIP module to trigger the GID synchronization.)		

1

[ECUC_DoIP_00004] Definition of EcucBooleanParamDef DoIPDevelopmentError Detect $\ \lceil$

Parameter Name	DoIPDevelopmentErrorDetect			
Parent Container	DolPGeneral			
Description	Switches the development error detection and notification on or off.			
	• true: detection and notification is enabled.			
	false: detection and notification is	• false: detection and notification is disabled.		
Multiplicity	1			
Туре	EcucBooleanParamDef			
Default value	-			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time	Х	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

[ECUC_DoIP_00067] Definition of EcucBooleanParamDef DoIPDhcpOptionVin Use \lceil

Parameter Name	DoIPDhcpOptionVinUse		
Parent Container	DolPGeneral		
Description	If DoIPDhcpOptionVinUse is set to true the DoIP module will add the VIN to the Dhcp host name if no valid Dhcp host name is already set.		
Multiplicity	1		
Туре	EcucBooleanParamDef		
Default value	-		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	_	
	Post-build time	_	





 \triangle

Scope / Dependency

[ECUC_DoIP_00064] Definition of EcucBooleanParamDef DoIPEntityStatusMax ByteFieldUse \lceil

Parameter Name	DoIPEntityStatusMaxByteFieldUse		
Parent Container	DoIPGeneral		
Description	This parameter is used to distinguish the optional support of the Max data size element of a diagnostic entity status response.		
Multiplicity	1		
Туре	EcucBooleanParamDef		
Default value	-		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local	·	

1

[ECUC_DoIP_00065] Definition of EcucIntegerParamDef DoIPGIDInvalidityPattern \lceil

Parameter Name	DoIPGIDInvalidityPattern		
Parent Container	DolPGeneral		
Description	Specifies the Byte pattern that is used for response messages if no valid GID could be retrieved.		
	Only the value '0' or '255' is allowed".		
Multiplicity	1		
Туре	EcucIntegerParamDef		
Range	0 255		
Default value	-		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		



[ECUC_DoIP_00073] Definition of EcucIntegerParamDef DoIPHostNameSizeMax

Parameter Name	DoIPHostNameSizeMax		
Parent Container	DolPGeneral		
Description	Maximum Size of the DHCP HostName in ASCII. This parameter is necessary to reserve the correct amount of bytes for working with the DHCP HostName option. Minimum range is 5 because Dhcp Host Name should be at least "DoIP-" on any configuration.		
Multiplicity	1		
Туре	EcucIntegerParamDef		
Range	5 255		
Default value	-		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		

1

[ECUC_DoIP_00006] Definition of EcucFloatParamDef DoIPMainFunctionPeriod

Parameter Name	DoIPMainFunctionPeriod		
Parent Container	DolPGeneral		
Description	Determines the frequency at which the DoIP_MainFunction() is called in [s].		
Multiplicity	1		
Туре	EcucFloatParamDef		
Range]0 INF[
Default value	-		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		

١

[ECUC_DoIP_00019] Definition of EcucIntegerParamDef DoIPMaxRequestBytes

Parameter Name	DoIPMaxRequestBytes
Parent Container	DolPGeneral
Description	Specifies the maximum allowed bytes of a DoIP message request without the DoIP header.
Multiplicity	1
Туре	EcucIntegerParamDef





Range	1 4294967295			
Default value				
Post-Build Variant Value	false	false		
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local	•		

[ECUC_DoIP_00074] Definition of EcucIntegerParamDef DoIPMaxUDPRequest PerConnection $\ \lceil$

Parameter Name	DoIPMaxUDPRequestPerConnection			
Parent Container	DoIPGeneral	DolPGeneral		
Description	This parameter captures the maximum amount of UDP Requests necessary to handle parallel within a single UDP connection.			
Multiplicity	1			
Туре	EcucIntegerParamDef			
Range	1 255			
Default value	-			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time X All Variants			
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

1

[ECUC_DoIP_00021] Definition of EcucEnumerationParamDef DoIPNodeType [

Parameter Name	DoIPNodeType			
Parent Container	DoIPGeneral	DolPGeneral		
Description	Describes the Type of the DoIP nod	e.		
Multiplicity	1	1		
Туре	EcucEnumerationParamDef			
Range	DOIP_GATEWAY The DoIP Entity is a DoIP Gateway.			
	DOIP_NODE The DoIP Entity is a DoIP Node.			
Post-Build Variant Value	false	false		
Value Configuration Class	Pre-compile time X All Variants			
	Link time	_		
	Post-build time –			
Scope / Dependency	scope: local		-	



[ECUC_DoIP_00005] Definition of EcucBooleanParamDef DoIPVersionInfoApi

Parameter Name	DoIPVersionInfoApi			
Parent Container	DoIPGeneral	DolPGeneral		
Description	Activates the DoIP_GetVersionInfo() API. TRUE: Enables the DoIP_GetVersionInfo() API. FALSE: DoIP_GetVersionInfo() API is not included.			
Multiplicity	1			
Туре	EcucBooleanParamDef			
Default value	false			
Post-Build Variant Value	false	false		
Value Configuration Class	Pre-compile time X All Variants			
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

1

[ECUC_DoIP_00017] Definition of EcucBooleanParamDef DoIPVinGidMaster [

Parameter Name	DoIPVinGidMaster		
Parent Container	DolPGeneral		
Description	Specifies if the DoIP entity is the Ve	ehicle ide	ntification Master for the GID (Group ID).
Multiplicity	1		
Туре	EcucBooleanParamDef		
Default value	-		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time X All Variants		
	Link time –		
	Post-build time –		
Scope / Dependency	scope: local		
	dependency: DoIPUseEIDasGID, DoIPTriggerGIDSynchronization		

1

$[{\tt ECUC_DoIP_00066}] \ Definition \ of \ {\tt EcucIntegerParamDef \ DoIPVinInvalidityPattern}$

Parameter Name	DoIPVinInvalidityPattern		
Parent Container	DoIPGeneral		
Description	Specifies the Byte pattern that is used for response messages if no valid VIN could be retrieved.		
	Only the value '0' or '255' is allowed".		
Multiplicity	1		
Туре	EcucIntegerParamDef		
Range	0 255		
Default value	-		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	Х	All Variants





	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		

1

[ECUC_DoIP_00106] Definition of EcucReferenceDef DoIPUseEidAsGidRef \lceil

Parameter Name	DoIPUseEidAsGidRef			
Parent Container	DolPGeneral			
Description	Reference to the interface containing the EID which shall be used as GID. Depending on the configuration, the GID is derived either from DoIPEid or from DoIPUseMac AddressForIdentification.			
Multiplicity	01			
Туре	Reference to DolPInterface			
Post-Build Variant Multiplicity	false			
Post-Build Variant Value	false			
Multiplicity Configuration Class	Pre-compile time X All Variants			
	Link time –			
	Post-build time –			
Value Configuration Class	Pre-compile time	Pre-compile time X All Variants		
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local dependency: Parameter shall only be enabled if DoIPVinGidMaster is true. Either Do IPEid or DoIPUseMacAddressForldentification shall be set for the referenced interface.			






Figure 10.2: DoIPGeneral



10.2.4 DolPGetGidCallback

[ECUC_DoIP_00024] Definition of EcucParamConfContainerDef DoIPGetGidCallback \lceil

Container Name	DoIPGetGidCallback
Parent Container	DolPGeneral
Description	This container describes the usage of a callback function to get the GID. (If this container is not present no callback function shall be used by DoIP module to retrive the GID.)
Configuration Parameters	

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
DolPGetGidDirect	01	[ECUC_DoIP_00028]	

No Included Containers	
no morados comuniore	

[ECUC_DoIP_00028] Definition of EcucFunctionNameDef DoIPGetGidDirect

Parameter Name	DoIPGetGidDirect			
Parent Container	DoIPGetGidCallback			
Description	If the DoIPGetGidDirect parameter exist the DoIP module shall call the configured callback function (<user>_DoIPGetGID) direct. (It is not needed to specify a service port to the DoIP service component.) If the DoIPGetGidDirect parameter does NOT exist the DoIP module shall use a RPort with a CallbackGetGID type of client-server port interface to retrive the GID.</user>			
Multiplicity	01			
Туре	EcucFunctionNameDef			
Default value	-			
Regular Expression	-			
Post-Build Variant Multiplicity	false			
Post-Build Variant Value	false			
Multiplicity Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE			
	Link time X VARIANT-LINK-TIME, VARIANT-POST-BUILD			
	Post-build time	_		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE	
	Link time X VARIANT-LINK-TIME, VARIANT-POST-BUILD			
	Post-build time –			
Scope / Dependency	scope: local			



10.2.5 DolPPowerModeCallback

[ECUC_DoIP_00023] Definition of EcucParamConfContainerDef DoIPPowerMode Callback \lceil

Container Name	DoIPPowerModeCallback
Parent Container	DolPGeneral
Description	This container describes the usage of a callback function to retrieve the current power mode. This container shall always be present.
Configuration Parameters	

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
DoIPPowerModeDirect	01	[ECUC_DoIP_00027]

ncluded Containers

[ECUC_DoIP_00027] Definition of EcucFunctionNameDef DoIPPowerModeDirect

Parameter Name	DoIPPowerModeDirect			
Parent Container	DoIPPowerModeCallback			
Description	If the DoIPPowerModeDirect parameter exist the DoIP module shall call the configured callback function (<user>_DoIPGetPowerModeCallback) direct. (It is not needed to specify a service port to the DoIP service component.) If the DoIPPowerModeDirect parameter does NOT present the DoIP module shall use a RPort with a CallbackGet PowerMode type of client-server port interface to retrive the current power mode.</user>			
Multiplicity	01			
Туре	EcucFunctionNameDef			
Default value	-			
Regular Expression	-			
Post-Build Variant Multiplicity	false			
Post-Build Variant Value	false			
Multiplicity Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE			
	Link time X VARIANT-LINK-TIME, VARIANT-POST-BUILD			
	Post-build time –			
Value Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE			
	Link time	Х	VARIANT-LINK-TIME, VARIANT-POST-BUILD	
	Post-build time –			
Scope / Dependency	scope: local			



10.2.6 DolPTriggerGidSyncCallback

[ECUC_DoIP_00025] Definition of EcucParamConfContainerDef DoIPTriggerGid SyncCallback \lceil

Container Name	DoIPTriggerGidSyncCallback
Parent Container	DolPGeneral
Description	This container describes the usage of a callback function to trigger the GID synchronization. (If this container does not exist no callback function shall be used by DoIP module to trigger the GID synchronization.)
Configuration Parameters	

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
DoIPTriggerGidSyncDirect	01	[ECUC_DoIP_00029]

Containers

[ECUC_DoIP_00029] Definition of EcucFunctionNameDef DoIPTriggerGidSync Direct \lceil

Parameter Name	DoIPTriggerGidSyncDirect			
Parent Container	DoIPTriggerGidSyncCallback			
Description	If the DoIPTriggerGidSyncDirect parameter exist the DoIP module shall call the configured callback function (<user>_DoIPTriggerGidSyncCallback) direct. (It is not needed to specify a service port to the DoIP service component.) If the DoIPTriggerGid SyncDirect parameter does NOT present the DoIP module shall use a RPort with a CallbackTriggerGIDSynchnonization type of client-server port interface to trigger the GID synchronization.</user>			
Multiplicity	01			
Туре	EcucFunctionNameDef			
Default value	-			
Regular Expression	-			
Post-Build Variant Multiplicity	false			
Post-Build Variant Value	false			
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE	
	Link time X VARIANT-LINK-TIME, VARIANT-POST-BUILD			
	Post-build time –			
Value Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE			
	Link time	Х	VARIANT-LINK-TIME, VARIANT-POST-BUILD	
	Post-build time –			
Scope / Dependency	scope: local			



10.2.7 DolPConfigSet

[ECUC_DoIP_00003] Definition of EcucParamConfContainerDef DoIPConfigSet [

Container Name	DoIPConfigSet
Parent Container	DoIP
Description	This container contains the configuration parameters and sub containers of the AUTOSAR DoIP module.
Configuration Parameters	

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
DolPGid	01	[ECUC_DoIP_00015]	
DoIPLogicalAddress	1	[ECUC_DoIP_00020]	

Included Containers			
Container Name	Multiplicity	Scope / Dependency	
DolPInterface	1255	This container defines a logical IP interface and collects properties to configure this interface.	

1

[ECUC_DoIP_00015] Definition of EcucIntegerParamDef DoIPGid [

Parameter Name	DolPGid			
Parent Container	DoIPConfigSet			
Description	Configured GID (Group ID of) for vehicle identification/vehicle announcement.			
Multiplicity	01			
Туре	EcucIntegerParamDef			
Range	0 281474976710655			
Default value	-			
Post-Build Variant Multiplicity	true			
Post-Build Variant Value	true			
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE	
	Link time	Х	VARIANT-LINK-TIME	
	Post-build time X VARIANT-POST-BUILD			
Value Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE			
	Link time	Х	VARIANT-LINK-TIME	
	Post-build time	Х	VARIANT-POST-BUILD	
Scope / Dependency	scope: local			
	dependency: DoIPVinGIDMaster, DoIPGetGID DoIPGid shall be used if DoIPVinGid Master is true and DoIPUseEidAsGidRef is disabled.			

Ī



[ECUC_DoIP_00020] Definition of EcucIntegerParamDef DoIPLogicalAddress

Parameter Name	DoIPLogicalAddress			
Parent Container	DoIPConfigSet			
Description	Describes the logical address of the DoIP entity, i.e. the LA that will route diagnostic requests to the Dcm of the DoIP entity.			
Multiplicity	1			
Туре	EcucIntegerParamDef			
Range	0 65535	0 65535		
Default value	-			
Post-Build Variant Value	true			
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE	
	Link time	X	VARIANT-LINK-TIME	
	Post-build time X VARIANT-POST-BUILD			
Scope / Dependency	scope: local			






Figure 10.3: DoIPConfigSet

10.2.8 DolPInterface

[ECUC_DolP_00100] Definition of EcucParamConfContainerDef DolPInterface [

Container Name	DolPInterface
Parent Container	DoIPConfigSet
Description	This container defines a logical IP interface and collects properties to configure this interface.
Post-Build Variant Multiplicity	false
Configuration Parameters	



Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
DoIPAliveCheckResponseTimeout	1	[ECUC_DoIP_00009]	
DolPEid	01	[ECUC_DoIP_00014]	
DoIPGeneralInactivityTime	1	[ECUC_DoIP_00068]	
DolPInitialInactivityTime	1	[ECUC_DoIP_00010]	
DoIPInitialVehicleAnnouncementTime	1	[ECUC_DoIP_00008]	
DolPInterfaceActLineCtrl	1	[ECUC_DoIP_00101]	
DoIPInterfaceAnnouncementStart	1	[ECUC_DoIP_00099]	
DolPInterfaceId	1	[ECUC_DoIP_00098]	
DoIPMaxTesterConnections	1	[ECUC_DoIP_00012]	
DoIPUseMacAddressForIdentification	1	[ECUC_DoIP_00013]	
DoIPUseVehicleIdentificationSyncStatus	1	[ECUC_DoIP_00016]	
DoIPVehicleAnnouncementCount	01	[ECUC_DoIP_00094]	
DoIPVehicleAnnouncementInterval	01	[ECUC_DoIP_00007]	

Included Containers				
Container Name	Multiplicity	Scope / Dependency		
DoIPChannel	165536	Configuration of one DoIPChannel.		
DoIPConnections	1	Container contains all lower layer connection specific information, i.e. the single Pdu References and Handle IDs to the SoAd.		
DoIPFurtherActionByteCallback	01	This container describes the Callbackfunction to get the Further Action byte. This container shall always be present. If the Do IPFurtherActionByteDirect parameter is not present, the DoIP module will use an RPort of ServiceInterface CallbackGetFurther ActionByte with the name "CBGetFurtherAction Byte_ <shortname container="" doipinterface="" enclosing="" of="">".</shortname>		
DoIPProtocolVersion	1	This container defines the protocol version of the DoIP entity.		
DoIPRoutingActivation	0255	This container describes the routing activation possibilities by representing for each container a possible routing activation request message to the DoIP entity and the according references to the activated diagnostic messages.		
DoIPTester	1255	This container describes the properties of the possible connectable Tester for the DoIP entity.		

١

[ECUC_DoIP_00009] Definition of EcucFloatParamDef DoIPAliveCheckResponse Timeout \lceil

Parameter Name	DoIPAliveCheckResponseTimeout		
Parent Container	DolPInterface		
Description	Timeout in [s] for waiting for a response to an Alive Check request before the connection is considered to be disconnected. Represents parameter T_TCP_Alive Check of ISO 13400-2.		
Multiplicity	1		
Туре	EcucFloatParamDef		
Range	[0 INF]		
Default value	-		





Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		-

[ECUC_DoIP_00014] Definition of EcucIntegerParamDef DoIPEid \lceil

Parameter Name	DolPEid			
Parent Container	DoIPInterface			
Description	Configured EID (Entity ID of) for vehicle identification/vehicle announcement. Only necessary if DoIPUseMacAddressForIdentification is set to FALSE.			
Multiplicity	01			
Туре	EcucIntegerParamDef	EcucIntegerParamDef		
Range	0 281474976710655	0 281474976710655		
Default value	-			
Post-Build Variant Multiplicity	true			
Post-Build Variant Value	true	true		
Multiplicity Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE			
	Link time X VARIANT-LINK-TIME			
	Post-build time	X	VARIANT-POST-BUILD	
Value Configuration Class	Pre-compile time	Pre-compile time X VARIANT-PRE-COMPILE		
	Link time X VARIANT-LINK-TIME			
	Post-build time X VARIANT-POST-BUILD			
Scope / Dependency	scope: local dependency: DoIPEid shall be used if DoIPUseMacAddressForIdentification of the same DoIPInterface is false.			

[ECUC_DoIP_00068] Definition of EcucFloatParamDef DoIPGeneralInactivity Time \lceil

Parameter Name	DoIPGeneralInactivityTime			
Parent Container	DolPInterface			
Description	Timeout in [s] for maximum inactivity of a TCP socket connection before the DoIP module will close the according socket connection. Represents parameter T_TCP_General_Inactivity of ISO 13400-2.			
Multiplicity	1			
Туре	EcucFloatParamDef	EcucFloatParamDef		
Range]0 INF[
Default value	-			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time X All Variants			
	Link time	_		





	Post-build time	ı	
Scope / Dependency	scope: local		

-

[ECUC_DoIP_00010] Definition of EcucFloatParamDef DoIPInitialInactivityTime \lceil

Parameter Name	DoIPInitialInactivityTime			
Parent Container	DoIPInterface	DoIPInterface		
Description	Timeout in [s] used for initial inactivity of a connected TCP socket connection directly after socket connection. Represents parameter T_TCP_Initial_Inactivity of ISO 13400-2.			
Multiplicity	1	1		
Туре	EcucFloatParamDef			
Range]0 INF[]0 INF[
Default value	-			
Post-Build Variant Value	false	false		
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time –			
Scope / Dependency	scope: local			

[ECUC_DoIP_00008] Definition of EcucFloatParamDef DoIPInitialVehicleAnnouncementTime \lceil

Parameter Name	DoIPInitialVehicleAnnouncementTime			
Parent Container	DolPInterface	DoIPInterface		
Description	Time to wait in [s] for sending first vehicle anouncement message after IP address assignment. Represents parameter A_DoIP_Announce_Wait of ISO 13400-2.			
Multiplicity	1	1		
Туре	EcucFloatParamDef			
Range	[0 INF]			
Default value	-			
Post-Build Variant Value	false	false		
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	-		
	Post-build time	_		
Scope / Dependency	scope: local		·	



[ECUC_DoIP_00101] Definition of EcucBooleanParamDef DoIPInterfaceActLine Ctrl \lceil

Parameter Name	DoIPInterfaceActLineCtrl			
Parent Container	DoIPInterface			
Description	This attribute defines whether the	This attribute defines whether the network interface		
	• is started "on-demand" when an	activatio	n line is sensed (TRUE) or	
	• is always available (FALSE).			
Multiplicity	1			
Туре	EcucBooleanParamDef			
Default value	-			
Post-Build Variant Multiplicity	false			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time X All Variants			
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

[ECUC_DoIP_00099] Definition of EcucEnumerationParamDef DoIPInterfaceAnnouncementStart \lceil

Parameter Name	DoIPInterfaceAnnouncementStart		
Parent Container	DoIPInterface		
Description	This attribute defines, when vehicle announcement is started on a DolPInterface		
	Automatic: As soon as the underlying UDP vehicle announcement connection switches to SOAD_SOCON_ONLINE		
	OnTrigger: As soon as the API DoIP_TriggerVehicleAnnouncement is called for the given DoIPInterface instance		
Multiplicity	1		
Туре	EcucEnumerationParamDef		
Range	DOIP_AUTOMATIC_ANNOUNCE AUTOMATIC announcement		
	DOIP_ONTRIGGER_ ANNOUNCE	TRIGG	ERED announcement
Default value	DOIP_AUTOMATIC_ANNOUNCE		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		<u> </u>



[ECUC_DoIP_00098] Definition of EcucIntegerParamDef DoIPInterfaceId [

Parameter Name	DolPInterfaceId			
Parent Container	DoIPInterface			
Description	This parameter is an identifier of the DolPInterface. The value of this parameter will be assigned to the symbolic name derived from the container short name.			
Multiplicity	1	1		
Туре	EcucIntegerParamDef (Symbolic Name generated for this parameter)			
Range	0 255	0 255		
Default value	-			
Post-Build Variant Multiplicity	false			
Post-Build Variant Value	false	false		
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

١

[ECUC_DoIP_00012] Definition of EcucIntegerParamDef DoIPMaxTesterConnections $\ \lceil$

Parameter Name	DoIPMaxTesterConnections		
Parent Container	DoIPInterface		
Description	Maximum amount of tester connections that shall be maintained at one time before alive check is performed.		
Multiplicity	1		
Туре	EcucIntegerParamDef		
Range	1 255		
Default value	-		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local	·	

1

[ECUC_DoIP_00013] Definition of EcucBooleanParamDef DoIPUseMacAddress ForIdentification \lceil

Parameter Name	DoIPUseMacAddressForIdentification
Parent Container	DolPInterface
Description	Provided the information if a configured EID at vehicle identification response/vehicle announcement is used or the MAC address. TRUE: Use MAC Address instead of EID for Vehicle identification/announcement. FALSE: Use configured EID for vehicle identification/announcement.
Multiplicity	1





Туре	EcucBooleanParamDef		
Default value	-		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time X All Variants		
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local	-	
	dependency: DoIPEid		

١

[ECUC_DoIP_00016] Definition of EcucBooleanParamDef DoIPUseVehicleIdentificationSyncStatus \lceil

Parameter Name	DoIPUseVehicleIdentificationSyncStatus			
Parent Container	DolPInterface	DoIPInterface		
Description	Defines if the optional VIN/GID synchronization status is used additionally in the vehicle identification/announcement.			
Multiplicity	1	1		
Туре	EcucBooleanParamDef			
Default value	-			
Post-Build Variant Value	false	false		
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	-		
	Post-build time	_		
Scope / Dependency	scope: local			

1

[ECUC_DoIP_00094] Definition of EcucIntegerParamDef DoIPVehicleAnnouncementCount \lceil

Parameter Name	DoIPVehicleAnnouncementCount			
Parent Container	DoIPInterface			
Description	Number of vehicle announcement messages on IP address assignment. Represents parameter A_DoIP_Announce_Num of ISO 13400-2.			
Multiplicity	01	01		
Туре	EcucIntegerParamDef			
Range	1 255			
Default value	-			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			



[ECUC_DoIP_00007] Definition of EcucFloatParamDef DoIPVehicleAnnouncementInterval \lceil

Parameter Name	DoIPVehicleAnnouncementInterval		
Parent Container	DoIPInterface		
Description	Time to wait in [s] for sending subsequent vehicle anouncement messages. Represents parameter A_DoIP_Announce_Interval of ISO 13400-2.		
Multiplicity	01		
Туре	EcucFloatParamDef		
Range	[0 INF]		
Default value	-		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		

-






Figure 10.4: DoIPInterface



10.2.9 DolPChannel

[ECUC_DoIP_00069] Definition of EcucParamConfContainerDef DoIPChannel

Container Name	DolPChannel
Parent Container	DolPInterface
Description	Configuration of one DoIPChannel.
Post-Build Variant Multiplicity	false
Configuration Parameters	

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
DoIPChannelSARef	1	[ECUC_DoIP_00070]
DoIPChannelTARef	1	[ECUC_DoIP_00071]

Included Containers		
Container Name	Multiplicity	Scope / Dependency
DoIPPduRRxPdu	01	This container contains the Rx Pdus to connect with the Rx Pdus of the PduR.
DoIPPduRTxPdu	01	This container contains the Tx Pdus to connect with the Tx Pdus of the PduR. If the parameter is not configured the channel is for functional addressing.

1

[ECUC_DoIP_00070] Definition of EcucReferenceDef DoIPChannelSARef

Parameter Name	DoIPChannelSARef
Parent Container	DolPChannel
Description	Reference to the DolPTester.
Multiplicity	1
Туре	Reference to DolPTester
Post-Build Variant Value	false
Scope / Dependency	

[ECUC_DoIP_00071] Definition of EcucReferenceDef DoIPChannelTARef

Parameter Name	DoIPChannelTARef
Parent Container	DolPChannel
Description	Reference to the target address.
Multiplicity	1
Туре	Reference to DoIPTargetAddress
Post-Build Variant Value	false
Scope / Dependency	






Figure 10.5: DoIPChannel

10.2.10 DolPPduRRxPdu

[ECUC_DoIP_00055] Definition of EcucParamConfContainerDef DoIPPduRRx Pdu \lceil

Container Name	DoIPPduRRxPdu
Parent Container	DolPChannel
Description	This container contains the Rx Pdus to connect with the Rx Pdus of the PduR.
Configuration Parameters	



Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
DolPPduRRxPduld	1	[ECUC_DoIP_00057]	
DolPPduRRxPduRef	1	[ECUC_DoIP_00058]	

No Included Containers		
NO Included Containers		

1

[ECUC_DoIP_00057] Definition of EcucIntegerParamDef DoIPPduRRxPduId [

Parameter Name	DoIPPduRRxPduld			
Parent Container	DoIPPduRRxPdu	DoIPPduRRxPdu		
Description	The DoIPPduRRxPduId is required	by the A	PI call DoIP_TpCancelReceive.	
Multiplicity	1			
Туре	EcucIntegerParamDef (Symbolic Na	ame gen	erated for this parameter)	
Range	0 65535			
Default value	-			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time X All Variants			
	Link time	_		
	Post-build time	-		
Scope / Dependency	scope: ECU			
	withAuto = true			

[ECUC_DoIP_00058] Definition of EcucReferenceDef DoIPPduRRxPduRef

Parameter Name	DoIPPduRRxPduRef			
Parent Container	DoIPPduRRxPdu	DoIPPduRRxPdu		
Description	Reference to the "global" Pdu structure to allow harmonization of handle IDs in the COM-Stack.			
Multiplicity	1			
Туре	Reference to Pdu			
Post-Build Variant Value	true			
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE	
	Link time X VARIANT-LINK-TIME			
	Post-build time X VARIANT-POST-BUILD			
Scope / Dependency	scope: local			



10.2.11 DolPPduRTxPdu

$[{\tt ECUC_DoIP_00056}] \ Definition \ of \ {\tt EcucParamConfContainerDef \ DoIPPduRTxPdu}$

Container Name	DoIPPduRTxPdu
Parent Container	DolPChannel
Description	This container contains the Tx Pdus to connect with the Tx Pdus of the PduR. If the parameter is not configured the channel is for functional addressing.
Configuration Parameters	

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
DolPPduRTxPduld	1	[ECUC_DoIP_00060]	
DoIPPduType	01	[ECUC_DoIP_00075]	
DoIPPduRTxPduRef	1	[ECUC_DoIP_00059]	

No Included Containers	
------------------------	--

1

[ECUC_DoIP_00060] Definition of EcucIntegerParamDef DoIPPduRTxPduId [

Parameter Name	DoIPPduRTxPduld			
Parent Container	DoIPPduRTxPdu			
Description	The DoIPPduRTxPduId is required by DoIP_TpTransmit or DoIP_IfTransmit and DoIP_TpCancelTransmit.			
Multiplicity	1	1		
Туре	EcucIntegerParamDef (Symbolic Name generated for this parameter)			
Range	0 65535			
Default value	-			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time X All Variants			
	Link time –			
	Post-build time –			
Scope / Dependency	scope: ECU			
	withAuto = true			

١

[ECUC_DoIP_00075] Definition of EcucEnumerationParamDef DoIPPduType \lceil

Parameter Name	DoIPPduType
Parent Container	DoIPPduRTxPdu
Description	API Type to use for communication with PduR. DOIP_IFPDU for UUDT messages, DOIP_TPPDU for all other diagnostic messages.





Multiplicity	01			
Туре	EcucEnumerationParamDef			
Range	DOIP_IFPDU	DOIP_IFPDU DOIP_IFPDU for UUDT messages,		
	DOIP_TPPDU	DOIP_	TPPDU for all other diagnostic messages.	
Default value	DOIP_TPPDU	•		
Post-Build Variant Multiplicity	true			
Post-Build Variant Value	true			
Multiplicity Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE			
	Link time	Х	VARIANT-LINK-TIME	
	Post-build time	X	VARIANT-POST-BUILD	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE	
	Link time	X	VARIANT-LINK-TIME	
	Post-build time	X	VARIANT-POST-BUILD	
Scope / Dependency	scope: local			

١

[ECUC_DoIP_00059] Definition of EcucReferenceDef DoIPPduRTxPduRef

Parameter Name	DoIPPduRTxPduRef			
Parent Container	DoIPPduRTxPdu	DoIPPduRTxPdu		
Description	Reference to the "global" Pdu structure to allow harmonization of handle IDs in the COM-Stack.			
Multiplicity	1			
Туре	Reference to Pdu			
Post-Build Variant Value	true			
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE	
	Link time	X	VARIANT-LINK-TIME	
	Post-build time	X	VARIANT-POST-BUILD	
Scope / Dependency	scope: local			

1

10.2.12 DolPConnections

[ECUC_DoIP_00032] Definition of EcucParamConfContainerDef DoIPConnections \lceil

Container Name	DoIPConnections
Parent Container	DolPInterface
Description	Container contains all lower layer connection specific information, i.e. the single Pdu References and Handle IDs to the SoAd.
Post-Build Variant Multiplicity	false
Configuration Parameters	



No Included Parameters

Included Containers		
Container Name	Multiplicity	Scope / Dependency
DoIPTargetAddress	165535	This container describes a possible TargetAddress that is supported by DoIP.
DoIPTcpConnection	2255	This container describes a TCP connection to the lower layer So Ad module.
DoIPUdpConnection	1255	This Container describes a Udp connection to the lower layer So Ad module.
DoIPUdpVehicleAnnouncement Connection	0255	This container describes the UDP multicast connections to the lower layer SoAd module.






Figure 10.6: DoIPConnections



10.2.13 DoIPTargetAddress

[ECUC_DoIP_00053] Definition of EcucParamConfContainerDef DoIPTargetAddress \lceil

Container Name	DoIPTargetAddress
Parent Container	DoIPConnections
Description	This container describes a possible TargetAddress that is supported by DoIP.
Configuration Parameters	

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
DoIPTargetAddressValue	1	[ECUC_DoIP_00054]

No Include	Containers
------------	------------

[ECUC_DoIP_00054] Definition of EcucIntegerParamDef DoIPTargetAddress Value \lceil

Parameter Name	DoIPTargetAddressValue			
Parent Container	DoIPTargetAddress	DoIPTargetAddress		
Description	Valid Target Address of a DoIP tar	get addre	ess.	
Multiplicity	1	1		
Туре	EcucIntegerParamDef			
Range	0 65535			
Default value	-			
Post-Build Variant Value	true			
Value Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE	
	Link time	Х	VARIANT-LINK-TIME	
	Post-build time	X	VARIANT-POST-BUILD	
Scope / Dependency	scope: local			

١

10.2.14 DoIPTcpConnection

[ECUC_DoIP_00045] Definition of EcucParamConfContainerDef DoIPTcpConnection \lceil



Container Name	DoIPTcpConnection
Parent Container	DoIPConnections
Description	This container describes a TCP connection to the lower layer SoAd module.
Configuration Parameters	

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
DoIPRequestAddressAssignment	1	[ECUC_DoIP_00095]
DoIPTcpConnectionSecurityRequired	01	[ECUC_DoIP_00097]

Included Containers		
Container Name	Multiplicity	Scope / Dependency
DoIPSoAdTcpRxPdu	1	This container describes a Rx PDU received via SoAd over TCP
DoIPSoAdTcpTxPdu	1	This container describes a Tx PDU sent via SoAd over TCP

1

[ECUC_DoIP_00095] Definition of EcucBooleanParamDef DoIPRequestAddress Assignment \lceil

Parameter Name	DoIPRequestAddressAssignment		
Parent Container	DoIPTcpConnection, DoIPUdpConnection, DoIPUdpVehicleAnnouncementConnection		
Description	The DoIP module shall request IP address assignment by calling SoAd_RequestlpAddr Assignment() for the TcplpLocalAddr related to this DoIpConnection.		
Multiplicity	1		
Туре	EcucBooleanParamDef		
Default value	true		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local	·	

[ECUC_DoIP_00097] Definition of EcucBooleanParamDef DoIPTcpConnection SecurityRequired \lceil

Parameter Name	DoIPTcpConnectionSecurityRequired	
Parent Container	DoIPTcpConnection	
Description	Indicates if the associated TCP socket uses a secure connection (e.g. TLS)	
Multiplicity	01	
Туре	EcucBooleanParamDef	
Default value	false	





Scope / Dependency	scope: local
	dependency: DoIPTcpConnectionSecurityRequired shall only be enabled if DoIP_ISO13400_2_2019 is enabled.




Figure 10.7: DoIPTcpConnection

10.2.15 DolPSoAdTcpRxPdu

[ECUC_DoIP_00080] Definition of EcucParamConfContainerDef DoIPSoAdTcpRx Pdu \lceil

Container Name	DoIPSoAdTcpRxPdu
Parent Container	DoIPTcpConnection
Description	This container describes a Rx PDU received via SoAd over TCP
Configuration Parameters	

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
DoIPSoAdTcpRxPduId	1	[ECUC_DoIP_00082]
DoIPSoAdTcpRxPduRef	1	[ECUC_DoIP_00083]

No Included Containers



1

[ECUC_DoIP_00082] Definition of EcucIntegerParamDef DoIPSoAdTcpRxPduId

Parameter Name	DoIPSoAdTcpRxPduId	DoIPSoAdTcpRxPduId		
Parent Container	DoIPSoAdTcpRxPdu	DoIPSoAdTcpRxPdu		
Description		The DoIPSoAdTcpRxPduId is required by the API call DoIP_SoAdTpRxIndication to receive I-PDUs from the SoAd.		
Multiplicity	1	1		
Туре	EcucIntegerParamDef (Sym	EcucIntegerParamDef (Symbolic Name generated for this parameter)		
Range	0 65535	0 65535		
Default value	-			
Post-Build Variant Value	false	false		
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: ECU			
	withAuto = true			

1

[ECUC_DoIP_00083] Definition of EcucReferenceDef DoIPSoAdTcpRxPduRef

Parameter Name	DoIPSoAdTcpRxPduRef			
Parent Container	DoIPSoAdTcpRxPdu	DoIPSoAdTcpRxPdu		
Description	Reference to the "global" Pdu structure to allow harmonization of handle IDs in the COM-Stack.			
Multiplicity	1			
Туре	Reference to Pdu			
Post-Build Variant Value	true			
Value Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE			
	Link time	X	VARIANT-LINK-TIME	
	Post-build time X VARIANT-POST-BUILD			
Scope / Dependency	scope: local			

1

10.2.16 DolPSoAdTcpTxPdu

[ECUC_DoIP_00081] Definition of EcucParamConfContainerDef DoIPSoAdTcpTx Pdu \lceil



Container Name	DoIPSoAdTcpTxPdu
Parent Container	DoIPTcpConnection
Description	This container describes a Tx PDU sent via SoAd over TCP
Configuration Parameters	

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
DoIPSoAdTcpTxPduId	1	[ECUC_DoIP_00085]
DoIPSoAdTcpTxPduRef	1	[ECUC_DoIP_00084]

No Included Containers	
------------------------	--

[ECUC_DoIP_00085] Definition of EcucIntegerParamDef DoIPSoAdTcpTxPduId [

Parameter Name	DoIPSoAdTcpTxPduId		
Parent Container	DoIPSoAdTcpTxPdu		
Description	The DoIPSoAdTcpTxPduId is required by the API call DoIP_SoAdTpTxConfirmation that is called by the SoAd to confirm that the IPdu has been transmitted successfully.		
Multiplicity	1		
Туре	EcucIntegerParamDef (Symbolic Name generated for this parameter)		
Range	0 65535		
Default value	-		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time X All Variants		
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: ECU		
	withAuto = true		

1

[ECUC_DoIP_00084] Definition of EcucReferenceDef DoIPSoAdTcpTxPduRef \lceil

Parameter Name	DoIPSoAdTcpTxPduRef	DoIPSoAdTcpTxPduRef		
Parent Container	DoIPSoAdTcpTxPdu	DoIPSoAdTcpTxPdu		
Description	Reference to the "global" Po COM-Stack.	Reference to the "global" Pdu structure to allow harmonization of handle IDs in the COM-Stack.		
Multiplicity	1	1		
Туре	Reference to Pdu	Reference to Pdu		
Post-Build Variant Value	true	true		
Value Configuration Class	Pre-compile time	Pre-compile time X VARIANT-PRE-COMPILE		
	Link time	X	VARIANT-LINK-TIME	
	Post-build time	X	VARIANT-POST-BUILD	
Scope / Dependency	scope: local	-		



10.2.17 DolPUdpConnection

[ECUC_DoIP_00052] Definition of EcucParamConfContainerDef DoIPUdpConnection \lceil

Container Name	DoIPUdpConnection
Parent Container	DoIPConnections
Description	This Container describes a Udp connection to the lower layer SoAd module.
Configuration Parameters	

Included Parameters			
Parameter Name Multiplicity ECUC ID			
DoIPRequestAddressAssignment	1	[ECUC_DoIP_00095]	

Included Containers			
Container Name	Multiplicity	Scope / Dependency	
DoIPSoAdUdpRxPdu	1	This container describes a Rx PDU received via SoAd over UDP.	
DoIPSoAdUdpTxPdu	1	This container describes a Tx PDU sent via SoAd over UDP.	




Figure 10.8: DoIPUdpConnection



10.2.18 DoIPSoAdUdpRxPdu

[ECUC_DoIP_00046] Definition of EcucParamConfContainerDef DoIPSoAdUdp RxPdu \lceil

Container Name	DoIPSoAdUdpRxPdu
Parent Container	DoIPUdpConnection
Description	This container describes a Rx PDU received via SoAd over UDP.
Configuration Parameters	

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
DoIPSoAdUdpRxPduId	1	[ECUC_DoIP_00048]	
DoIPSoAdUdpRxPduRef	1	[ECUC_DoIP_00049]	

No Included Containers

1

[ECUC_DoIP_00048] Definition of EcucIntegerParamDef DoIPSoAdUdpRxPduId

Parameter Name	DoIPSoAdUdpRxPduId			
Parent Container	DoIPSoAdUdpRxPdu	DoIPSoAdUdpRxPdu		
Description	The DoIPSoAdUdpRxPduId is requreceive I-PDUs from the SoAd.	The DoIPSoAdUdpRxPduId is required by the API call DoIP_SoAdIfRxIndication to receive I-PDUs from the SoAd.		
Multiplicity	1	1		
Туре	EcucIntegerParamDef (Symbolic Name generated for this parameter)			
Range	0 65535			
Default value	-			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time X All Variants			
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: ECU			
	withAuto = true			

١

[ECUC_DoIP_00049] Definition of EcucReferenceDef DoIPSoAdUdpRxPduRef \lceil

Parameter Name	DoIPSoAdUdpRxPduRef
Parent Container	DoIPSoAdUdpRxPdu
Description	Reference to the "global" Pdu structure to allow harmonization of handle IDs in the COM-Stack.
Multiplicity	1





Туре	Reference to Pdu		
Post-Build Variant Value	true		
Value Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE		
	Link time	Х	VARIANT-LINK-TIME
	Post-build time	Х	VARIANT-POST-BUILD
Scope / Dependency	scope: local		

I

10.2.19 DoIPSoAdUdpTxPdu

[ECUC_DoIP_00047] Definition of EcucParamConfContainerDef DoIPSoAdUdp TxPdu \lceil

Container Name	DoIPSoAdUdpTxPdu
Parent Container	DoIPUdpConnection
Description	This container describes a Tx PDU sent via SoAd over UDP.
Configuration Parameters	

Included Parameters			
Parameter Name Multiplicity ECUC ID			
DoIPSoAdUdpTxPduld	1	[ECUC_DoIP_00051]	
DoIPSoAdUdpTxPduRef	1	[ECUC_DoIP_00050]	

No Included Containers	
------------------------	--

1

[ECUC_DoIP_00051] Definition of EcucIntegerParamDef DoIPSoAdUdpTxPduId

Parameter Name	DoIPSoAdUdpTxPduId			
Parent Container	DoIPSoAdUdpTxPdu			
Description	The DoIPSoAdUdpTxPduId is required by the API call DoIP_SoAdIfTxConfirmation that is called by the SoAd to confirm that the IPdu has been transmitted successfully.			
Multiplicity	1			
Туре	EcucIntegerParamDef (Symbolic Name generated for this parameter)			
Range	0 65535			
Default value	-			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time X All Variants			
	Link time	_		
	Post-build time –			





Scope / Dependency	scope: ECU
	withAuto = true

[ECUC_DoIP_00050] Definition of EcucReferenceDef DoIPSoAdUdpTxPduRef

Parameter Name	DoIPSoAdUdpTxPduRef				
Parent Container	DoIPSoAdUdpTxPdu	DoIPSoAdUdpTxPdu			
Description	Reference to the "global" Pdu structure to allow harmonization of handle IDs in the COM-Stack.				
Multiplicity	1	1			
Туре	Reference to Pdu				
Post-Build Variant Value	true	true			
Value Configuration Class	Pre-compile time	Pre-compile time X VARIANT-PRE-COMPILE			
	Link time X VARIANT-LINK-TIME				
	Post-build time X VARIANT-POST-BUILD				
Scope / Dependency	scope: local				

Ī

10.2.20 DolPUdpVehicleAnnouncementConnection

[ECUC_DoIP_00076] Definition of EcucParamConfContainerDef DoIPUdpVehicle AnnouncementConnection $\ \lceil$

Container Name	DoIPUdpVehicleAnnouncementConnection
Parent Container	DoIPConnections
Description	This container describes the UDP multicast connections to the lower layer SoAd module.
Configuration Parameters	

Included Parameters				
Parameter Name Multiplicity ECUC ID				
DoIPRequestAddressAssignment	1	[ECUC_DoIP_00095]		

Included Containers		
Container Name	Multiplicity	Scope / Dependency
DoIPSoAdUdpVehicle AnnouncementTxPdu	1	This container describes the vehicle announcement TxPdu sent via the SoAd.

For parameter table [ECUC_DoIP_00095] DoIPRequestAddressAssignment, see definition below container DoIPTcpConnection.



10.2.21 DoIPSoAdUdpVehicleAnnouncementTxPdu

[ECUC_DoIP_00077] Definition of EcucParamConfContainerDef DoIPSoAdUdp VehicleAnnouncementTxPdu \lceil

Container Name	DoIPSoAdUdpVehicleAnnouncementTxPdu
Parent Container	DoIPUdpVehicleAnnouncementConnection
Description	This container describes the vehicle announcement TxPdu sent via the SoAd.
Configuration Parameters	

Included Parameters			
Parameter Name Multiplicity ECUC ID			
DoIPSoAdUdpVehicleAnnouncementTxPduId	1	[ECUC_DoIP_00078]	
DoIPSoAdUdpVehicleAnnouncementTxPduRef	1	[ECUC_DoIP_00079]	

[ECUC_DoIP_00078] Definition of EcucIntegerParamDef DoIPSoAdUdpVehicle AnnouncementTxPduId $\crup{\crup{1pt}{$\lceil$}}$

Parameter Name	DoIPSoAdUdpVehicleAnnouncementTxPduId			
Parent Container	DoIPSoAdUdpVehicleAnnouncementTxPdu			
Description	The DoIPSoAdUdpVehicleAnnouncementTxPduld is required by the API call DoIP_So AdIfTxConfirmation() that is called by the SoAd to confirm that the IPdu has been transmitted successfully.			
Multiplicity	1			
Туре	EcucIntegerParamDef (Symbolic Name generated for this parameter)			
Range	0 4294967295			
Default value	-			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time X All Variants			
	Link time	_		
	Post-build time –			
Scope / Dependency	scope: ECU			
	withAuto = true			



[ECUC_DoIP_00079] Definition of EcucReferenceDef DoIPSoAdUdpVehicleAnnouncementTxPduRef \lceil

Parameter Name	DoIPSoAdUdpVehicleAnnouncementTxPduRef			
Parent Container	DoIPSoAdUdpVehicleAnnouncementTxPdu			
Description	Reference to the "global" PDU structure to allow harmonization of handle IDs in the COM-Stack.			
Multiplicity	1			
Туре	Reference to Pdu			
Post-Build Variant Value	true	true		
Value Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE			
	Link time X VARIANT-LINK-TIME			
	Post-build time X VARIANT-POST-BUILD			
Scope / Dependency	scope: local			

10.2.22 DolPFurtherActionByteCallback

[ECUC_DoIP_00092] Definition of EcucParamConfContainerDef DoIPFurtherActionByteCallback \lceil

Container Name	DoIPFurtherActionByteCallback
Parent Container	DoIPInterface
Description	This container describes the Callbackfunction to get the Further Action byte. This container shall always be present. If the DoIPFurtherActionByteDirect parameter is not present, the DoIP module will use an RPort of ServiceInterface CallbackGetFurther ActionByte with the name "CBGetFurtherActionByte_ <shortname container="" do="" enclosing="" ipinterface="" of="">".</shortname>
Configuration Parameters	

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
DoIPFurtherActionByteDirect	01	[ECUC_DoIP_00093]	

No Included Containers	
------------------------	--



[ECUC_DoIP_00093] Definition of EcucFunctionNameDef DoIPFurtherAction ByteDirect \lceil

Parameter Name	DoIPFurtherActionByteDirect			
Parent Container	DoIPFurtherActionByteCallba	DoIPFurtherActionByteCallback		
Description	Direct C Callback function to get the OEM specific Further Action Byte for the DoIP vehicle identification response/vehicle announcement. If the DoIPFurtherActionByte Direct parameter is present, the DoIP module will not use an RPort of ServiceInterface "CBGetFurtherActionByte" but will call the configured function.			
Multiplicity	01	01		
Туре	EcucFunctionNameDef			
Default value	_			
Regular Expression	-	-		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE	
	Link time X VARIANT-LINK-TIME, VARIANT-POST-BUILD			
	Post-build time –			
Scope / Dependency	scope: local			

10.2.23 DolPProtocolVersion

[ECUC_DoIP_00102] Definition of EcucParamConfContainerDef DoIPProtocol Version \lceil

Container Name	DoIPProtocolVersion
Parent Container	DolPInterface
Description	This container defines the protocol version of the DoIP entity.
Configuration Parameters	

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
DoIP_ISO13400_2_2012	1	[ECUC_DoIP_00103]	
DoIP_ISO13400_2_2019	1	[ECUC_DoIP_00105]	
DoIPAnnouncedProtocolVersion	1	[ECUC_DoIP_00104]	

No Included Containers	

1



[ECUC_DoIP_00103] ISO13400_2_2012 [

Definition of EcucBooleanParamDef DoIP_

Parameter Name	DoIP_ISO13400_2_2012		
Parent Container	DoIPProtocolVersion		
Description	If this parameter is enabled, the DoIP entity supports communication with ISO13400-2:2012 compliant tester using protocol version 0x02.		
Multiplicity	1		
Туре	EcucBooleanParamDef		
Default value	true		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time X All Variants		
	Link time –		
	Post-build time –		
Scope / Dependency	scope: local		

[ECUC_DoIP_00105] ISO13400_2_2019 [

Definition of EcucBooleanParamDef DoIP_

Parameter Name	DoIP_ISO13400_2_2019		
Parent Container	DoIPProtocolVersion		
Description	If this parameter is enabled, the DoIP entity supports communication with ISO13400-2:2019 compliant tester using protocol version 0x03.		
Multiplicity	1		
Туре	EcucBooleanParamDef		
Default value	true		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time X All Variants		
	Link time –		
	Post-build time –		
Scope / Dependency	scope: local		

[ECUC_DoIP_00104] Definition of EcucEnumerationParamDef DoIPAnnounced ProtocolVersion \lceil

Parameter Name	DoIPAnnouncedProtocolVersion		
Parent Container	DoIPProtocolVersion		
Description	This parameter defines the used protocol version for vehicle announcements and vehicle identification responses if the vehicle identification request contains protocol version 0xFF.		
Multiplicity	1		
Туре	EcucEnumerationParamDef		
Range	DOIP_ISO13400_2_2012	ISO13400-2:2012	
	DOIP_ISO13400_2_2019	ISO13400-2:2019	





Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time X All Variants		
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		-

1




Figure 10.9: DoIPProtocolVersion

10.2.24 DolPRoutingActivation

[ECUC_DoIP_00030] Definition of EcucParamConfContainerDef DoIPRoutingActivation \lceil

Container Name	DoIPRoutingActivation
Parent Container	DolPInterface
Description	This container describes the routing activation possibilities by representing for each container a possible routing activation request message to the DoIP entity and the according references to the activated diagnostic messages.
Post-Build Variant Multiplicity	false
Configuration Parameters	

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
DoIPRoutingActivationNumber	1	[ECUC_DoIP_00033]	
DoIPRoutingActivationSecurityRequired	01	[ECUC_DoIP_00096]	
DoIPTargetAddressRef	165535	[ECUC_DoIP_00034]	



Included Containers			
Container Name	Multiplicity	Scope / Dependency	
DoIPRoutingActivation AuthenticationCallback	01	Container describes the Callbackfunction to call on a Routing Activation Request for Authentication. If this container is configured but the DoIPRoutingActivationAuthenticationFunc parameter is not present, the DoIP module will use an RPort of ServiceInterface <routingactivation>_RoutingActivation with the name "CB<routingactivation>RoutingActivation". <routing activation=""> is the ShortName of the DoIPRoutingActiviation container.</routing></routingactivation></routingactivation>	
DoIPRoutingActivation ConfirmationCallback	01	Container describes the Callbackfunction to call on a Routing Activation Request for Confirmation. If this container is configured but the DoIPRoutingActivationConfirmationFunc parameter is not present the DoIP module will use an RPort of ServiceInterface <routingactivation>_RoutingActivation with the name "CB<routingactivation>RoutingActivation". <routing activation=""> is the ShortName of the DoIPRoutingActiviation container.</routing></routingactivation></routingactivation>	

[ECUC_DoIP_00033] Definition of EcucIntegerParamDef DoIPRoutingActivation Number \lceil

Parameter Name	DoIPRoutingActivationNumber			
Parent Container	DoIPRoutingActivation	DoIPRoutingActivation		
Description	Identifies the Routing activation Number which is received for a DoIP routing activation request message.			
Multiplicity	1			
Туре	EcucIntegerParamDef			
Range	0 255			
Default value	-			
Post-Build Variant Value	true			
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE	
	Link time	Х	VARIANT-LINK-TIME	
	Post-build time X VARIANT-POST-BUILD			
Scope / Dependency	scope: local			

[ECUC_DoIP_00096] Definition of EcucBooleanParamDef DoIPRoutingActivation SecurityRequired \lceil

Parameter Name	DoIPRoutingActivationSecurityRequired
Parent Container	DoIPRoutingActivation
Description	Indicates if a routing activation requires a secure TCP connection
Multiplicity	01
Туре	EcucBooleanParamDef
Default value	false
Scope / Dependency	scope: local

-



[ECUC_DoIP_00034] Definition of EcucReferenceDef DoIPTargetAddressRef

Parameter Name	DoIPTargetAddressRef		
Parent Container	DoIPRoutingActivation	DoIPRoutingActivation	
Description	Reference to all DoIPTargetAddre	ss which	are activated on this Routing activation.
Multiplicity	165535		
Туре	Reference to DoIPTargetAddress		
Post-Build Variant Multiplicity	true		
Post-Build Variant Value	true		
Multiplicity Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE		VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time X VARIANT-POST-BUILD		
Value Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE		
	Link time X VARIANT-LINK-TIME		
	Post-build time X VARIANT-POST-BUILD		VARIANT-POST-BUILD
Scope / Dependency	scope: local		






Figure 10.10: DoIPRoutingActivation

10.2.25 DolPRoutingActivationAuthenticationCallback

[ECUC_DoIP_00035] Definition of EcucParamConfContainerDef DoIPRoutingActivationAuthenticationCallback \lceil

Container Name	DoIPRoutingActivationAuthenticationCallback
Parent Container	DoIPRoutingActivation
Description	Container describes the Callbackfunction to call on a Routing Activation Request for Authentication. If this container is configured but the DoIPRoutingActivation AuthenticationFunc parameter is not present, the DoIP module will use an RPort of ServiceInterface <routingactivation>_RoutingActivation with the name "CB<routing activation="">RoutingActivation> is the ShortName of the Do IPRoutingActivation container.</routing></routingactivation>
Configuration Parameters	



Included Parameters		
Parameter Name	Multiplicity	ECUC ID
DoIPRoutingActivationAuthenticationFunc	01	[ECUC_DoIP_00039]
DoIPRoutingActivationAuthenticationReqLength	1	[ECUC_DoIP_00040]
DoIPRoutingActivationAuthenticationResLength	1	[ECUC_DoIP_00041]

|--|

١

[ECUC_DoIP_00039] Definition of EcucFunctionNameDef DoIPRoutingActivation AuthenticationFunc \lceil

Parameter Name	DoIPRoutingActivationAuthenticationFunc		
Parent Container	DoIPRoutingActivationAuthenticationCallback		
Description	Direct C Callback function to trigger the authentication function for routing activation. If the DoIPRoutingActivationAuthenticationFunc parameter is present, the DoIP module will not use an RPort of ServiceInterface <routingactivation>_RoutingActivation but call the configured function.</routingactivation>		
Multiplicity	01		
Туре	EcucFunctionNameDef		
Default value	-		
Regular Expression	_		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE		
	Link time X VARIANT-LINK-TIME, VARIANT-POST-BUILD		
	Post-build time –		
Value Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE		
	Link time	X	VARIANT-LINK-TIME, VARIANT-POST-BUILD
	Post-build time	_	
Scope / Dependency	scope: local		

١

[ECUC_DoIP_00040] Definition of EcucIntegerParamDef DoIPRoutingActivation AuthenticationReqLength $\ \lceil$

Parameter Name	DoIPRoutingActivationAuthenticationReqLength	
Parent Container	DoIPRoutingActivationAuthenticationCallback	
Description	Describes the amount of bytes used to handle to the authentication function on routing activation. If 0 is configured as length the parameter AuthenticationReqData will not be handled to the API.	
Multiplicity	1	
Туре	EcucIntegerParamDef	
Range	04	





Default value	-		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE
	Link time	Х	VARIANT-LINK-TIME, VARIANT-POST-BUILD
	Post-build time	-	
Scope / Dependency	scope: local		

[ECUC_DoIP_00041] Definition of EcucIntegerParamDef DoIPRoutingActivation AuthenticationResLength $\ \lceil$

Parameter Name	DoIPRoutingActivationAuthentication	DoIPRoutingActivationAuthenticationResLength	
Parent Container	DoIPRoutingActivationAuthentication	DoIPRoutingActivationAuthenticationCallback	
Description	Describes the amount of bytes used to read by the authentication function on routing activation. If 0 is configured as length the parameter AuthenticationResData will not be fetched via the API.		
Multiplicity	1		
Туре	EcucIntegerParamDef		
Range	04		
Default value	-		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE		
	Link time X VARIANT-LINK-TIME, VARIANT-POST-BUILD		
	Post-build time –		
Scope / Dependency	scope: local		

1

10.2.26 DolPRoutingActivationConfirmationCallback

[ECUC_DoIP_00061] Definition of EcucParamConfContainerDef DoIPRoutingActivationConfirmationCallback $\ \lceil$

Container Name	DoIPRoutingActivationConfirmationCallback
Parent Container	DoIPRoutingActivation
Description	Container describes the Callbackfunction to call on a Routing Activation Request for Confirmation. If this container is configured but the DolPRoutingActivationConfirmation Func parameter is not present the DolP module will use an RPort of ServiceInterface <routingactivation>_RoutingActivation with the name "CB<routingactivation>Routing Activation". <routingactivation> is the ShortName of the DolPRoutingActivitation container.</routingactivation></routingactivation></routingactivation>
Configuration Parameters	



Included Parameters		
Parameter Name	Multiplicity	ECUC ID
DoIPRoutingActivationConfirmationFunc	01	[ECUC_DoIP_00036]
DoIPRoutingActivationConfirmationReqLength	1	[ECUC_DoIP_00037]
DoIPRoutingActivationConfirmationResLength	1	[ECUC_DoIP_00038]

No Included Containers	
------------------------	--

-

[ECUC_DoIP_00036] Definition of EcucFunctionNameDef DoIPRoutingActivation ConfirmationFunc $\ \lceil$

Parameter Name	DoIPRoutingActivationConfirmationFunc		
Parent Container	DoIPRoutingActivationConfirmationCallback		
Description	Direct C Callback function to trigger the confirmation function for routing activation. If the DoIPRoutingActivationConfirmationFunc parameter is present the DoIP module will not use an RPort of ServiceInterface <routingactivation>_RoutingActivation but call the configured function.</routingactivation>		
Multiplicity	01		
Туре	EcucFunctionNameDef		
Default value	-		
Regular Expression	-		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE		
	Link time	X	VARIANT-LINK-TIME, VARIANT-POST-BUILD
	Post-build time	ı	
Value Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE		
	Link time	Х	VARIANT-LINK-TIME, VARIANT-POST-BUILD
	Post-build time	_	
Scope / Dependency	scope: local		

1

[ECUC_DoIP_00037] Definition of EcucIntegerParamDef DoIPRoutingActivation ConfirmationReqLength $\ \lceil$

Parameter Name	DoIPRoutingActivationConfirmationReqLength	
Parent Container	DoIPRoutingActivationConfirmationCallback	
Description	Describes the amount of bytes used to handle to the confirmation function on routing activation. If 0 is configured as length the parameter ConfirmedReqData will not be handled to the API.	
Multiplicity	1	
Туре	EcucIntegerParamDef	
Range	04	





Default value	-		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE		
	Link time	Х	VARIANT-LINK-TIME, VARIANT-POST-BUILD
	Post-build time	-	
Scope / Dependency	scope: local		

1

[ECUC_DoIP_00038] Definition of EcucIntegerParamDef DoIPRoutingActivation ConfirmationResLength \crete{lambda}

Parameter Name	DoIPRoutingActivationConfirmationResLength		
Parent Container	DoIPRoutingActivationConfirmationCallback		
Description	Describes the amount of bytes used to read by the confirmation function on routing activation. If 0 is configured as length the parameter ConfirmedResData will not be fetched via the API.		
Multiplicity	1		
Туре	EcucIntegerParamDef		
Range	04		
Default value	-		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	Х	VARIANT-LINK-TIME, VARIANT-POST-BUILD
	Post-build time	_	
Scope / Dependency	scope: local		

10.2.27 DolPTester

[ECUC_DoIP_00031] Definition of EcucParamConfContainerDef DoIPTester [

Container Name	DoIPTester
Parent Container	DolPInterface
Description	This container describes the properties of the possible connectable Tester for the DoIP entity.
Post-Build Variant Multiplicity	false
Configuration Parameters	



Included Parameters		
Parameter Name	Multiplicity	ECUC ID
DoIPNumByteDiagAckNack	1	[ECUC_DoIP_00042]
DoIPTesterSA	1	[ECUC_DoIP_00043]
DoIPRoutingActivationRef	1255	[ECUC_DoIP_00062]

١

[ECUC_DolP_00042] Definition of EcucIntegerParamDef DolPNumByteDiagAck Nack \lceil

Parameter Name	DoIPNumByteDiagAckNack			
Parent Container	DoIPTester	DoIPTester		
Description	Specifies the number of original Diagnostic request bytes the DoIP entity responses on a NACK of a diagnostic response message to the Tester.			
Multiplicity	1			
Туре	EcucIntegerParamDef			
Range	0 4294967295			
Default value	-			
Post-Build Variant Value	true			
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE	
	Link time	Х	VARIANT-LINK-TIME	
	Post-build time	X	VARIANT-POST-BUILD	
Scope / Dependency	scope: local		·	

١

[ECUC_DoIP_00043] Definition of EcucIntegerParamDef DoIPTesterSA \lceil

Parameter Name	DoIPTesterSA			
Parent Container	DoIPTester			
Description	Source Address of the Tester sent v	ia routii	ng activation or diagnostic message.	
Multiplicity	1	1		
Туре	EcucIntegerParamDef			
Range	0 65535			
Default value	-			
Post-Build Variant Value	true			
Value Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE			
	Link time	Х	VARIANT-LINK-TIME	
	Post-build time	Х	VARIANT-POST-BUILD	
Scope / Dependency	scope: local			

١



[ECUC_DoIP_00062] Definition of EcucReferenceDef DoIPRoutingActivationRef

Parameter Name	DoIPRoutingActivationRef		
Parent Container	DolPTester		
Description	Reference to a DoIPRoutingActivation describing the possible routing activations of the DoIPTester		
Multiplicity	1255		
Туре	Reference to DoIPRoutingActiva	ition	
Post-Build Variant Multiplicity	true		
Post-Build Variant Value	true		
Multiplicity Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE		
	Link time	X	VARIANT-LINK-TIME
	Post-build time X VARIANT-POST-BUILD		VARIANT-POST-BUILD
Value Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE		
	Link time X VARIANT-LINK-TIME		
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: local		

1




Figure 10.11: DoIPTester

10.3 Published Information

For details refer to the chapter 10.3 "Published Information" in SWS_BSWGeneral [1].



A Change History

Please note that the lists in this chapter also include constraints and specification items that have been removed from the specification in a later version. These constraints and specification items do not appear as hyperlinks in the document.

A.1 Traceable item history of this document according to AUTOSAR Release R22-11

A.1.1 Added Specification Items in R22-11

none

A.1.2 Changed Specification Items in R22-11

Number	Heading
[SWS_DoIP_00020]	
[SWS_DoIP_00022]	
[SWS_DoIP_00023]	
[SWS_DoIP_00024]	
[SWS_DoIP_00025]	
[SWS_DoIP_00026]	
[SWS_DoIP_00027]	
[SWS_DoIP_00031]	
[SWS_DoIP_00032]	
[SWS_DoIP_00033]	
[SWS_DoIP_00037]	
[SWS_DoIP_00038]	
[SWS_DoIP_00039]	
[SWS_DoIP_00040]	
[SWS_DoIP_00041]	
[SWS_DoIP_00044]	
[SWS_DoIP_00045]	
[SWS_DoIP_00047]	
[SWS_DoIP_00048]	
[SWS_DoIP_00049]	
[SWS_DoIP_00050]	
[SWS_DoIP_00051]	



Number	Heading
[SWS_DoIP_00054]	
[SWS_DoIP_00055]	
[SWS_DoIP_00056]	
[SWS_DoIP_00057]	
[SWS_DoIP_00148]	
[SWS_DoIP_00244]	
[SWS_DoIP_00245]	
[SWS_DoIP_00261]	
[SWS_DoIP_00262]	
[SWS_DoIP_00263]	
[SWS_DoIP_00264]	
[SWS_DoIP_00266]	
[SWS_DoIP_00267]	
[SWS_DoIP_00268]	
[SWS_DoIP_00269]	
[SWS_DoIP_00270]	
[SWS_DoIP_00277]	
[SWS_DoIP_00278]	
[SWS_DoIP_00287]	
[SWS_DoIP_00288]	
[SWS_DoIP_00289]	
[SWS_DoIP_00290]	
[SWS_DoIP_91000]	
[SWS_DoIP_91002]	

Table A.1: Changed Specification Items in R22-11

A.1.3 Deleted Specification Items in R22-11

none

A.1.4 Added Constraints in R22-11

none

A.1.5 Changed Constraints in R22-11

none



A.1.6 Deleted Constraints in R22-11

none

A.2 Traceable item history of this document according to AUTOSAR Release R23-11

A.2.1 Added Specification Items in R23-11

Number	Heading
[SWS_DoIP_00321]	
[SWS_DoIP_00322]	
[SWS_DoIP_00323]	
[SWS_DoIP_00324]	
[SWS_DoIP_00325]	
[SWS_DoIP_00326]	
[SWS_DoIP_00327]	
[SWS_DoIP_00330]	
[SWS_DoIP_00331]	
[SWS_DoIP_00332]	

Table A.2: Added Specification Items in R23-11

A.2.2 Changed Specification Items in R23-11

Number	Heading
[SWS_DoIP_00016]	
[SWS_DoIP_00017]	
[SWS_DoIP_00019]	
[SWS_DoIP_00077]	
[SWS_DoIP_00078]	
[SWS_DoIP_00110]	
[SWS_DoIP_00113]	
[SWS_DoIP_00114]	
[SWS_DoIP_00141]	

Table A.3: Changed Specification Items in R23-11



A.2.3 Deleted Specification Items in R23-11

none

A.3 Traceable item history of this document according to AUTOSAR Release R24-11

A.3.1 Added Specification Items in R24-11

Number	Heading
[SWS_DoIP_00333]	Used DoIP protocol version
[SWS_DoIP_91003]	Definition of API function DoIP_AllowNonTlsDoIPConnection

Table A.4: Added Specification Items in R24-11

A.3.2 Changed Specification Items in R24-11

none

A.3.3 Deleted Specification Items in R24-11

none