## Program For UART interfacing with LPC 2148:-

```
#include<lpc214x.h>
void UART0_init(void)
PINSEL0=PINSEL0|0x00000005;
U0LCR=0x83;
 U0DLM=0x00;
U0DLL=0x61;
U0LCR=0x03;
unsigned char UART0_Rxchar(void)
while((U0LSR&0x01)==0);
void UART_Txchar(char ch)
U0THR=ch;
while ((U0LSR\&0x40)==0);
int main (void)
char receive;
UART0_init();
while(1)
receive=UART0_Rxchar();
UART_Txchar(receive);
}return 0;}
```