Nodemcu v3-CH340 sch

esp8266



MATTERS NEEDING ATTENTION
On every boot/reset/wakeup,
GPIO15 MUST keep LOW, GPIO2 MUST keep HIGH.
GPIO0 HIGH -> RUN MODE, LOW -> FLASH MODE.
When you need to use the sleep mode,GPIO16 and RST should be connected,
and GPIO16 will output LOW to reset the system at the time of wakeup.



ADC



Use 1% resistor here.

KEY



USB TO UART



POWER



IO-PIN



Title		
Size: A2	Number	Revision
Date: 2019-07-27	Sheet of	
File: E:\新品\...\Nodemcu V3-340原理图.SchDoc	Drawn By:	