

二进制数的补码:

- ・ 最高位为符号位(O为正, 1为负)
- 正数的补码和它的原码相同
- · 负数的补码 = 数值位逐位求反 + 1

$$+5 = (0 \ 0101)$$

 $-5 = (1 \ 1011)$

两个补码表示的二进制数相加时的符号位讨论

例: 用二进制补码运算求出 -

注意编码的 取值范围

 $13+10 \cdot 13-10 \cdot -13+10 \cdot -13-10$

+13 0 01101 +13 0 01101 +10 0 01010 -10 1 10110 +3 0 00011 + 23 0 10111

-13 1 10011 -13 1 10011 -10 1 10110 +10 0 01010 -3 1 11101 -23 1 01001

结论: 将两个加数的符号位和来自最高位数字位的进位相


加、结果就是和的符号

・码制

用不同数码表示不同事物时遵循的规则 例如:学号,身份证号,车牌号。。。

- 目前,数字电路中都采用二进制
- 表示数量时称二讲制
- ・表示事物时称二值逻辑

wang_hong@tsinghua.edu.cn | 横葉大堂



Fixed-length encodings 等长编码

If all choices are equally likely (or we have no reason to expect otherwise), then a fixed-length code is often used. Such a code will use at least enough bits to represent the information content.

ex. Decimal digits 10 = {0,1,2,3,4,5,6,7,8,9} 4-bit BCD (binary code decimal)


$$log_2(10) = 3.322 < 4bits$$

ex. ~86 English characters = {A-Z (26), a-z (26), 0-9 (10), punctuation (11), math (9), financial (4)} 7-bit ASCII (American Standard Code for Information Interchange)

$$log_2(86) = 6.426 < 7bits$$

wang_hong@tsinghua.edu.cn 19 莱大学

1种常	常用的 [·]	十进制	代码		
十进制数	8421码	余 3 码	2421码	5211码	余3循环码
0	0000	0011	0000	0000	0010
1	0001	0100	0001	0001	0110
2	0010	0101	0010	0100	0111
3	0011	0110	0011	0101	0101
4	0100	0111	0100	0111	0100
5	0101	1000	1011	1000	1100
6	0110	1001	1100	1001	1101
7	0111	1010	1101	1100	1111
8	1000	1011	1110	1101	1110
9	1001	1100	1111	1111	1010



格雷码 每一位的状态变化都按一定的顺序循环。 编码顺序依次变化,按表中顺序变化时,相邻代码只有一位 改变状态。 编码顺 二进制 格雷码 编码顺序 二进制码 格雷码 序 清華大学 wang_hong@tsinghua.edu.cn

