OTA via BLE: Using Android Smartphone

1. Install the 'ST BLE Sensor' application in Google Play Store.



ST BLE 센서 어플리케이션을 사용하면 모든 센서 데이터에 액세스 할 수 있습니다

2. Launch this application.



3. Input command via UART of SRM100A


enter_service_manager

Caution) This command erases all flash memory, so do not use it unless you download OTA firmware.


4. Select 'CONNECT TO A DEVICE'




CONNECT TO A DEVICE




5. Select OTAServiceMgr 선택




6. Push "SELECT FILE" and then choose the binary file, XXXXX





7. Push the download button. (Red rectangle square in the image below)



8. When the update is complete, you can see the "Upload completed" pop-up.

