
## Lecture 2

• Performance/Power/Cost

## Computer Engineering Methodology





# Importance of Evaluation/Analysis


- Why do we care about <u>performance/power/cost</u> evaluation?
  - Purchasing perspective
    - given a collection of machines, which has the
      - best performance ? lowest power
      - □ least cost ?
      - best performance / cost ?
  - Design perspective
    - faced with design options, which has the
      - best performance improvement ? Best energy-efficiency?
      - least cost ?
      - best performance / cost ?
- How to measure, report, and summarize performance/power/cost?
  - Metric
  - □ Benchmark 常使用評估的程式


# Defining Performance

#### Which airplane has the best performance?









Chapter 1 — Computer Abstractions and Technology — 4

## Response Time and Throughput

- Response time e.g. Smartphone
  - How long it takes to do a task
- Throughput e.g. Server
  - Total work done per unit time
    - e.g., tasks/transactions/... per hour
- How are response time and throughput affected by
  - Replacing the processor with a faster version? response time
  - Adding more processors? throughput
- We'll focus on response time for now...

### Relative Performance

- Define Performance = 1/Execution Time
- "X is n time faster than Y"

Performance<sub>x</sub>/Performance<sub>y</sub>

- = Execution time  $_{Y}$  /Execution time  $_{X} = n$
- Example: time taken to run a program
  - 10s on A, 15s on B
  - Execution Time<sub>B</sub> / Execution Time<sub>A</sub>
     = 15s / 10s = 1.5
  - So A is 1.5 times faster than B

## Measuring Execution Time

### Elapsed time

- Total response time, including all aspects
  - Processing, I/O, OS overhead, idle time
- Determine system performance

#### CPU time

- Time spent processing a given job
  - Discounts I/O time, other jobs' shares
- Comprises user CPU time and system CPU time
- Different programs are affected differently by CPU and system performance

### CPU Time

CPU Time = CPU Clock Cycles × Clock Cycle Time


= CPU Clock Cycles

Clock Rate (frequency)

- Performance improved by
  - Reducing number of clock cycles
  - Increasing clock rate
  - Hardware designer must often trade off clock rate against cycle count

## CPU Clocking

Operation of digital hardware governed by a constant-rate clock



- Clock period: duration of a clock cycle
  - e.g.,  $250ps = 0.25ns = 250 \times 10^{-12}s$
- Clock frequency (rate): cycles per second

Chapter 1 — Computer e.g., 4.0GHz = 4000MHz = 4.0×10<sup>9</sup>Hz
Abstractions and Technology —

## CPU Time Example

- Computer A: 2GHz clock, 10s CPU time
- Designing Computer B
  - Aim for 6s CPU time

- CPU Time = CPU Clock Cycles × Clock Cycle Time  $= \frac{\text{CPU Clock Cycles}}{\text{Clock Rate (frequency)}}$
- □ Can do faster clock, but causes 1.2 × clock cycles
- How fast must Computer B clock be?

Clock Rate<sub>B</sub> = 
$$\frac{\text{Clock Cycles}_{\text{B}}}{\text{CPU Time}_{\text{B}}} = \frac{1.2 \times \text{Clock Cycles}_{\text{A}}}{6\text{s}}$$

Clock Cycles<sub>A</sub> = CPU Time<sub>A</sub> × Clock Rate<sub>A</sub>

$$= 10\text{s} \times 2\text{GHz} = 20 \times 10^{9}$$

Clock Rate<sub>B</sub> =  $\frac{1.2 \times 20 \times 10^{9}}{6\text{s}} = \frac{24 \times 10^{9}}{6\text{s}} = 4\text{GHz}$ 

### Instruction Count and CPI

CPU Time = CPU Clock Cycles × Clock Cycle Time

Clock Cycles = Instruction Count × Cycles per Instruction

CPU Time = Instruction Count  $\times$  CPI  $\times$  Clock Cycle Time

Instruction Count × CPI

#### Clock Rate

- Instruction Count for a program
  - (Instruction Set Architecture)
  - Determined by <u>program</u>, <u>ISA</u> and <u>compiler</u>
- Average cycles per instruction
  - Affected by both
    - Hardware CPI per instruction type)

Chapter 1 — Compuscoftware (instruction mix)

## CPI Example

- Computer A: Cycle Time = 250ps, CPI = 2.0
- Computer B: Cycle Time = 500ps, CPI = 1.2
- Same ISA
- Which is faster, and by how much?

$$\begin{aligned} \text{CPU Time}_{A} &= \text{Instruction Count} \times \text{CPI}_{A} \times \text{Cycle Time}_{A} \\ &= I \times 2.0 \times 250 \text{ps} = I \times 500 \text{ps} & \text{A is faster...} \end{aligned}$$
 
$$\begin{aligned} \text{CPU Time}_{B} &= \text{Instruction Count} \times \text{CPI}_{B} \times \text{Cycle Time}_{B} \\ &= I \times 1.2 \times 500 \text{ps} = I \times 600 \text{ps} \end{aligned}$$
 
$$\begin{aligned} &= I \times 600 \text{ps} \\ &= I \times 500 \text{ps} \end{aligned}$$
 
$$\begin{aligned} &= I \times 600 \text{ps} \\ &= I \times 500 \text{ps} \end{aligned}$$
 
$$\begin{aligned} &= I \times 600 \text{ps} \\ &= I \times 500 \text{ps} \end{aligned}$$
 
$$\begin{aligned} &= I \times 600 \text{ps} \\ &= I \times 600 \text{ps} \end{aligned}$$

### CPI in More Detail

If different instruction classes take different numbers of cycles

$$Clock\ Cycles = \sum_{i=1}^{n} (CPI_{i} \times Instruction\ Count_{i})$$

Weighted average CPI

$$CPI = \frac{Clock \ Cycles}{Instruction \ Count} = \sum_{i=1}^{n} \left( CPI_i \times \frac{Instruction \ Count_i}{Instruction \ Count} \right)$$

Relative frequency

## CPI Example

 Alternative compiled code sequences using instructions in classes A, B, C

Class	А	В	С
CPI for class	1	2	3
IC in sequence 1	2	1	2
IC in sequence 2	4	1	1

- Sequence 1: IC = 5
  - Clock Cycles= 2×1 + 1×2 + 2×3= 10
  - Avg. CPI = 10/5 = 2.0

Sequence 2: IC = 6

- Clock Cycles =  $4 \times 1 + 1 \times 2 + 1 \times 3$ = 9
- Avg. CPI = 9/6 = 1.5


## Aspects of CPU Performance

CPU time = Seco	nds = Instructions	x Cycles	x Seconds
Prog	ram Program	Instructi	on Cycle
(benchr	Inst Count	СРІ	Clock Rate
Algorithm	X	X	
Programming Language	X	X	
Compiler	X	X	
ISA (instruction set arc	X hitecture)	X	X


When comparing 2 machines, these "3 components" must be considered! We cannot only consider 1 component!

# Now, you can answer this question..


Q2: CPU frequency Performance




### Power Trends




In CMOS IC technology



## The CMOS Inverter



## Energy vs. Power




## Reducing Power

- Suppose a new CPU has
  - 85% of capacitive load of old CPU
  - 15% voltage and 15% frequency reduction

$$\frac{P_{\text{new}}}{P_{\text{old}}} = \frac{C_{\text{old}} \times 0.85 \times (V_{\text{old}} \times 0.85)^2 \times F_{\text{old}} \times 0.85}{C_{\text{old}} \times V_{\text{old}}^2 \times F_{\text{old}}} = 0.85^4 = 0.52$$

- The power wall
  - We can't reduce voltage further
  - We can't remove more heat
- How else can we improve performance?


## Uniprocessor Performance



Chapter 1 — Computer
Abstractions and Technology —
21

#### Why is Multi-Core Good for Energy-Efficiency?


Do the same thing, but cost less energy.



## Multiprocessors


- Multicore microprocessors
  - More than one processor per chip
- Requires <u>explicitly parallel programming</u>
  - Compare with instruction level parallelism
    - Hardware executes multiple instructions at once
    - Hidden from the programmer
  - Hard to do
    - Programming for performance
    - Load balancing
    - Optimizing communication and synchronization

# Manufacturing ICs



Yield: proportion of working dies per wafer

## AMD Opteron X2 Wafer



- X2: 300mm wafer, 117 chips, 90nm technology
- X4: 45nm technology

# Integrated Circuit Cost

Cost per die = 
$$\frac{\text{Cost per wafer}}{\text{Dies per wafer} \times \text{Yield}}$$

Dies per wafer  $\approx \text{Wafer area/Die area}$ 

Yield =  $\frac{1}{(1+(\text{Defects per area} \times \text{Die area/2}))^2}$ 

- Yield proportion of working dies per wafer
- IC cost is nonlinear relation to area and defect rate
  - Wafer cost and area are fixed
  - Defect rate determined by manufacturing process
    - Die area determined by architecture and circuit design

### SPEC CPU Benchmark

- Programs used to measure performance
  - Supposedly typical of actual workload
- Standard Performance Evaluation Corp (SPEC)
  - Develops benchmarks for CPU, I/O, Web, ...
- Elapsed time to execute a selection of programs
  - Negligible I/O, so focuses on CPU performance
- Contain both integer and floating point applications
  - CINT (integer) and CFP (floating-point)

SPEC2006 benchmark description	SPEC2006	Benchmark r SPEC2000	name by SPE SPEC95	C generation SPEC92	SPEC89
GNU C compiler					— gcc
Interpreted string processing			— perl		espresso
Combinatorial optimization		— mcf			li
Block-sorting compression		— bzip2		compress	eqntott
Go game (AI)	go	vortex	go	sc	
Video compression	h264avc	gzip	ijpeg		•
Games/path finding	astar	eon	m88ksim		
Search gene sequence	hmmer	twolf			
Quantum computer simulation	libquantum	vortex			
Discrete event simulation library	omnetpp	vpr			
Chess game (AI)	sjeng	crafty			
XML parsing	xalancbmk	parser			
CFD/blast waves	bwaves				fpppp
Numerical relativity	cactusADM				tomcatv
Finite element code	calculix				doduc
Differential equation solver framework	dealll				nasa7
Quantum chemistry	gamess				spice
EM solver (freq/time domain)	GemsFDTD			swim	matrix300
Scalable molecular dynamics (~NAMD)	gromacs		apsi	hydro2d	
Lattice Boltzman method (fluid/air flow)	Ibm		mgrid	su2cor	
Large eddie simulation/turbulent CFD	LESlie3d	wupwise	applu	wave5	
_attice quantum chromodynamics	milc	apply	turb3d		'
Molecular dynamics	namd	galgel		•	
mage ray tracing	povray	mesa			
Spare linear algebra	soplex	art			
Speech recognition	sphinx3	equake			
Quantum chemistry/object oriented	tonto	facerec			
Weather research and forecasting	wrf	ammp			
Magneto hydrodynamics (astrophysics)	zeusmp	lucas			
, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		fma3d			
		sixtrack			

### How to Summarize Suite Performance

- Arithmetic average of execution time of all pgms?
  - But they vary by 4X in speed, so some would be more important than others in arithmetic average
- SPECRatio: Normalize execution times to reference computer, yielding a ratio proportional to performance =

time on reference computer

time on computer being rated

#### **SPECRatio**

If program SPECRatio on Computer A is 1.25 times bigger than Computer B, then

$$1.25 = \frac{SPECRatio_{A}}{SPECRatio_{B}} = \frac{ExecutionTime_{reference}}{ExecutionTime_{reference}}$$

$$= \frac{ExecutionTime_{B}}{ExecutionTime_{B}} = \frac{Performance_{A}}{Performance_{B}}$$

 Note that when comparing 2 computers as a ratio, execution times on the reference computer drop out, so choice of reference computer is irrelevant

### CINT2006 for Intel Core i7 920

Description	Name	Instruction Count x 10 <sup>9</sup>	CPI	Clock cycle time (seconds x 10 <sup>-9</sup> )	Execution Time (seconds)	Reference Time (seconds)	SPECratio
Interpreted string processing	perl	2252	0.60	0.376	508	9770	19.2
Block-sorting compression	bzip2	2390	0.70	0.376	629	9650	15.4
GNU C compiler	gcc	794	1.20	0.376	358	8050	22.5
Combinatorial optimization	mcf	221	2.66	0.376	221	9120	41.2
Go game (AI)	go	1274	1.10	0.376	527	10490	19.9
Search gene sequence	hmmer	2616	0.60	0.376	590	9330	15.8
Chess game (AI)	sjeng	1948	0.80	0.376	586	12100	20.7
Quantum computer simulation	libquantum	659	0.44	0.376	109	20720	190.0
Video compression	h264avc	3793	0.50	0.376	713	22130	31.0
Discrete event simulation library	omnetpp	367	2.10	0.376	290	6250	21.5
Games/path finding	astar	1250	1.00	0.376	470	7020	14.9
XML parsing	xalancbmk	1045	0.70	0.376	275	6900	25.1
Geometric mean	-	_	_	-	-	_	25.7

### SPEC Power Benchmark

- Specpower: Power consumption of server at different workload levels
  - Run SPECJBB2005 (Java Business Application)
  - Report power consumption of servers at different workload levels, divided into 10% increments
  - Performance: ssj\_ops/sec
  - Power: Watts (Joules/sec)

Overall ssj\_ops per Watt = 
$$\left(\sum_{i=0}^{10} ssj_ops_i\right) / \left(\sum_{i=0}^{10} power_i\right)$$


# SPECpower\_ssj2008 for X4

Target Load %	Performance (ssj_ops/sec)	Average Power (Watts)
100%	231,867	295
90%	211,282	286
80%	185,803	275
70%	163,427	265
60%	140,160	256
50%	118,324	246
40%	920,35	233
30%	70,500	222
20%	47,126	206
10%	23,066	180
0%	0	141
Overall sum	1,283,590	2,605
∑ssj_ops/ ∑power		493

## Pitfall: Amdahl's Law

錢要花在刀口上

 Improving an aspect of a computer and expecting a proportional improvement in overall performance



$$T_{\text{improved}} = \frac{T_{\text{affected}}}{\text{improvement factor}} + T_{\text{unaffected}}$$

- Example: multiply accounts for 80s/100s
  - How much improvement in multiply performance to get 5x overall?

$$20 = \frac{80}{n} + 20$$
 • Can't be done!

Chapter 1 Corollary: make the common case fast

## Fallacy: Low Power at Idle

- Look back at X4 power benchmark
  - At 100% load: 295W
  - At 50% load: 246W (83%)
  - At 10% load: 180W (61%)
- Google data center
  - Mostly operates at 10% 50% load
  - At 100% load less than 1% of the time
- Consider designing processors to make power proportional to load

#### Pitfall: MIPS as a Performance Metric

- MIPS: Millions of Instructions Per Second
  - Doesn't account for
    - Differences in ISAs between computers
    - Differences in complexity between instructions
      - CPI varies between programs on a given CPU (Can't have single MIPS index for a processor)

$$\begin{aligned} \text{MIPS} &= \frac{Instruction \, count}{Execution \, time \times 10^6} \\ &= \frac{Instruction \, count}{Instruction \, count \times CPI_{\times 10^6}} = \frac{Clock \, rate}{CPI \times 10^6} \end{aligned}$$

CPU's performance can't be represented by a single

Chapter 1 — Mapes value Abstractions and Technology —

Different CPUs can't be compared with MIPS

## Homework #1

Ex 1.5, 1.6 1.8 – Due next week before classes