


Computer Networks: Assignment-10

Name: Suraj Shah

Admission Number: I24AI012

Q 1) Configure the network below using two routers, one wireless and another 1841 router.

Diagram:



IP Config:

PC0: 192.168.1.2 / 255.255.255.0 / 192.168.1.1

PC1: 192.168.1.3 / 255.255.255.0 / 192.168.1.1

PC2: 192.168.1.4 / 255.255.255.0 / 192.168.1.1

PC3: 192.168.1.5 / 255.255.255.0 / 192.168.1.1

PC4: 192.168.1.6 / 255.255.255.0 / 192.168.1.1

Laptop0: 192.168.1.7 / 255.255.255.0 / 192.168.1.1

PC5: 192.168.4.3 / 255.255.255.0 / 192.168.4.1

PC6: 192.168.4.4 / 255.255.255.0 / 192.168.4.1

PC7: 192.168.4.5 / 255.255.255.0 / 192.168.4.1

PC8: 192.168.4.2 / 255.255.255.0 / 192.168.4.1

Tablet PC4: 192.168.4.10 / 255.255.255.0 / 192.168.4.1

Tablet PC5: 192.168.4.11 / 255.255.255.0 / 192.168.4.1

Tablet PC6: 192.168.4.13 / 255.255.255.0 / 192.168.4.1

Tablet PC7: 192.168.4.12 / 255.255.255.0 / 192.168.4.1

Laptop1: 192.168.4.7 / 255.255.255.0 / 192.168.4.1

Laptop2: 192.168.4.8 / 255.255.255.0 / 192.168.4.1

Laptop3: 192.168.4.6 / 255.255.255.0 / 192.168.4.1

Laptop4: 192.168.4.9 / 255.255.255.0 / 192.168.4.1

Router0:

FastEthernet0/0: 192.168.1.1 / 255.255.255.0

FastEthernet0/1: 192.168.4.1 / 255.255.255.0

WirelessRouter0:

Internet:

Default Gateway: 192.168.4.1

LAN: 192.168.4.2 / 255.255.255.0

Wireless:

Wireless Settings			
SSID	Rahat		
2.4 GHz Channel	1 - 2.412GHz		
Coverage Range (meters)	250.00		
Authentication			
☐ Disabled	☒ WEP	WEP Key	0987612345
☐ WPA-PSK	☐ WPA2-PSK	PSK Pass Phrase	
☐ WPA	☐ WPA2		
RADIUS Server Settings			
IP Address			
Shared Secret			
Encryption Type	40/64-Bits (10 Hex digits)		

PC, Tablet, Laptop:

Wireless:

Link Information

Connect

Profiles

Below is a list of available wireless networks. To search for more wireless networks, click the **Refresh** button. To view more information about a network, select the wireless network name. To connect to that network, click the **Connect** button below.

Wireless Network Name	CH	Signal
Rahat	1	100%

Site Information

Wireless Mode

Infrastructure

Network Type

Mixed B/G/N

Radio Band

Auto

Security

WEP

MAC Address

0001.98A9.6306

Refresh

Connect

2.4GHz



Adapter is Active

Wireless-N Notebook Adapter

Wireless Network Monitor v1.0

Model No. WPC300N


Output:

Fire	Last Status	Source	Destination	Type	Color	Time(sec)	Periodic	Num	Edit	Delete
	Successful	PC8	192.168.4....	ICMP		0.000	N	0	(edit)	(delete)
	Successful	PC6	Laptop1	ICMP		0.000	N	1	(edit)	(delete)
	Successful	PC6	Laptop2	ICMP		0.000	N	2	(edit)	(delete)

Fire	Last Status	Source	Destination	Type	Color	Time(sec)	Periodic	Num	Edit	Delete
	Successful	PC4	PC8	ICMP		0.000	N	3	(edit)	(delete)
	Successful	Laptop0	PC7	ICMP		0.000	N	4	(edit)	(delete)
	Successful	PC0	Tablet PC4	ICMP		0.000	N	5	(edit)	(delete)

Q 2) Configure the FTP server as shown in the below network.

Diagram:



IP Config:

PC0: 192.168.0.2 / 255.255.255.0 / 192.168.0.1

PC1: 192.168.0.3 / 255.255.255.0 / 192.168.0.1

Router1:

FastEthernet0/0: 10.10.10.1 / 255.0.0.0

FastEthernet0/1: 192.168.0.1 / 255.255.255.0

Server1: 10.10.10.2 / 255.0.0.0 / 10.10.10.1

Services:

FTP:

FTP

Service ☒ On ☐ Off

User Setup

Username

Password

☐ Write ☐ Read ☐ Delete ☐ Rename ☐ List

	Username	Password	Permission	
1	cisco	cisco	RWDNL	Add
2	cisco1	test	RWNL	Save
				Remove

Output:

```
PC0
Physical Config Desktop Programming Attributes
Command Prompt

Cisco Packet Tracer PC Command Line 1.0
C:\>ping 10.10.10.2

Pinging 10.10.10.2 with 32 bytes of data:

Request timed out.
Reply from 10.10.10.2: bytes=32 time<1ms TTL=127
Reply from 10.10.10.2: bytes=32 time<1ms TTL=127
Reply from 10.10.10.2: bytes=32 time<1ms TTL=127

Ping statistics for 10.10.10.2:
    Packets: Sent = 4, Received = 3, Lost = 1 (25% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms

C:\>ftp 10.10.10.2
Trying to connect...10.10.10.2
Connected to 10.10.10.2
220- Welcome to PT Ftp server
Username:ciscot
331- Username ok, need password
Password:
230- Logged in
(passive mode On)
ftp>put hello.txt

Writing file hello.txt to 10.10.10.2:
File transfer in progress...

[Transfer complete - 41 bytes]

41 bytes copied in 0.054 secs (759 bytes/sec)
ftp>dir

Listing /ftp directory from 10.10.10.2:
 0 : asa842-k8.bin                5571584
 1 : asa923-k8.bin                30468096
 2 : c1841-advipservicesk9-mz.124-15.T1.bin 33591768
 3 : c1841-ipbase-mz.123-14.T7.bin 13832032
 4 : c1841-ipbasek9-mz.124-12.bin 16599160
 5 : c1900-universalk9-mz.SPA.155-3.M4a.bin 33591768
 6 : c2600-advipservicesk9-mz.124-15.T1.bin 33591768
 7 : c2600-i-mz.122-28.bin        5571584
 8 : c2600-ipbasek9-mz.124-8.bin  13169700
 9 : c2800nm-advipservicesk9-mz.124-15.T1.bin 50938004
10 : c2800nm-advipservicesk9-mz.151-4.M4.bin 33591768
11 : c2800nm-ipbase-mz.123-14.T7.bin 5571584
12 : c2800nm-ipbasek9-mz.124-8.bin 15522644
13 : c2900-universalk9-mz.SPA.155-3.M4a.bin 33591768
14 : c2950-i6q412-mz.121-22.EA4.bin 3058048
15 : c2950-i6q412-mz.121-22.EA8.bin 3117390
16 : c2960-lanbase-mz.122-25.FX.bin 4414921
17 : c2960-lanbase-mz.122-25.SEE1.bin 4670455
18 : c2960-lanbasek9-mz.150-2.SE4.bin 4670455
19 : c3560-advipservicesk9-mz.122-37.SE1.bin 8662192
20 : c3560-advipservicesk9-mz.122-46.SE.bin 10713279
21 : c800-universalk9-mz.SPA.152-4.M4.bin 33591768
22 : c800-universalk9-mz.SPA.154-3.M6a.bin 83029236
23 : cat3k_caa-universalk9.16.03.02.SPA.bin 505532849
24 : cgr1000-universalk9-mz.SPA.154-2.CG 159487552
25 : cgr1000-universalk9-mz.SPA.156-3.CG 184530138
26 : hello.txt                    41
27 : ir800-universalk9-bundle.SPA.156-3.M.bin 160968869
28 : ir800-universalk9-mz.SPA.155-3.M 61750062
29 : ir800-universalk9-mz.SPA.156-3.M 63753767
30 : ir800_yocto-1.7.2.tar        2877440
31 : ir800_yocto-1.7.2_python-2.7.3.tar 6912000
32 : pt1000-i-mz.122-28.bin        5571584
33 : pt3000-i6q412-mz.121-22.EA4.bin 3117390
ftp>
```



Physical Config Desktop Programming Attributes

Command Prompt

```
Cisco Packet Tracer PC Command Line 1.0
C:\>ftp 10.10.10.2
Trying to connect...10.10.10.2
Connected to 10.10.10.2
220- Welcome to PT Ftp server
Username:cisco1
331- Username ok, need password
Password:
230- Logged in
(passive mode On)
ftp>get hello.txt


Reading file hello.txt from 10.10.10.2:
File transfer in progress...

[Transfer complete - 41 bytes]

41 bytes copied in 0 secs
ftp>|
```

Q3) Configure the email server as shown in the network below.

Diagram:



IP Config:

PC1: 10.0.0.2 / 255.0.0.0 / 10.0.0.1

PC2: 10.0.0.3 / 255.0.0.0 / 10.0.0.1

Router:

FastEthernet0/0: 10.0.0.1 / 255.0.0.0

FastEthernet0/1: 192.168.1.1 / 255.255.255.0

Server: 192.168.1.2 / 255.0.0.0 / 192.168.1.1

Services:

EMAIL:

EMAIL

SMTP Service
☒ ON ☐ OFF

POP3 Service
☒ ON ☐ OFF

Domain Name:

User Setup

User Password

user1

user2

Mail Config:

PC0

Physical Config **Desktop** Programming Attributes

Configure Mail X

User Information

Your Name:

Email Address:

Server Information

Incoming Mail Server:

Outgoing Mail Server:

Logon Information

User Name:

Password:

PC1

Physical Config **Desktop** Programming Attributes

Configure Mail X

User Information

Your Name:

Email Address:

Server Information

Incoming Mail Server:

Outgoing Mail Server:

Logon Information

User Name:

Password:

Output:

