

# **Embedded C through AVR-GCC**



G V V Sharma\*

## **CONTENTS**

### 1 **Components**

1

#### 2 Blink

1

Abstract—This manual shows how to control an led using AVR-GCC. AVR-GCC is a C compiler for the Atmega328p.

_delay_ms(500);
//turn led on
PORTB = ((1 << PB5));
_delay_ms(500);

1 Components

Component Value Quantity Arduino UNO 1

## 2 Blink

1. Install subversion

sudo apt update sudo apt install subversion

2. Go to your working directory and download the folder titled **codes** using the following command.

svn checkout https://github.com/gadepall/ arduino/trunk/avr-gcc/setup/codes

- 3. Connect your arduino to the computer and open a terminal.
- 4. Open a terminal and go to the **codes** directory. Type make. The built in led on the arduino should be blinking.
- 5. If you open main.c in geany, you can execute the code by Shift+F9.
- 6. Now open **main.c**. Explain the following lines.

\*The author is with the Department of Electrical Engineering, Indian Institute of Technology, Hyderabad 502285 India e-mail: gadepall@iith.ac.in. All content in this manual is released under GNU GPL. Free and open source.

**Solution:**  $((0 \ll PB5))$  writes 0 to pin 13 (PB5). delay ms(500) introduces a delay of 500 ms.

7. Modify the above code to keep the led on.

PORTB = ((0 << PB5));

8. Repeat the above exercise to keep the led off.