

Logitech MX Master 4: How to Adjust Pointer DPI and Speed

To adjust the pointer DPI and speed on the Logitech MX Master 4 mouse, follow these steps:

1. Ensure the Logi Options Plus application is installed on your computer.
2. Launch the application and select your Logitech MX Master 4 mouse from the list of connected devices.
3. Navigate to the 'Point, Scroll, and Press' settings.
4. Click on 'Pointer Speed' to adjust the speed according to your preference.
5. [To extend the sensor range, select the 'Extend Sensor Range' option to unlock higher DPI values, allowing you to adjust the DPI from standard settings around 400-800 DPI up to 8,000 DPI for high-precision tasks.](#)

[For more detailed instructions and troubleshooting, refer to the Logitech MX Master 4 user guide and support page.](#)