### Condition

## Extent of Defect/Damage

### **Action To Be** Taken



Shallow (not reaching casing)

Continue to use.

Deep (reaching the casing)

Scrap.

Cut



Tread cut penetration

Scrap.

Side cut penetration

Scrap.

Separation (tread separated from belt or casing ply)




**Excessive swelling** 

casing separated

If covering the entire circumference of the tire, scrap.

Scrap.



Peeling of tread or tread and

Scrap.

# Condition

Extent of Defect/Damage

Action To Be Taken

Separation (belt edge separation)



Separation or impact breaking from belt edge

Scrap.

Rim Chafing



Chafing at bead area

Continue to use with monitoring.

Abnormal Wear



Feathering

Quick wearing of both shoulders or center

Spot wear, irregular wear

Wearing of one shoulder


Rotate or reverse tires, check pressures and load.

Check pressures and load.

Check brakes, wheels, bearings and alignment.

Check alignment.

**Tread Chunking** 



Blocks chunk out from the tread

Improve road surface, rotate or reverse tires, avoid rough driving.

# Condition Extent of **Action To Be** Defect/Damage Taken Continue to use, with Shallow cracking adequate pressure. Groove Cracking Consult a Bridgestone Deep cracking Representative. Tire impact breaking from Scrap. shock or cut Side Impact Breaking Even wearing, with no Scrap. external damage or swelling Worn Out

**△DANGER**Others

(NO PHOTO)

Affected by lightning

Damaged due to oil or chemical action, fire

Scrap.

Scrap.