
class client.service



«interface» contract::IClientConfigurationService

- getBattervPowerMessageInterval(): int
- + getCameraEnabled(): boolean + getConnectionParameter() : ConnectionParameter
- + getLastHostAdress(): String
- + getLastPort(): int
- + getLocationMessageInterval(); int + getSavedPassword(): String
- + reset(): void + resetSavedConnectionParameter(): void
- + saveConnectionParameter(ConnectionParameter): void

impl::ClientConfigurationService

- CAMERA ENABLED KEY: String = "CameraEnabled" (readOnly) - LAST HOST ADRESS KEY: String = "LastHostAdress" (readOnly)
- LAST PORT KEY: String = "LastPort" (readOnly) - LOCATION MESSAGE INTERVAL KEY: String = "LocationMessag... {readOnly}
- prefs: SharedPreferences {readOnly} SAVED PASSWORD KEY: String = "SavedPassword" {readOnly}
- + ClientConfigurationService(Context) + getBatteryPowerMessageInterval():int
- + getCameraEnabled(): boolean + getConnectionParameter(): ConnectionParameter
- + getLastHostAdress(): String
- + getLastPort():int + getLocationMessageInterval(); int
- + getSavedPassword(): String + reset(): void
- + resetSavedConnectionParameter(): void
- + saveConnectionParameter(ConnectionParameter) : void