

UNDER COATS

Bondfix White

White cement-based product with re-dispersible polymer for a smooth finish on interior and exterior walls.

*All COLORSOME® products contain no added Lead, Mercury, Arsenic or Chromium from April 2008.



WATER
RESISTANT



LEAD FREE*
GUARANTEE



EXCELLENT
DURABILITY

*All COLORSOME® products contain no added Lead, Mercury, Arsenic or Chromium from April 2008.

1. AREAS OF APPLICATION



EXTERIOR/
INTERIOR
PLASTERS



CONCRETE



ASBESTOS
SHEETS



MASONRY
SURFACES

Ideal for interior and exterior plaster surfaces, concrete, asbestos sheets, masonry and other cementitious substrates.

2. FEATURES & BENEFITS

- ✓ Provides smooth, uniform finish
- ✓ Good Workability
- ✓ Does not require water curing
- ✓ Good water resistance
- ✓ 1 coat application up to 6 mm thickness
- ✓ Controlled water vapour permeability
- ✓ Excellent abrasion resistance
- ✓ Algae and fungi resistance on wall
- ✓ Good intercoat adhesion to emulsion paints

3. PRODUCT DETAILS

CHEMICAL PARAMETERS

- **Base:** White Cement with re-dispersible polymer
- **Colour:** White
- **Thinning:** 35% - 40% Water by weight
- **Stability of Thinned Material:** Use within 45 minutes

PHYSICAL PARAMETERS

PARAMETER	TEST STANDARD USED	TYPICAL VALUES
Drying Time (Surface Dry)	---	30 min
Recoat Period (at 25°C & 50% RH)	---	6 - 8 hours
Shelf Life (from manufacture)	---	1 Year (in original, sealed sacks)
Compressive Strength	---	Good
Tensile Adhesion Strength	---	Good
Flexural Strength	---	Good

4. APPLICATION METHOD



SURFACE PREPARATION

- **New concrete/masonry:** Allow to cure completely (28 days recommended). Ensure clean, dry surface, free from dirt, loose plaster, dust, and all contaminants.
- Remove existing algae/fungi growth by vigorous wire brushing and cleaning. One coat of a professional quality bio-inhibitor is recommended to prevent further growth.
- Pre-wet the surface with water before you the first coat.



PRIMING & APPLICATION

- **Step 1:** Sand surface with Emery Paper 180 and wipe clean.
- **Step 2:** Pre-wet surface before 1st coat.
- **Step 3:** Apply 1st coat using putty knife/trowel (dilute with 35-40% water).
- **Step 4:** Pre-wet surface and apply 2nd coat (dilute with 35-40% water) after 6-8 hours. Do not sand vigorously.



POST-PAINTING

Apply a coat of professional quality exterior wall primer or special-purpose adhesive primer over the completely cured putty. Follow with 2-3 coats of high-quality emulsion paint for the desired finish.

5. SAFETY FEATURES & PRECAUTIONS



Refer to MSDS for detailed safety information.



Keep out of reach of children and away from food and drink.



Wear eye protection during application; rinse immediately with plenty of water if eyes are contacted.



Avoid skin contact; wash immediately with soap and water if contacted.



Do not pour leftover product down drain or into water courses.



STORAGE PRECAUTIONS



Store at a cool and dry place at ambient temperatures. Product has 1 year shelf life in original tightly sealed sacks.

COVERAGE



1 - 1.5 sq.m/kg for upto 1.5 mm thickness in 2 coats on rough surfaces.

HOW TO USE



1 Clean and smooth surface.



2 Mix with 20-30% water.



3 Apply 1-2 coats.



4 Wait 6-8 hours before 2nd coat.



5 Sand, apply primer and emulsion.

RECOMMENDED FOR

- ✓ Exterior/Interior Plasters
- ✓ Concrete Surfaces
- ✓ Masonry Surfaces
- ✓ Asbestos Sheets

