



EXTERIOR EMULSION

ShieldSheen

Premium Shield Finish

A smooth water-based, modified acrylic emulsion fortified with advanced Dust Proof Technology and Silicon Boost.

- DUST PROOF TECHNOLOGY
- WATER RESISTANT
- UV PROTECTION
- SUPERIOR DURABILITY



- WATER BASED
- LEAD FREE* GUARANTEE
- EXTREME PROTECTION

*All COLORSOME® products contain no added Lead, Mercury, Arsenic or Chromium.

1. AREAS OF APPLICATION



Exterior Walls



Residential Buildings



Commercial Complexes



High-Rise Structures

Ideal for exterior surfaces that require long-lasting protection, beauty, and superior weather resistance.

2. FEATURES AND BENEFITS

- ✓ Superior Dust Proof Technology resists dust settlement, keeping homes clean for longer.
 - ✓ Enhanced with Silicon Boost for improved water resistance and durability.
 - ✓ Excellent resistance to algae and fungi growth prevents black spots.
 - ✓ Withstands extreme tropical conditions like high rainfall, humidity, and heat.
- ✓ Provides extreme good protection against alkali and UV degradation.
 - ✓ Prevents shade fading and ensures film integrity.
 - ✓ Excellent hiding power and smooth, premium finish.
 - ✓ Meets LEEDS green building standards.
 - ✓ Extensive shade range with over 1900 attractive colors, including dark shades.
 - ✓ Supported by a comprehensive performance warranty.

3. PRODUCT DETAILS

CHEMICAL PARAMETERS:

Polymer type: Acrylic Emulsion
Pigment type: Rutile Titanium Dioxide and extenders
Specific Gravity: Approx. 1.35
Shelf Life: 2 Years

PHYSICAL PARAMETERS:

PARAMETER	TEST STANDARD USED	TYPICAL VALUES
Theoretical Coverage	—	60 - 70 sq.ft./ltr in 2 coats**
Recommended Coats	—	2 Coats
Application Tools	—	Brush / Roller / Spray
Finish	—	Smooth Sheen

**Coverage may vary depending on surface porosity, texture, application method and color shade.

4. APPLICATION METHOD



SURFACE PREPARATION

- **New Concrete Plaster:** should be cured for at least 28 days old and have a monfare content of less than 5–10%. Excessive laitance should be removed by mechanical methods. Dust and other details should be removed by vacuum cleaning. Any fine clocks or pin holes should be covered with Epoxy-based mortar.
- **Old Concrete Planer:** damaged areas of surface insulations should be repaired using apoxy-based mortar. All cracks larger than hairline shall be considered as moving and must be repaired with apoxy-based mortar. All delaminated and splashed areas of concrete shall be repaired prior to application of PDD with epoxy-based mortar.



PRIMING

- Apply one coat of Colorsome Water-Based Primer at the recommended coverage.
- Ensure the primer is compatible with the substrate and allow it to dry completely.
- For highly absorbent or porous surfaces, apply a second coat of Colorsome Water-Based Primer if required.
- Allow the primer to dry for 4–6 hours before applying the first coat of the finish.



APPLICATION OF SHIELDSHEEN

- Cleans application, mix the material well with mechanical mixer to get homogeneous brush able consistency.
- Apply mixed material with brush or roller at recommended coverage for first coat and allow to day for 8 - 10 hours before 2nd coat applications, depending on the ambient conditions and surface temperature.
- Similarly apply 2nd coat at recommended coverage, both coat should be applied to cross - direction to each other.
- Wet test may be performed when at least 72 hours have passed since application of the final coat.

5. SAFETY FEATURES & PRECAUTIONS



Kindly refer to the MSDS for COLORSOME ShieldSheen for detailed safety measures.



Keep out of reach of children and away from eatables.



Wear eye protection and gloves during application.



In case of contact with eyes, rinse immediately with plenty of water.



Do not empty into drains or watercourses.



Dispose of container safely and responsibly.

STORAGE PRECAUTIONS



- Store in a cool and dry place at ambient temperatures.
- Store the container with the lid tightly closed in an upright position.
- Store away from direct sunlight and heat.

RECOMMENDED FOR



- ✓ New Construction
- ✓ Renovation
- ✓ Coastal Areas
- ✓ High Humidity Zones
- ✓ Industrial & Pollution Prone Areas

HOW TO USE



- 1 Clean the surface and remove dust and loose particles.
- 2 Apply 1 coat of Epoxy Primer evenly.
- 3 Let it dry for 4–6 hours before applying top coat.

