

WOOD COATINGS

Woodguard Pro

A premium paraffin-based wood coating for unsurpassed gloss and durability.



-  **UNSURPASSED GLOSS**
-  **LEAD FREE GUARANTEE**
-  **NO ADDED LEAD, MERCURY, ARSENIC OR CHROMIUM**

1. AREAS OF APPLICATION



Interior Furniture



Wooden Cabinets



Veneer Surfaces



Seasoned Wood

Ideal for all wooden interior applications requiring a high gloss, durable finish.

2. FEATURES AND BENEFITS

- ✓ Very high depth-of-image for a mirror-like finish
- ✓ Unmatched solid content for higher film thickness and durability
- ✓ Heat, scratch, and stain resistance for low maintenance
- ✓ White variant provides excellent opacity and Whiteness Index
- ✓ Provides long-lasting hardness
- ✓ Maintains mirror-like shine for years
- ✓ High gloss finish

3. PRODUCT DETAILS

CHEMICAL PARAMETERS:

- Paraffin-based coating
- Unmatched solid content

PHYSICAL PARAMETERS:

Parameter	Test Standard	Typical Values
Gloss Level (60° head)	—	>95% (after buffing)
Viscosity (by vol)	—	10–15%
Drying Time (Surface dry)	—	60 mins
Tack Free Time	—	2.5 hours
Recommended Recoat Time	—	10–12 mins* (initial coats)
Coverage	—	0.5 – 0.9 sq. mtrs./kg**
Buffing Time	—	24–48 hours after last coat
Solvent Base	—	Paraffin-based
Shelf Life (Polyester base)	—	9 months
Shelf Life (Catalyst/Accelerator)	—	12 months

* Application conditions at 25°C and 50% RH ** Coverage may vary based on application method and surface type.

4. APPLICATION METHOD



SURFACE PREPARATION

- Ensure seasoned wood is clean and free from dust, oil, or grease. Compressor must be free from moisture and oil.
- Sand surface along grains with paper no. 180, then 320/400. Wipe clean.
- Apply 1–2 coats of generic Epoxy Insulator to reduce absorption and insulate oils/resins.
- Apply generic Wood Filler for dents.



STAINING & APPLICATION

Optional staining: Apply Interior or Exterior Wood Stains by ragging, dry for 30–120 mins.

Application steps: Use Air Spraying (2.2–2.8 Kgs/sq.cm pressure).

- Check recoatability by touch—film should be tacky and rubbery.
- Apply 6–8 coats of the system. For first few coats, recoating interval is 10–12 mins. Stop if film stops being tacky, allow overnight dry, sand with 220 paper, restart.



MIXING & BUFFING

- Mix Base:Special Accelerator:Catalyst in 100:1:2 ratio.
- Consume thinned paint within 5–10 mins. Use NC Paints Thinner for clean up.

BUFFING: Must be done after 24–48 hours of last coat.

- Sand with 220 to remove wax, then progressive sanding from 440 to 2000.
- Carry out wet sanding with 600–2000 papers. Uniformly apply generic buffing compound to achieve desired gloss.
- Do not heavy buff on small areas.

5. SAFETY FEATURES & PRECAUTIONS



Flammable product. Keep away from ignition sources.



Work in a well-ventilated place; wear overalls and gloves.



Avoid eye and skin contact; wash with plenty of clean water in case of contact.



Do not inhale or inject; seek medical attention if symptoms persist.



Store container tightly closed, upright, in a cool, dry place.



Keep out of reach of children.



No added Lead, Mercury or Chromium compounds.

STORAGE PRECAUTIONS



- Store in original tightly closed container away from direct sunlight and heat.
- Keep containers closed when not in use.
- Store in a cool, dry place away from children and eatables.

RECOMMENDED FOR

- ✓ Wooden furniture
- ✓ Seasoned wood surfaces
- ✓ Veneer surfaces
- ✓ Interior applications

HOW TO USE

- 1 Clean and sand wood surface.
- 2 Apply insulating coat (Epoxy Insulator).
- 3 Add accelerator to base, then mix catalyst prior to spraying.
- 4 Spray apply 6–8 coats as per recommended process.
- 5 Allow to dry, progressive sand and uniformly buff for high gloss.

