

FIRE PUMP PRIORITY
MAIN:1 PUMP

=====

FP-1 FP-2 FP-3



FIRE PUMP PRIORITY
MAIN:2 PUMP

=====

FP-1 FP-2 FP-3



FIRE PUMP PRIORITY
STAND-BY PUMP

=====

FP-1 FP-2 FP-3



ENGINE FAILS TO START
STATUS

=====

FP-1 FP-2 FP-3



FPDC CONTROL PANEL

Version: FPDC\305\26\W.01

Fire Pump Sequence 1
Main1 PUMP : FP1
Main2 PUMP : FP2
Standby PUMP: FP3

- FALSE START FILTER
Ignores short pressure spikes
- FAIL SAFE LOGIC - AUTO STANDBY START
S/B auto-starts if main pump fails to start.
- ORIGINAL LOGIC INTACT
Fire demand start unchanged
- PRIORITY SELECT P1/P2/P3
Change via panel push button
- EQUAL RUN HOURS
Saves fuel & engine wear

FIRE PUMP RUNNING
STATUS

=====

FP-1 FP-2 FP-3



RESET



SET
PRIORITY

FIRE PUMP DUTY CONTROL PANEL

Designed / Mfg. By:

=====

M/s VISHAL ENTERPRISES
P7, Rising City, Thakar Nagar,
Maan, Hinjewadi PH1, PUNE 411057

Contact: 8275580423 / 7350833874
Email: vishalent@yahoo.co.in

