Patterning What exactly is a Topographically Patterned Surface?

Photolithography

Chemical Patterns Differnt Chemical Properties. Patters Topographic Patters Disordered Patters Chemically Homogenemo

Line Greling Str.

Instability and Soft Patterning Laboratory भारतीय प्रौद्योगिकी संस्थान खडगपुर Indian Institute of Technology

Top Down Approaches:: Lithography


- Photolithography
- Soft Lithography
 - Micro contact printing
 - Nano Imprint Lithography group of methods
 - Capillary Force Lithography
 - Micro Molding in Capillaries

- (1) How do you make Such Topographic Petterns.
 - (2) What are the potential applications of Such patterns.
- Structural Superhydropho bicis-> Self Cleaning Surfaces
- → Diffraction of Light →

 Rain bour Color on the beek Side of a CD.

 → Insect Vision/Chenquip of Color like

Back Side of a Compact Disc,



Some topographic Patterns ->
Which have feeture Size
Comperable to the WL of Visible
Light ->

Structural Color

The BIGGEST application area of Patterning







Pentium II processor

200 M Hz Clock Speed

500 MBHDD

1999

To what is this change attributed to?

Intel Core i9-9980XE

4.5 GHz speed

5 TB HDD

2019


Patterning in Micro Electronics

The micro electronic industry PC, Laptop, Cell Phone, i-pod


Have you ever thought how every year the speed of the computer processor becomes faster or how the memory sizes increases?


P

Reality is the tremendous progress in the field of micro electronics industry is attributed to the progress of a specific patterning technique, which is known as photolithography.




The p – n Junction





- A p—n junction is formed at the boundary between a p-type and n-type semiconductor.
- If two separate pieces of material were used, this would introduce a grain boundary between the semiconductors which severely inhibits its utility by scattering the electrons and holes.
- so p—n junctions are created in a single crystal of semiconductor by doping
- P-N junctions are elementary "building blocks" of many semiconductor electronic devices such as diodes, transistors, solar cells, and integrated circuits

Some Pa



Instability and Soft Patterning Laboratory भारतीय प्रौद्योगिकी संस्थान खडगपुर Indian Institute of Technology

1 n-type doping Chamber 圣 基 =

| M | M | M |

| P-type doped Doping of the exposeel Remove the p-n function


nplnln

(1) Some Topographic teatures on the nefer (of a meterial that does not react/
degrade and prevents
diffusion of the dopont) (2) Place in n-type doping chember.

These strips or patterns

prevent the n type dopontfrom reaching the surface ofthe wafer.

The p - n Junction




Keep making the domains Smeller and

So you can put more p-n junctions.

- Line Width in a Computer chip.
- So simply put if your lines become narrower, you can have more number of p n junctions on a chip whose physical dimensions are the same.
- These lines are created by the method of Photolithography.
- For example while a Pentium II processor had lines which are 300 nm wide, the lines are about 32 nm wide in a i-core 5 processor.
- Similarly progress in patterning is also responsible for higher capacity memories.

Kharaqpur 🕮

Intel Microprocessors – Brief History





Historically, advances in microelectronics have been due to ability to making smaller and denser patterns.

- →Photolithography has been the workhorse of the semiconductor industry.
- → Lithography is key technology pacing Moore's Law












Photolithography

- Innovations in the integrated circuit industry is the main motive force for the tremendous advance in the field of surface patterning.
 - Transistor invented in 1947.
 - The first Integrated Circuit built in 1960. The line width in integrated circuits was 5 μ m.
 - First IBM PC (1981), 16 K Byte memory, 4.77 MHz clock speed.
 - Line widths of 350 nm was achieved, when 40 GB D-RAM was discovered in 1997.
 - Present state ~ 40 nm.
- Narrower is the line size, closer is the packing, better is the performance of the circuit!





Photolithography Process: Basic Steps



Silicon Wafer

Photo resist

Spin Coating

Mask

Optical Source

Mask Aligner

Developer

Etching